

Return Loss (dB) is a comparison of the reflected signal to the forward signal in decibels. If the antenna system is perfectly matched, the Return Loss would be negative infinity dB.

Cellular systems and antenna manufacturers often use VSWR for specifications. Match Efficiency is popular for testing because it is easy to determine a good match versus a bad match. For example a system with a VSWR of 1.50 would show -13.98 dB Return Loss and 96% Match Efficiency.

Auto Scale vs. Manual Scale

In swept mode Auto Scaling sets the measurement unit scale so the trace is maximized in the graph. This makes it easier to read.




Figure 3 Auto Scaling Swept Frequency Mode

However, if you plan to look at the size or shape of traces for quick comparisons, it might be more meaningful to set a standard scale. Be aware that it is possible to set the scale manually so the information is not on the display at all.




Figure 4 Manual Scaling Swept Frequency Mode

In the single sweep mode Auto Scaling sets the measurement unit scale so the pointer is mid range of the previous reading. The maximum and minimum scale values are approximately 10% higher or lower than the measured value.




Figure 5 Auto Scaling Single Frequency Mode

This setting is an operator preference based on the mode that best presents the desired information.




Figure 6 Manual Scaling Single Frequency Mode

Sweep Type- Single Hold vs. Continuous

Continuous sweep continually sweeps the selected frequency band updating the measured value with each sweep. An asterisk (*) is blinking on the left side of the display to indicate sweep rate. The single hold mode will freeze a trace on the display and hold is displayed on the right. Holding a trace is also helpful before saving the trace, (more about saving traces under that heading later in this section).

Understanding Various Operating Modes

The Antenna Tester is connected and the cellular system is selected (see basic operation). User selections are customized, the power is on, and the top level menu is displayed (also in basic operation). Now what?

Before we explain how to measure the antenna match, a brief discussion of your options is in order.

Since the AT-800 will change the way you test antennas we suggest taking some time to explore the different operating modes and find what is best for your application.

Swept Frequency vs. Single Frequency

Swept frequency graphically displays the unit of measure over a band of frequencies. The cursor, a vertical dotted line, can be moved with the arrow keys to pinpoint a particular frequency. The measured match value and the frequency at the cursor position are shown at the top of the display.




Figure 1 Swept Frequency

- Enter the frequency using the **numeric keypad** or change the frequency using the **UP/DOWN** arrow keys.
- Press the **ENTER** key. The cursor will blink on the stop frequency.
- Enter the frequency using the **numeric keypad** or change the frequency using the **UP/DOWN** arrow keys.
- Press the **ENTER** key. The tester will begin sweeping.
- **CENTER** MHz - The cursor will blink on the Center frequency and Center MHz will be highlighted.
- Enter the frequency using the **numeric keypad** or change the frequency using the **UP/DOWN** arrow keys.
- Press the **ENTER** key. The tester will begin sweeping.
- Press the **SPAN** key. Enter the frequency using the **numeric keypad** or change the frequency using the **UP/DOWN** arrow keys.
- Press the **ENTER** key. The tester will begin sweeping.

Select Measurement Units

Antenna match information can be presented using four different measurement units. Depending on your application, follow the steps below to select Rho, VSWR, %Match or Return Loss.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **MEAS UNITS** key.
- Press the **UNITS** key.


- Press either the **RHO**, **VSWR**, **%MATCH** or **RETURN LOSS** key. The selected unit will be shown on the left side of the display.
- Press **RETURN** to go back one menu level or **MENU** to return to the top menu level.

Select Auto or Manual Scale

Selecting the scale simply sets up how the information will look on the display.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **MEAS UNITS** key.
- Depending on desired mode press either **AUTO** or **MANUAL SCALE**:
 - **AUTO SCALE** - the units scale changes and the Antenna Tester begins sweeping.
 - **MANUAL SCALE** - the cursor will blink on the minimum scale value and Manual Scale will be highlighted.
 - Enter the desired value using the **numeric keypad** or change the value using the **UP/DOWN** arrow keys.
 - Press the **ENTER** key. The cursor will blink on the maximum scale value.
 - Enter the desired value using the **numeric keypad** or change the value using the **UP/DOWN** arrow keys.
 - Press the **ENTER** key. The tester will begin sweeping.

Measure Match



NOTE: If an out of range value is entered, the minimum (if under-range) or maximum (if over-range) value will be substituted. If a maximum value that is lower than the minimum value is entered, the cursor will blink again on the minimum value waiting for a correct entry. The actual range depends on the units selected.

HINT: Using the arrow keys will keep you in the acceptable range. If you are not sure if the larger value should be at the top or bottom of the scale, press the auto scale key to see where the software puts it.

Selecting the Sweep Type

Sweep types are continuous or single hold. Continuous will sweep and update the trace automatically. Single hold will sweep once and the trace will remain in the display. Each time single hold is pressed, the trace is updated.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **SWEEP TYPE** key.
- Depending on desired mode press either **SINGLE HOLD** or **CONT** key. **HOLD** will be displayed if single hold is selected. The tester begins sweeping if continuous is selected.

Saving a Trace

The AT-800 can store up to 12 traces. A saved trace can be used to evaluate long term antenna performance, compare performance under different conditions or for comparison to another antenna. A saved trace is also a powerful tool in limit testing (more about limit testing later in this section). The information can later be uploaded to a PC using optional interface software and the serial port. Traces are stored in nonvolatile memory so they are not lost when the Antenna Tester is turned off.

- Press the **MENU** key.
- Press the **UTIL** key.
- Press the **PRESET** key.

Set Serial Baud Rate

Measurement data can be transferred between the AT-800 and a personal computer using the serial port and optional interface software. The data can then be used for analysis, printed, or stored.

The data transfer rate (baud rate) between the Antenna Tester and computer must be identical and set to 9600. To change the baud rate for the serial port on the Antenna Tester, follow the steps below. Complete interface software instructions are included with the software.

- Press the **MENU** key.
- Press the **UTIL** key.
- Press the **SERIAL** key.
- Repeatedly press the **SERIAL** key until the 9600 is displayed.

Connecting the Antenna Tester

The following paragraphs will explain how to connect the Antenna Tester for various operations. Refer to the component description diagram on page 4 of the Introduction section if needed.

Connecting External DC

CAUTION

Required input is 11 to 16 VDC 250mA
Connector is wired outside positive, inside negative.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **TRACE** key.
- Press the **RECALL TRACE** key.
- Press the **REG-n** key for the desired trace, press the **MORE RECALL** key to access 5-8 and again to access 9-12. If needed, use the **ESC** key to back up. The saved trace will be displayed and the corresponding register number will be shown at the bottom of the display.

NOTE: The arrow keys can be used to move the cursor, and the corresponding measurement and frequency at the cursor will be displayed. Remember the up arrow key will move the cursor to the highest value on the trace and the down arrow key will move it to the lowest.

- Press the **RETURN** key to return to register selection.
- Press the **ESC** key to return to trace menu.

Clearing a Trace

When a trace is no longer needed or you need to clear registers for space, follow the steps below.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **TRACE** key.
- Press the **CLEAR TRACE** key.
- Press the **REG-n** key for the desired trace, press the **MORE CLEAR** key to access 5-8 and again to access 9-12. If

needed, use the **ESC** key to back up. The word *full* will be replaced by *empty* at the selected register.

- Press the **ESC** key to return to the trace menu.

Limit Testing

Limit testing is a quick pass-fail test using operator defined limits or a stored trace as a minimum for acceptability. Pass or fail will be displayed at the top of the display and an audible tone can be enabled to indicate a fail situation.

Limit testing is probably the most labor-efficient mode for operating the AT-900. Since all the software settings are retained when the tester is turned off, once the limit test is set up it's simply a matter of connecting the next antenna system, turning on the power and reading pass or fail.

Turn Audio On/Off

Audio tone for fail indication.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **LIMIT** key.
- Pressing the **AUDIO** key will toggle between on and off.

Selecting Limit Values

Valid limit values depend on measurement units selected. Valid entries are:

VSWR - between 1.0 and 100.0
 %Match- between 0 and 100%
 Return Loss- between -32 and 0 dB
 FHO- between 0.000 and 1.000

- Press the **MENU** key.
- Press the **MEAS MATCH** key.

- Press the **MENU** key.
- Press the **UTIL** key.
- Press the **CELL SYS** key.
- Press the appropriate key for the cellular system in use.
- Press either **BASE** or **MOBILE** depending on the band to be tested.

Setting the Auto Shut-Off Timer

In order to preserve battery life, the Antenna Tester will automatically shut off after 5, 15, 30 or 60 minutes without any keystrokes. Follow the steps below to select the length of time, before auto shut-off occurs.

- Press the **MENU** key.
- Press the **UTIL** key.
- Press the **TIMER** key until the desired interval is displayed.

Return to Factory Presets

When the Antenna Tester is turned on, the various software parameters will be set to the condition they were at when the tester was turned off.

To return the parameters to the factory setting follow the steps below. The parameters will be set to the conditions listed below.

Software Parameter	Factory Setting
Cellular System	AMPS, Mobile
Frequency Band	User; 806MHz - 960MHz
Measurement Units	VSWR
Scale	min., 1.0; max., 5.0
Mode	Swept Frequency
Sweep Type	Continuous
Baud Rate	9600
Auto Shut-off Timer	5
Audio	Off

Select Key

The operator instructions written for this manual were based on stepping through the software menu using the keys below the display. Once you are comfortable operating the AT-600, you might find it faster to use the select key to access some functions. These include: Units, Scale, Start and Stop Frequencies in swept frequency mode and Units, Scale, Frequency and Channel in single frequency mode.

Press the select key until the cursor is blinking at the desired function. The first function enabled depends on the last function selected through the menu.

Utility Messages

There are five utility messages that can be displayed to inform you of equipment, or procedural, conditions.

"Lo Batt" is displayed when battery voltage is less than 6.6V, refer to maintenance section for charging batteries.

"Busy" is displayed during mode changes indicating the measurement information is being updated.

"Hold" is displayed when in the Swept Frequency mode, and Single Hold is the selected sweep type.

"Pass" or "Fail" will be displayed indicating the appropriate results of a limit test.

"Noise" will be displayed if there is excessive background noise measured. The measurement may not be accurate. See "Troubleshooting" if this condition is persistent.

Out of Range Values

When entering numeric data, it is possible to enter a value out of range. Depending on the function, the Antenna Tester will either enter the minimum or maximum value, or the cursor will continue to blink on the function out of range waiting for the correct entry.

Selecting the Cellular System

Select the appropriate cellular system.

- Press the **SWEPT FREQ** key.
- Press the **LIMIT** key.
- Press the **VALUE** key. The cursor will blink next to it.
- Enter the desired value using the numeric keypad or change the value using the **UP/DOWN** arrow keys.
- Press the **ENTER** key. Pass or Fail will be displayed, a tone will be heard for fail if audio is enabled.

Using a Trace as the Limit

The trace you want to use for the limit must be saved. You can have the current antenna test running or start it after you set up the limit test.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **LIMIT** key.
- Press the **TRACE ->** **LIMIT** key.
- Press the **REG-n** key where the trace is stored. A dotted outline of the limit trace will be displayed with the new trace displayed over it. Pass or Fail will be displayed.




Figure 8 Dotted Outline of Limit Trace

NOTE: You can still move the cursor, change measurement units, frequency band and scale. The dotted outline of the limit trace will be automatically adjusted to provide a direct comparison with the antenna system under test.

Clearing a Limit

Follow the steps below to clear either an operator defined limit value or a trace limit. The trace will still be stored in memory, the limit value will be erased.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SWEPT FREQ** key.
- Press the **LIMIT** key.
- Press the **CLEAR LIMIT** key. The value field will change to off if an operator value was being used, the dotted outline of the limit trace will be removed if a trace was being used.

Single Frequency

This mode is useful for tuning antennas, particularly with the audio on. The frequency can be selected following user-defined instructions or automatically, by selecting the channel.

The correct cellular system and base or mobile should be selected and shown in the top right corner of the display, if not, follow steps in Basic Operation for Selecting Cellular System.

Selecting the Frequency - User Defined

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SINGLE FREQ** key.
- Press the **FREQ MHZ** key. The cursor will be blinking at the frequency and Freq MHz will be highlighted.
- Enter the desired frequency using the numeric keypad or change the value using the **UP/DOWN** arrow keys.
- Press the **ENTER** key. The measured value and the frequency will be shown at the top of the display.

Basic Operation

General Information

- To increase or decrease display contrast, press and hold the **BACKLIGHT** key while pressing either the **UP** or **DOWN** arrow key.

- To turn the backlight off, press the **BACKLIGHT** key.



Display Software Menu

- Press the **MENU** key to display the software menu.

General Information

Blinking Cursor (black square)

The cursor will be blinking in the selected area, indicating that the parameter for that area can be changed.



Enter Key

All data entry, and mode changes accessed using select key, require the enter key to be pressed before they are initiated.



Up/Down Arrow Keys

When a function is enabled for change, the up/down arrow keys can be used to either scroll through your choices or increase/decrease the numerical value. The actual increments depend on the function.



Left Arrow Key

The left arrow key can be used to backspace erasing one character at a time during data entry.



Escape (ESC)

Returns to previous menu without initiating a change.

Getting Started

This section describes initial quick steps to get started. For detailed information regarding connecting the Antenna Tester refer to that section at the end of this chapter.



Power On/Off

- To turn the Antenna Tester on, momentarily press the **ON** key. The results of a self test will be displayed if a failure is present. For more information about the self test or a failure, refer to the maintenance section.
- To turn the Antenna Tester off, press and hold the **ON** key for 1 second.

AC Mains Adapter

Operating the Antenna Tester using the AC Mains Adapter charges the batteries. Charging time is typically 8 hours. Charge life is minimum 2 hours of continuous operation with the backlight on. "Lo Batt" is displayed when the batteries require charging. Use supplied adapter only and do not use adapter with the batteries removed.

NOTE: For optimum battery life, charge the batteries only after the low battery indication is displayed.

Automobile Cigarette Lighter Adapter

The Antenna Tester can be operated using the 12V automobile battery via the optional cigarette lighter adapter. This method also charges the batteries, however charge time will depend on actual battery voltage



Backlight

- To turn the backlight on, press the **BACKLIGHT** key.

Selecting the Frequency - Automatically

- Repeatedly press the **SELECT** key until the cursor is blinking on CH (channel).
- Use the numeric keypad or **UP/DOWN** arrow keys to change the value.
- Press the **ENTER** key. The frequency will change to correspond to the selected channel.

Select Measurement Units

Antenna match information can be presented using three different measurement units. Depending on your application, follow the steps below to select Rh_o, VSWR, %Match or Return Loss.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SINGLE FREQ** key.
- Press the **UNITS** key.
- Press either the **RHO**, **VSWR**, **%MATCH** or **RETURN LOSS** key. The selected unit will be shown in the center of the display.
- Press the **RETURN** key to go back one menu level.

Select Auto or Manual Scale

Selecting the scale simply sets up how the information will look on the display.

- Press the **MENU** key.
- Press the **MEAS MATCH** key from the top level menu.
- Press the **SINGLE FREQ** key.
- Depending on desired method press either **AUTO** or **MANUAL SCALE**:
- **AUTO SCALE** - the units scale changes.

- **MANUAL SCALE** - the cursor will blink on the maximum scale value and Manual Scale will be highlighted.
 - Enter the desired value using the **numeric keypad** or change the value using the **UP/DOWN** arrow keys.
 - Press the **ENTER** key. The cursor will blink on the minimum scale value.
 - Enter the desired value using the **numeric keypad** or change the value using the **UP/DOWN** arrow keys.
 - Press the **ENTER** key.

NOTE: If an out of range value is entered, the minimum (if under-range) or maximum (if over-range) value will be substituted. If a maximum value that is lower than the minimum value is entered the cursor will blink again on the minimum value, waiting for a correct entry. The actual range depends on the units selected.

HINT: Using the arrow keys will keep you in the acceptable range. If you are not sure if the larger value should be at the right or left side of the scale, press the auto scale key to see where the software puts it.

Turn Audio On/Off

The pitch varies with the match condition allowing you to tune an antenna without having to look at the display.

- Press the **MENU** key.
- Press the **MEAS MATCH** key.
- Press the **SINGLE FREQ** key.
- Pressing the **AUDIO** key toggles between on and off.



BASIC OPERATION

Features

Swept Frequency Mode—Fast scan shows VSWR, RHO, match efficiency or return loss across an entire band. A movable cursor can be used to pinpoint a scan frequency and the corresponding measurement value is displayed.

Single Frequency Mode—Provides measurement information in units of Reflection Coefficient (RHO): Voltage Standing Wave Ratio (VSWR); % Match, or Return Loss (dB) at one frequency on a simulated meter movement. An audio generator can be enabled to produce a tone that is proportional to the match condition.

Auto Scaling—Used in either swept or single frequency modes, sets the Y axis for best measurement display.

Relative Field Strength—Verifies output of portable cellular phones having fixed antennas.

Cellular System Presets—Pre-programmed band segments for AMPS, GSM, PDC, CT-2, and CT-2 Korea cellular testing.

Limit Testing—Quick pass-fail indication; compares measurements to user selected limits.

Data Storage—Saves and recalls up to 12 traces to be used to set limit or long term monitoring of antenna performance.

Serial Communication Link—Built in serial port and optional software uploads data to a personal computer for analysis or storage.


Optional Equipment Available

Automobile Cigarette Lighter Adapter—(P/N 5A2238-1) Connects tester to standard 12V automotive cigarette lighter jack.

Carrying Case—(P/N 7000A850) Convenient and protective, large enough to carry the tester, AC adapter, connectors, field strength antenna and instruction book.

Verification Kit—(P/N 7000A845) Used to verify tester performance. Includes standard mismatch and connector adapter.

Interface Software—(P/N 7000A840) PC compatible software used to upload trace data for analysis, printing or storage. System requirements: IBM PC/XT/AT or equivalent; DOS 3.0 or later; Windows 3.1, 2Mb free hard disk space; color or grey scale VGA or SVGA monitor. Includes interface cable.



FIELD STRENGTH

Field Strength Measurement

With the field strength antenna installed, the Antenna Tester can be used to verify the output of portable cellular phones with fixed antennas. This is a relative measurement. The measurement sensitivity is such that a full scale deflection will occur at about three meters from a source that is radiating 12.6 watt effective radiate power (ERP). The gain factor can be adjusted to increase the measurement sensitivity.

Turn Audio On/Off

The pitch varies with the field strength.

- Press the **MENU** key.
- Press the **FIELD STR** key.
- Pressing the **AUDIO** key toggles between on and off.

Enter Gain Factor / Select Auto Gain

Increasing the gain factor increases the measurement sensitivity. Setting the gain to auto will set a gain factor so that the pointer is in the middle of the scale.

- Press the **MENU** key.
- Press the **FIELD STR** key.
- Press either:
 - **AUTO GAIN**: the pointer moves to the approximate middle of the scale.
 - **GAIN**: The cursor will blink on the gain value. Enter the desired value using the numeric keypad or change the value using the up/down arrow keys.
 - Press the **ENTER** key.

Display Description

- | | |
|------------------------------------|--|
| 1. Sweep Rate Indicator | Blinks when sweeping. |
| 2. Measurement Units | Indicates selected measurement units. |
| 3. Trace | Graphic display of measured results across selected frequency band. |
| 4. Menu Select Key Labels | Defines function of menu select keys located below the display. |
| 5. Frequency Band Scale | Displays frequency band selected. |
| 6. Cursor | Used to select measurement position on the trace. |
| 7. Utility Label | Area for displaying general data (Lo Batt, Busy, Hold, Noise, and test results). |
| 8. Band | Indicates selected band for cellular system defined, (Tx, Rx, TxRx, or User). |
| 9. Base / Mobile Indicator | Indicates Base or Mobile selection. |
| 10. Cellular System | Indicates cellular system selected (AMPS, GSM, PDC, CT-2, CT-2 Korea). |
| 11. Frequency | Selected Frequency (for swept mode this is frequency at the cursor position). |
| 12. Measured Value | Numeric display of measured value (for swept mode this is the value at the cursor position). |
| 13. Measurement Units Scale | Displays user defined measurement scale. |
| 14. Pointer | Moves across scale to show analog type indication of measured value. |
| 15. Channel | Channel number corresponding to selected frequency. |




Figure 1 Swept Frequency Mode Sample Display





Figure 2 Single Frequency Mode Sample Display



MAINTENANCE

Operational Tests

Power-up

There are several operational tests run at power up. The test is displayed only if any of the tests failed. The results are displayed to the right of the test as shown in figure 1. If you would like the test screen displayed regardless of results, press any key while pressing the ON key at initial power up. If any test fails, check the troubleshooting section for possible correction. When displaying the tests as described above, a stuck key will be indicated.

Firmware Rev.—Revision date for the firmware installed.

NVram—	Checks for valid contents
Rom—	
EEprom—	
Ram—	
A/D—	Checks for proper circuit operation
Temp—	
PLL—	

Stuck_Keys—Checks if keys are depressed at power up.

Battery Test

The battery test checks the output voltage of the the batteries. The result is displayed in a simulated analog meter type graphic with the value shown at the top of the display. The scale is set from 6-8V. If the voltage measured is less than 7V you should charge the batteries.

Component Description

- LCD Display**
Backlit dot matrix. Backlight is on a timer to increase battery life.
- External DC Connector**
Connection for AC Mains and Cigarette Lighter Adapters.
- Cursor Keys**
In swept frequency mode pressing or holding this key moves the cursor to the left. During data entry this key will erase data.
Left Arrow
In swept frequency mode pressing or holding this key moves the cursor to the right.
Right Arrow
Moves the cursor to the maximum point on the displayed trace. During data entry this key will increase numeric data.
Up Arrow
Moves the cursor to the minimum point on the displayed trace. During data entry this key will decrease numeric data.
- Backlight Key**
Turns backlight on or off.
- ON Key**
Press to turn tester on, press and hold to turn tester off.
- +/- Key**
Toggles numeric value between positive and negative.
- Enter Key**
Press to complete data entry.
- ESC Key**
Back up through menu structure. At the top menu level, blanks menu. Escapes from data entry without saving changes.
- Menu Key**
Displays software menu and enables menu select keys
- Select Key**
Enables current parameter, indicated by flashing cursor, to be changed. Pressing this key again enables the next parameter to be changed.
- Numeric Keys**
Input Numeric values.
- Menu Select Keys**
Used to access the menu sections described directly above them. Can also be used to scroll through available settings in a particular parameter.
- Test Port**
Connect antenna or antenna lead.
- Serial Port**
Connect communication cable to allow data transfer to a PC.




Figure 1 Power-up Self Test

NOTE: The AT-900 will shut off if the battery is too low and full accuracy is maintained at any battery voltage.

- Be sure the AC mains adapter is not connected.
- Press the **MENU** key.
- Press the **TEST** key.
- Press the **BATT TEST** key.
- Press the **RETURN** key to end the test.




Figure 2 Battery Test

Display Test

The display test is used to be sure that each area of the display is functional. When the test is started the display is filled with various characters. Each pixel then changes state, either from black to white or white to black. If there is any area that is not functional return the tester to Bird Electronic for repair.

- Press the **MENU** key.
- Press the **TEST** key.
- Press the **DISP TEST** key. The test is started.
- Press the **ESC** key to stop the test.





Figure 3 Display Test



Self Test

The self test is similar to the operational tests run at power up described on page 2 of this section. The one difference is the keypad test.




Figure 4 Self Test


- Press the **MENU** key.
- Press the **TEST** key.
- Press the **SELF TEST** key.
- To test the keypad, Press each key (except esc and on). The value next to Keypad is hexadecimal and corresponds to the key pressed. If the value does not change for each key, refer to "Troubleshooting" in this section.
- Press the **ESC** key to stop the test.

Cleaning

Clean the antenna tester and the display with a soft cloth dampened with mild detergent and water only.


CAUTION

Harsh or abrasive detergents and some solvents can damage the display unit and information on labels.



1. AT-800
2. AC Mains Adapter
3. Female TNC Connector
4. Field Strength Antenna
5. Instruction Book (Not Shown)

Items Supplied



Calibration

For maximum performance and accuracy, the Antenna Tester should be calibrated once every 12 months. Return the unit to Bird Electronic authorized service center listed below.

Service Center

U.S.A. Sales and Manufacturing

Service Group
Bird Electronic Corporation
30303 Aurora Road
Cleveland (Solon), Ohio 44139-2794
Phone: (216)248-1200
Fax: (216)248-5426
Cable: BIRDELEC
Telex: 706898 Bird Elec UD

Sales Offices

European Sales Office

Bird Electronic Ltd.
Unit 1 Shannon Business Centre
Town Centre Shannon
County Clare, Ireland
Phone: 353 61 360583 or 353 61 360577
Fax: 353 61 360585

Pan Asian Sales Office

Bird Electronic Ltd.
3A Unit 6 Tyrnwhitt Road
Singapore 0820
Phone: 65 299 2537
Fax: 65 299 8509

- Flip the back cover in the direction of the arrow shown below. To avoid disconnecting P2, (battery connector), lay the back cover next to the front.
- Remove the old batteries.




Figure 5. Battery / Fuse Replacement

- Install the new batteries checking the orientation of the positive and negative terminals. Polarity is indicated on the case, and in figure 5.
- Be sure P2 is connected and the shock strips are still in place.
- Place the back cover over the front cover making sure it is properly seated.
- Replace the six screws.
- Run the battery test on page 2 of this section.

BIRD ELECTRONIC CORPORATION
 14000 BIRDBUILDING DRIVE
 BIRDA, TEXAS 75009
 (817) 437-9200
 FAX (817) 437-9201
 BIRD ELECTRONIC CORPORATION
 14000 BIRDBUILDING DRIVE
 BIRDA, TEXAS 75009
 (817) 437-9200
 FAX (817) 437-9201

Fuse Replacement

CAUTION

Replace with only the same type and rating fuse.
315mA 250V

- Follow the steps outlined in "Battery Replacement" replacing the fuse where replacing the batteries is indicated.

Troubleshooting

Operator maintenance or service is limited to battery and fuse replacement. Any other required service must be performed at the factory.

Refer to the following paragraphs for help in isolating error conditions.

The Antenna Tester will not power up.

Power for the Antenna Tester can be provided in three ways—the internal batteries, an AC mains adapter or an optional automobile cigarette lighter adapter. Try to power the tester using each available means. The internal batteries may need charged, or if recently replaced, are installed incorrectly. The AC mains adapter may not be securely connected, may be damaged, or there is no power supplied at the wall receptacle. The internal fuse may have opened and requires replacement. If the unit was recently opened, recheck P2, the battery connector, be sure it is securely connected. Follow the instructions for battery and fuse replacement when opening the unit.

NVRAM Test Fails

An NVRAM error indicates the information in nonvolatile RAM, a type of memory, is not valid. The probable cause is power was lost. When the unit is off, the batteries, if charged and present, or power from the AC mains adapter, if connected, supply power to retain stored trace data and software settings. This information is lost if all power is removed. Clear the error by pressing the ESC key.

Clearing a Limit	3-14
Single Frequency	3-14
Selecting the Frequency - User Defined	3-14
Selecting the Frequency - Automatically	3-15
Select Measurement Units	3-15
Select Auto or Manual Scale	3-15
Turn Audio On/Off	3-16

Field Strength

Field Strength Measurement	4-2
Turn Audio On/Off	4-2
Enter Gain Factor / Select Auto Gain	4-2

Maintenance

Operational Tests	5-2
Power Up	5-2
Battery Test	5-2
Display Test	5-3
Self Test	5-4
Cleaning	5-4
Calibration	5-5
Service Center	5-5
Sales Offices	5-5
Charging Batteries	5-6
Battery Replacement	5-6
Fuse Replacement	5-8
Troubleshooting	5-8
Parts List	5-10
Specifications	6-2

Utility Messages	2-4
Out of Range Values	2-4
Selecting the Cellular System	2-4
Setting the Auto Shut-Off Timer	2-5
Return to Factory Presets	2-5
Set Serial Baud Rate	2-6
Connecting the Antenna Tester	2-6
Connecting External DC	2-6
Connecting the Antenna	2-7
Measure Match	
Understanding Various Operating Modes	3-2
Swept Frequency vs. Single Frequency	3-2
Band Selection—Presets vs. User Defined	3-3
Measurement Units—RHO vs. VSWR vs. Match Efficiency (%) vs. Return Loss (dB)	3-3
Auto Scale vs. Manual Scale	3-4
Sweep Type—Single Hold vs. Continuous	3-5
Swept Frequency	3-6
Select Frequency Band - Presets	3-6
Select Frequency Band - User Defined	3-6
Select Measurement Units	3-7
Select Auto or Manual Scale	3-8
Selecting the Sweep Type	3-9
Saving a Trace	3-9
Recalling a Trace	3-10
Clearing a Trace	3-11
Limit Testing	3-12
Turn Audio On/Off	3-12
Selecting Limit Values	3-12
Using a Trace as the Limit	3-13

Be sure to read battery charging and replacement sections if the problem persists.

ROM, EEPROM, RAM, A/D, TEMPR, PLL Test Fails

Ensure the results are valid by repeating the self test or turning the unit off then back on. If the problem persists return the unit for service.

Stuck Keys Test Fails

If any characters other than 0 are displayed next to "stuck keys" during power up test, perform the keypad test on page 4 of this section. Remember, if a key is depressed during power up to display the power up test results it is normal for other characters to be displayed. If the key remains stuck return the unit for service.

"Noise" Is Displayed During Testing

The Antenna Tester measures background noise to determine if nearby signals could cause an erroneous match measurement. Power down all nearby transmitting antennas. All interfering signals must be removed before resuming measurement.

Table of Contents

Notice ii

Changes to this Manual ii

About this Manual iii

Safety Symbols iii

Typography iv

Chapter Layout iv

Introduction

Menu Structure 1-1

Items Supplied 1-2

Component Description 1-5

Display Description 1-7

Features 1-8

Optional Equipment Available 1-8

Basic Operation

Getting Started 2-2

Power On/Off 2-2

AC Mains Adapter 2-2

Automobile Cigarette Lighter Adapter 2-2

Backlight 2-2

Display Software Menu 2-3

General Information 2-3

Blinking Cursor (black square) 2-3

Enter Key 2-3

Up/Down Arrow Keys 2-3

Left Arrow Key 2-3

Escape (ESC) 2-3

Select Key 2-4

Parts List

Part Name	Part Number
AT-800 Complete	7000A801
Parts Supplied with AT-800 Complete, or Installed when shipped.	
Battery (6 required)	5A2230
Fuse	5-1976-11
AC Mains Adapter, 115v	5A2229
AC Mains Adapter, 230v	5A2236
Female TNC Connector	4240-407
Field Strength Antenna	5A2228-1
Instruction Book	920-AT800-1
Foam Shock Strips (2)	5A2243

Optional Adapters:

N/m	4240-402
N/f	4240-403
BNC/m	4240-404
BNC/f	4240-405
TN/m	4241-406
UHF/m	4241-408
UHF/f	4240-409
SMA/m	4240-410
SMA/f	4240-411

Optional Parts or Accessories

Automobile Cigarette Lighter Adapter	5A2238-1
Interface Software	7000A840
Includes Cable	5A2264-9MF-10
Verification Kit	7000A845
Carrying Case	7000A850

About this Manual (cont.)

Typography

There are two types of keys on the Antenna Tester. A *Hard Key* is a key that has a particular function and it is indicated on the key. These key names are set in a bold typeface, e.g. Press the **MENU** key.

A *Menu Select Key*, (there are five under the display), will have a different label, or name, depending on the selected function. The name will be at the bottom of the display located directly above the corresponding key. These key names are set in a bold italic typeface, e.g. Press the **MEAS MATCH** key.

Chapter Layout

Introduction—Will help you become familiar with the parts of the Antenna Tester, Features Available, and Optional Equipment.

Basic Operation—Everyone should read this section! Getting Started will provide the information required to get the Antenna Tester powered up. General information provides helpful information about how to operate the Antenna Tester, and some time saving hints for alternate operating methods.

Measure Match—Since the AT-800 Antenna Tester offers a unique method of measuring Antenna Systems we have included the section, "Understanding Various Operating Modes". Even if you already know the basics of antenna match testing you might find this section useful. The remainder of the chapter provides step by step instructions for measuring match.

Field Strength—Provides step by step instructions for measuring relative field strength of fixed cellular antennas.

Maintenance—This chapter contains the information required to keep the AT-800 working for you. There are instructions for several operational tests on the Antenna Tester, battery and fuse information, calibration requirements, parts information and troubleshooting information.



$$V \cdot D = P$$



$$|P_v| = |P_i| = \frac{VSWR - 1}{VSWR + 1}$$



$$Z = \sqrt{\frac{R + j\omega L}{G + j\omega C}} \quad (1)$$



$$\int_0^1 x \, dx$$



SPECIFICATIONS

Frequency Range 806 to 960 MHz
Frequency Resolution 30 kHz
Measurement Range
 VSWR 1.00 to 100.00
 Match Efficiency 0 to 100%
 Return Loss -32 to 0 dB
 Rho 0.000 to 1.000
Measurement Speed
 Single Frequency 5 Readings/second
 Swept Frequency 1 Sweep/second
Test Port
 Impedance 50Ω nominal
 Connector (Field Interchangeable) Female TNC
Field Strength
 Range 0 to 100% Relative
 Sensitivity Full scale deflection at 3m @ 12.6 Watts ERP
Power Requirements
 Batteries Six Rechargeable AA (KR-15/51)
 External DC 11 to 16 VDC 250mA
External AC Adapter 108 to 132, or 207 to 253 VAC @ 48 to 63 Hz
Interface Serial (female DB-9 connector)
Operating Temperature 1.0° to 50° C (32° to 122° F)
Storage Temperature -40° to 71° C (-40° to 160° F)
Size (including connector) 6" x 4 5/8" x 1 1/4" (204mm x 118mm x 42mm)
Weight 1 3/4 lb (0.8 kg)

Specifications are subject to change without notice.

About this Manual

Many people read the operators manual only as a last resort. If you are one of those people, you should at least read the next two pages so that you can find the information when you do need it. You will also learn where to find valuable time saving information.

Safety Symbols

WARNING

Warning notes call attention to a procedure, which if not performed correctly, could result in personal injury.

CAUTION

Caution notes call attention to a procedure, which if not performed correctly, could result in damage to the equipment.



This symbol appears on the equipment indicating there is important information in the instruction manual regarding that particular area. See pages 2-7 and 5-6 for specific cautions.

NOTE: Calls attention to supplemental information

HINT: Provides time saving information concerning a particular procedure.

Notice

Changes to this Manual

We have made every effort to ensure this manual is accurate at the time of publication. If you should discover any errors or if you have suggestions for improving this manual, please send your comments to our factory. This manual may be periodically updated, when inquiring about updates to this manual refer to the part number and revision level on the title page.

Limited Warranty

All products manufactured by Seller are warranted to be free from defects in material and workmanship for a period of one (1) year, unless otherwise specified, from date of shipment and to conform to applicable specifications, drawings, blueprints and/or samples. Seller's sole obligation under these warranties shall be to issue credit, repair or replace any item or part thereof which is proved to be other than as warranted; no allowance shall be made for any labor charges of Buyer for replacement of parts, adjustment or repairs, or any other work, unless such charges are authorized in advance by Seller.

If Seller's products are claimed to be defective in material or workmanship or not to conform to specifications, drawings, blueprints and/or samples, Seller shall, upon prompt notice being filed, either examine the products where they are located or issue shipping instructions for return to Seller (transportation charges prepaid by Buyer), in the event any of our products are proved to be other than as warranted, transportation costs (freight and cartage) to and from Seller's plant, will be borne by Seller and reimbursement or credit will be made for amounts so expended by Buyer. Every such claim for breach of these warranties shall be deemed to be waived by Buyer unless made in writing within ten (10) days from the date of discovery of the defect.


The above warranties shall not extend to any products or parts, thereof which have been subjected to any misuse or neglect, damaged by accident, rendered defective by reason of improper installation or by the performance of repairs or alterations outside of our plant, and shall not apply to any goods or parts thereof furnished by Buyer or acquired from others at Buyer's request and/or to Buyer's specifications. In addition, Seller's warranties do not extend to the failure of tubes, transistors, bases and batteries, or to other equipment and parts manufactured by others, except to the extent of the original manufacturer's warranty to Seller.

The obligations under the foregoing warranties are limited to the process errors listed. These warranties provide exclusive remedy for defects, expressly in lieu of all other remedies including, but not limited to, consequential damages. SELLER HEREBY DISCLAIMS ALL LIABILITY FOR CONSEQUENTIAL DAMAGES, WHETHER EXPRESS, STATUTORY OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, AND NO PERSON IS AUTHORIZED TO ASSUME FOR SELLER ANY OBLIGATION OR LIABILITY NOT STRICTLY IN ACCORDANCE WITH THE FOREGOING.

Operator Manual
AT-800 Antenna Tester

BLVD
Electronic Corporation
Cleveland (Solon) Ohio USA

© Copyright 1995 by Blvd Electronic Corporation
Instruction Book Part Number 920-A1800-1 Rev.D



**QUALITY INSTRUMENTS
FOR RF POWER MEASUREMENTS**

From 2 to 2300 MHz and from 25 milliwatts
to 250 kilowatts in 50 ohm coaxial line systems

TERMALINE®

**ABSORPTION
WATTMETERS**

LOAD RESISTORS

CALORIMETERS

THRULINE®

**DIRECTIONAL
MONITORING
WATTMETERS**

TENULINE®

ATTENUATORS

COAXSWITCH®

**SELECTOR
SWITCHES**

COAXIAL RF FILTERS

SEINTRILINE®

FILTER-COUPPLERS



BIRD
ELECTRONIC CORPORATION
30303 Aurora Road Cleveland, (Solon) Ohio 44139-2794

OPERATING INSTRUCTIONS

**AT-800
ANTENNA TESTER**

