

APPLIES TO P21DDN AND P31DDN RADIOS

NOTE: This manual has been reproduced in "Full Page" format, with all pages scanned in actual size. To print sections of long pages in standard 8.5 by 11 inch size, use the Adobe "Snapshot" tool to select the portion or detail you want to print. Click on "Tools" then on "Basic" and then on "Snapshot Tool." To get a full-size reproduction of this document, take the PDF file to a commercial graphics shop for printing on a document (roll) printer.



**MOTOROLA**

**PT Series**



**"Handie-Talkie"® FM Radiophone**

25-54 MC 1.4 & 5 W RF POWER

MANUAL 68P81032A45-C



**MOTOROLA**

HANDIE-TALKIE

**FM RADIOPHONE**

1.4 & 5.0 W RF POWER

25-54 MC

PORTABLE

TRANSISTORIZED



Model P31DDC-1030AM



**MOTOROLA INC.**

**Communications Division**

ENGINEERING PUBLICATIONS

4501 WEST AUGUSTA BOULEVARD

CHICAGO, ILLINOIS 60651

Copyright 1966 by Motorola, Inc.

Printed in U. S. A.

9/23/66-AP

68P81032A45

Issue - C

# CONTENTS

SECTION	PAGE
Guaranteed Performance Specifications . . . . .	iii
Model Chart . . . . .	iv
 <b>DESCRIPTION AND OPERATION</b>	
Description . . . . .	1
Pre-Operational Notes . . . . .	2
Operation . . . . .	2
Accessory Table . . . . .	4
Accessories . . . . .	5
 <b>BATTERY REPLACEMENT AND CHARGING</b>	
Battery Replacement Procedure . . . . .	6
Dry Batteries . . . . .	6
Nickel-Cadmium Batteries . . . . .	7
Battery Life . . . . .	7
 <b>THEORY OF OPERATION</b>	
General . . . . .	7
Circuit Theory . . . . .	8
 <b>MAINTENANCE</b>	
Test Equipment . . . . .	11
Test Procedure . . . . .	11
Disassembly Procedure . . . . .	13
Receiver Stage Analysis . . . . .	15
Transmitter Service Notes . . . . .	17
Repair . . . . .	17
 <b>SERVICE PROCEDURES AND DIAGRAMS</b>	
Transmitter Alignment Procedure (NTB6060 Series) . . . . .	19
IDC Adjustment Procedure . . . . .	20
Transmitter Alignment Procedure (NTB6050 Series) . . . . .	23
IDC Adjustment Procedure . . . . .	24
Receiver Alignment Procedure . . . . .	27
P21/P31DDN-1000 Series Intercabling Diagram (A Version Control Panels) . . . . .	29
P21/P31DDN-1000 Series Intercabling Diagram (B Version Control Panels) . . . . .	30
P21/P31DDN-3000 Series Intercabling Diagram (A Version Control Panels) . . . . .	31
P21/P31DDN-3000 Series Intercabling Diagram (B Version Control Panels) . . . . .	32
Transmitter Printed Circuit Board and Wiring Diagram . . . . .	33
Handset Models Receiver Printed Circuit Board and Wiring Diagram . . . . .	34
Transmitter Printed Circuit Board and Wiring Diagram . . . . .	35
Receiver Printed Circuit Board and Wiring Diagram . . . . .	36
Transmitter Printed Circuit Board and Wiring Diagram . . . . .	37
25-42 MC "Private-Line" Printed Circuit Board and Wiring Diagram . . . . .	39
42-54 MC "Private-Line" Printed Circuit Board and Wiring Diagram . . . . .	40
Carrier Squelch Schematic Diagram and Parts List (Sheet 1 of 2) . . . . .	42
Carrier Squelch Schematic Diagram and Parts List (Sheet 2 of 2) . . . . .	43
Dual Squelch "Private-Line" Schematic Diagram and Parts List (Sheet 1 of 2) . . . . .	46
Dual Squelch "Private-Line" Schematic Diagram and Parts List (Sheet 2 of 2) . . . . .	47

**GUARANTEED PERFORMANCE SPECIFICATIONS**

GENERAL

MODELS		P31DDN-1000 Series	P31DDN-3000 Series	P21DDN-1000 Series	P21DDN-3000 Series
POWER SUPPLY		Eleven #1050 Industrial "D" cells or one 14.0 v nickel-cadmium battery.			
BATTERY DRAIN	Standby	4 ma at 14.0 v	10 ma at 14.0 v	4 ma at 14.0 v	10 ma at 14.0 v
	Receive	55 ma at 14.0 v	62 ma at 14.0 v	55 ma at 14.0 v (12 ma**)	62 ma at 14.0 v (19 ma**)
	Transmit	900 ma at 13.5 v	900 ma at 13.5 v	410 ma at 14.0 v	415 ma at 14.0 v
DIMENSIONS (excluding antenna) (with dry cell batteries)	Speaker-microphone	9" x 7-3/4" x 3-3/4"			
	Speaker-Handset	9" x 8-3/4" x 3-3/4"			
	Handset	9" x 8-3/4" x 3-3/4"			
DIMENSIONS (excluding antenna) (with nickel-cadmium batteries)	Speaker-microphone	9" x 6-3/8" x 3-3/4"			
	Speaker-Handset	9" x 7-3/8" x 3-3/4"			
	Handset	9" x 7-3/8" x 3-3/4"			
WEIGHT* (with dry cell batteries)	Speaker-microphone	7# 14 oz.	8#	7# 7 oz.	7# 9 oz.
	Speaker-Handset	8# 7 oz.	8# 9 oz.	7# 15 oz.	8# 1 oz.
	Handset	8# 4 oz.	8# 6 oz.	7# 12 oz.	7# 14 oz.
WEIGHT* (with nickel-cadmium batteries)	Speaker-microphone	6# 8 oz.	6# 10 oz.	6# 1 oz.	6# 3 oz.
	Speaker-Handset	7#	7# 2 oz.	6# 9 oz.	6# 11 oz.
	Handset	6# 13 oz.	6# 15 oz.	6# 6 oz.	6# 8 oz.

TRANSMITTER

CHASSIS MODEL	NTB6060 Series with NLB6120 Series Power Amplifier	NTB6050 Series
RF OUTPUT	5.0 w at nominal battery voltage (13.5 v)	1.4 w at nominal battery voltage (14.0 v)
FREQUENCY STABILITY	NTB6060 Series $\pm 0.002\%$ from $-30^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ ( $+25^{\circ}\text{C}$ reference)	NTB6050 Series $\pm 0.0025\%$ from $-30^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ ( $+25^{\circ}\text{C}$ reference)
MODULATION	16F3: $\pm 5$ kc for 100% at 1000 cps; or 36F3: $\pm 15$ kc for 100% at 1000 cps	
CRYSTAL MULTIPLICATION	16 times	
SPURIOUS AND HARMONICS	more than 52 db below carrier	more than 45 db below carrier
FM NOISE	At least 35 db below $\pm 3.3$ kc deviation at 1000 cps, or at least 40 db below $\pm 10$ kc deviation at 1000 cps	
AUDIO RESPONSE	$+1, -3$ db of 6 db/octave pre-emphasis characteristic from 300 to 3000 cps	
AUDIO DISTORTION	Less than 8% at 1000 cps, 2/3 rated maximum deviation	

RECEIVER

MODULATION ACCEPTANCE*	$\pm 5$ kc (split channel models) or $\pm 15$ kc (wide band models)		
SENSITIVITY	Less than 0.35 microvolt for 20 db quieting		
SPURIOUS AND IMAGE REJECTION	More than 70 db below carrier		
NOISE SQUELCH SENSITIVITY	Noise compensated type: adjustable sensitivity, will open at less than 0.18 microvolt		
TONE CODED SQUELCH SENSITIVITY		Fixed sensitivity will open at less than 0.18 microvolt	Fixed sensitivity will open at less than 0.18 microvolt
AUDIO OUTPUT	500 milliwatts to speaker or 3 milliwatts to handset at less than 10% distortion		
FREQUENCY STABILITY	$\pm 0.0025\%$ from $-30^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ ( $+25^{\circ}\text{C}$ reference)		
SELECTIVITY	More than 60 db at $\pm 20$ kc or $\pm 40$ kc measured by the 20 db quieting method		
CHANNEL SPACING*	20 kc ( $\pm 5$ kc Bandwidth)	40 kc ( $\pm 15$ kc Bandwidth)	

\*Tone-coded squelch available in split-channel models only

\*\*Applies to handset models without loudspeaker

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

FCC LICENSE DESIGNATION: P31 Series CC1505  
P21 Series CC1504B

# MOTOROLA

MODEL CHART

FM "HANDIE-TALKIE" RADIOPHONES

25-54 MC 1.4 & 5.0 W RF POWER

LEGEND

- = ONE ITEM INCLUDED
- = ONE ITEM INCLUDED WITH EVERY 5 (OR LESS) RADIO SETS
- = ONE ALTERNATE ITEM INCLUDED. CHOICE DEPENDENT UPON FREQUENCY
- = TWO ITEMS INCLUDED
- = ONE ALTERNATE ITEM INCLUDED (FACTORY OPTION)

\*REPRESENTS A SERIES OF MODELS AND NOT A SPECIFIC MODEL. THE SPECIFIC MODEL, AS STAMPED ON THE CHASSIS, IS DETERMINED BY ITS APPLICATION.

ITEM	DESCRIPTION	REFERENCE DIAGRAM	MODEL NUMBER	XMITR FREQ.	RCVR FREQ.	CHANNEL SPACING	TYPES OF SQUELCH	
							1.4 W RF OUTPUT SPEAKER-MICROPHONE MODELS	5.0 W RF OUTPUT SPEAKER-MICROPHONE MODELS
*NRB1120AA	RECEIVER (1-FREQ) WIDE CHANNEL; CARRIER SQUELCH	63E81017A21	P21DDN-1000AM	1	1	40 KC	X	X
*NRB1120AB	RECEIVER (1-FREQ) SPLIT CHANNEL; CARRIER SQUELCH	63E81017A21	P21DDN-1010AM	2	1	40 KC	X	X
*NRB1120AC	RECEIVER (2-FREQ) WIDE CHANNEL; CARRIER SQUELCH	63E81017A21	P21DDN-1030AM	2	2	40 KC	X	X
*NRB1120AD	RECEIVER (2-FREQ) SPLIT CHANNEL; CARRIER SQUELCH	63E81017A21	P21DDN-1100AM	1	1	20 KC	X	X
*NRB1120AE	RECEIVER (1-FREQ) SPLIT CHANNEL; DUAL SQUELCH	63E81017A22	P21DDN-1100AM	2	1	20 KC	X	X
*NRB1120AH	RECEIVER (2-FREQ) SPLIT CHANNEL; DUAL SQUELCH	63E81017A22	P21DDN-1130AM	2	2	20 KC	X	X
*NTB6050AA	TRANSMITTER (1-FREQ) CARRIER SQUELCH	63E81017A21	P21DDN-1100AM	1	1	20 KC	X	X
*NTB6050AB	TRANSMITTER (2-FREQ) CARRIER SQUELCH	63E81017A21	P21DDN-1130AM	2	1	20 KC	X	X
*NTB6050AC	TRANSMITTER (1-FREQ) "PRIVATE-LINE" MODEL	63E81017A22	P21DDN-3100AM	1	1	20 KC	X	X
*NTB6050AD	TRANSMITTER (2-FREQ) "PRIVATE-LINE" MODEL	63E81017A22	P21DDN-3130AM	2	2	20 KC	X	X
*NTB6060AA	TRANSMITTER (1-FREQ) CARRIER SQUELCH	63E81017A21	P21DDN-1000AR	1	1	40 KC	X	X
*NTB6060AB	TRANSMITTER (2-FREQ) CARRIER SQUELCH	63E81017A21	P21DDN-1010AR	2	1	40 KC	X	X
*NTB6060AC	TRANSMITTER (1-FREQ) "PRIVATE-LINE" MODEL	63E81017A22	P21DDN-1030AR	1	1	40 KC	X	X
*NTB6060AD	TRANSMITTER (2-FREQ) "PRIVATE-LINE" MODEL	63E81017A22	P21DDN-1100AR	2	2	40 KC	X	X
NLN6141A	"PRIVATE-LINE" SQUELCH BOARD (25-42 MC)	63E81017A22	P21DDN-1130AR	2	2	40 KC	X	X
NLB6142A	"PRIVATE-LINE" SQUELCH BOARD (42-54 MC)	63E81017A22	P21DDN-3100AR	1	1	20 KC	X	X
NLB6120A	HI POWER FINAL AMPLIFIER	63E81017A21 & 22	P21DDN-3130AR	2	2	20 KC	X	X
NCN6039A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1000AR	1	1	40 KC	X	X
NCN6040A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1010AR	2	1	40 KC	X	X
NCN6040B	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1030AM	2	2	40 KC	X	X
NCN6041A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1100AM	1	1	20 KC	X	X
NCN6042A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1100AM	2	1	20 KC	X	X
NCN6043A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1130AM	1	1	20 KC	X	X
NCN6043B	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1100AM	2	1	20 KC	X	X
NCN6044A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1130AM	1	1	20 KC	X	X
NCN6044B	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1100AM	2	1	20 KC	X	X
NCN6045A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-3100AM	1	1	20 KC	X	X
NCN6046A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-3130AM	2	2	20 KC	X	X
NCN6047A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1000AR	1	1	40 KC	X	X
NCN6048A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1010AR	2	1	40 KC	X	X
NCN6049A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1030AM	2	2	40 KC	X	X
NCN6050A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1100AM	1	1	20 KC	X	X
NCN6051A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1130AM	2	2	20 KC	X	X
NCN6052A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-3100AM	1	1	20 KC	X	X
NCN6053A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-3130AM	2	2	20 KC	X	X
NCN6054A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1000AR	1	1	40 KC	X	X
NCN6054B	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1010AR	2	1	40 KC	X	X
NCN6055A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1030AM	2	2	40 KC	X	X
NCN6039B	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1100AM	1	1	20 KC	X	X
NCN6057A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1130AM	2	2	20 KC	X	X
NCN6058A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-3100AM	1	1	20 KC	X	X
NCN6059A	CONTROL PANEL, 2-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-3130AM	2	2	20 KC	X	X
NCN6060A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE CARRIER SQUELCH	63E81017A21	P21DDN-1000AR	1	1	40 KC	X	X
NCN6061A	CONTROL PANEL, 2-FREQ. XMIT, 2-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1010AR	2	1	40 KC	X	X
NCN6065A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1030AM	2	2	40 KC	X	X
NCN6065B	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE DUAL SQUELCH	63E81017A22	P21DDN-1100AM	1	1	20 KC	X	X
NLN6129A	CARRYING STRAP						X	X
NLN6306A	UNIT HARDWARE KIT						X	X
NLN6307A	UNIT HARDWARE KIT						X	X
NLN6252A	TUNING TOOLS						X	X
NMN6017A	HANDSET						X	X
NMN6018A	MICROPHONE						X	X
YM45	RECEIVER CONTROL CRYSTAL						X	X
YM46	RECEIVER CONTROL CRYSTAL						X	X
YN	RECEIVER IF CRYSTAL						X	X
AB-2	TRANSMITTER CRYSTAL						X	X
ABX-2	TRANSMITTER CRYSTAL						X	X
TLN6492AA	"VIBRASENDER-SPONDER" UNIT						X	X
NAB6141A	ANTENNA						X	X
NAB6142A	ANTENNA						X	X
NAB6143A	ANTENNA						X	X
NAB6144A	ANTENNA						X	X
NAB6145A	ANTENNA						X	X
NLN6241A	"PRIVATE-LINE" HARDWARE KIT						X	X
NLD6315A	BOTTOM PLATE KIT						X	X
NCN6056A	CONTROL PANEL, 1-FREQ. XMIT, 1-FREQ. RECEIVE CARRIER SQUELCH						X	X
NLN6496	KNOB KIT						X	X

# DESCRIPTION AND OPERATION

## 1. DESCRIPTION

The Motorola "Handie-Talkie" FM radiophone is a completely transistorized and weatherproof portable communications radio set. The radiophones are complete, self-powered, portable FM transmitter and receiver units for two-way communication. The advantages of the transistor -- reliability, lightweight, compact size, reduced maintenance and operating costs -- are fully utilized.

Motorola dual squelch "Private-Line" radios are especially useful when operating under crowded channel conditions. Several networks may share the same carrier frequency in the same area with a minimum of interference when each network uses a different "Private-Line" tone frequency.

Dual squelch "Private-Line" radios and carrier squelch radios are available in two series of models. The lighter weight P21 series for maximum portability and the P31 series where higher r-f power output is required. The P21 series units deliver 1.4 watts of r-f power at nominal battery voltage throughout the 25-54 mc band and weigh as little as 6 lbs. 1 oz. The P31 series units deliver 5 watts of r-f power output and weigh as little as 6 lbs. 8 oz. Both series of radiophones are available in one or two frequency models. Refer to the Model Chart in the front of this manual for a complete listing of the models available.

### a. Power Supplies

Three power supplies are available for use with the radios described in this manual. They are not included as part of the radio set model, but are selected when ordering the "Handie-Talkie" unit. These power supplies can be used with both P21 and P31 Series radios and are as follows:

- (1) NPN1007A Nickel-Cadmium Power Supply.
- (2) NPN1008A Standard Dry Battery Power Supply.
- (3) NPN1009A Standard Dry Battery Power Supply. (Used with NLN6135A Shockmount Rack).

Refer to the BATTERY REPLACEMENT AND CHARGING section of this manual for further information on these power supplies.

In addition to the above battery power units, a Model NPN6032A 117-volt ac power supply is available as an accessory item. (See accessory table.)

Power packs are changed by unsnapping two spring snaps located at the ends of the unit and separating the power pack from the radio section. Another power pack (dry battery, nickel-cadmium, or the 117-volt a-c power supply) can then be attached to the radio section to again form an integral package.

### b. Antennas

The NAB6040A Series Antenna consists of a stainless steel whip 42" long and a removable loading coil. The loading coil consists of a series resonant tunable inductance. The combination of whip and loading coil produces a 1/4 wavelength antenna tunable within a given band of 25-54 mc range. Refer to the Model Chart for the specific frequency ranges of the antennas.

#### **NOTE**

The Motorola "Handie-Talkie" radiophone may be used with a fixed or elevated antenna. The antenna circuit provides a 50-ohm termination at the antenna receptacle; therefore, any 50-ohm antenna resonant to the transmitter frequency can be used. The higher the antenna, the greater the area that can be covered.

### c. Handset

The NMN6017A Handset is supplied complete with a rubber covered coiled cord, which extends to about 5 ft., and a weatherproof connector. A push-to-talk bar on the handset turns the transmitter on. The handset connector plugs into a four-prong receptacle on top of the unit housing.

### d. Microphone

The NMN6018A Microphone is supplied with a rubber covered coiled cord, which can be extended to about 5 ft., and a weatherproof connector. This palm type microphone is provided with

a push-to-talk button which turns on the transmitter. The microphone connector plugs into a four-prong receptacle located on top of the unit housing.

e. Brackets

Brackets at both ends of the "Handie-Talkie" FM radiophone are used for fastening the NLN6311A or NLN6312A Back Pack Harness to the unit for back pack operation. One set of mounting brackets is located near the top of the unit for fastening the shoulder straps of the harness. Another set is located near the bottom of the battery compartment for fastening the waist strap. Refer to the instructions packed with the back harness for installation of the harness on the radiophone.

## 2. PRE-OPERATIONAL NOTES

Use care when unpacking and handling the "Handie-Talkie" FM radiophone. Open the shipping carton and carefully remove all items. Check the contents to be sure that all items have been included.

Inspect the equipment thoroughly as soon as possible after delivery. If any part of the equipment has been damaged in transit, report the extent of damage to the transportation company immediately.

### **IMPORTANT**

This equipment contains batteries. Extended storage of the equipment will reduce the operating performance due to reduction in battery voltage and life. Partially used dry batteries, if left standing for long periods, will leak electrolyte and may result in damage to the radio equipment. If equipment is to be stored for a long period of time, remove the batteries and store them in a cool place.

The Motorola "Handie-Talkie" radiophone is shipped direct from the factory completely assembled, ready for use, except for the installation of the antenna.

## 3. OPERATION

### **CAUTION**

Do not key transmitter unless antenna, dummy load or equivalent is connected to the antenna receptacle.

a. To Turn On

Remove the microphone or handset from the mounting bracket. The ON-OFF switch is located under the microphone or mouthpiece end of the handset. Press down on the side of the switch labeled PUSH ON. This places the receiver in operation.

### **NOTE**

All power supplies except the a-c power supplies, turn on and off with the ON-OFF switch on the radiophone housing. To turn on the a-c power supply always use the ON-OFF switch on the power supply housing.

b. To Adjust Receiver Audio Volume

Turn the squelch control fully counterclockwise. On dual squelch models, turn the "PL" OFF switch to the OFF position. Adjust the volume control until the desired volume is obtained from the speaker.

c. To Adjust Squelch Control

Turn the squelch control fully counterclockwise. On dual squelch models, turn the "PL" OFF switch to the OFF position. With no signal being received, turn the squelch control clockwise until the noise just cuts out (squelches).

d. "Private-Line" Operation (dual squelch models only)

For "Private-Line" operation, place the "PL" OFF switch in the "PL" position. All non-"Private-Line" and incorrectly coded "Private-Line" signals will then be blocked from the speaker. The squelch control is inoperative when the "PL" OFF switch is in the "PL" position and does not require adjustment.

### **NOTE**

Before transmitting, momentarily place the "PL" OFF switch in the OFF position. This enables the operator to check for a clear channel and thus avoid breaking in on the transmission of another on-frequency unit.

e. To Monitor

To monitor all on-frequency transmissions, turn the unit on and adjust the volume and squelch controls to the proper levels. On dual squelch models, the "PL" OFF switch must be OFF. To

monitor only properly coded "Private-Line" transmissions, the "PL" OFF switch must be in the "PL" position.

**NOTE**

All models feature a semi-automatic ON-OFF switch that automatically turns the radio off when the microphone or handset is replaced in its holder. Continuous monitoring of the receiver in microphone equipped models may be accomplished by placing the microphone in its holder face up. In handset equipped models, continuous monitoring is accomplished by leaving the handset out of its holder. Continuous monitoring of the receiver while the handset is in its holder can be accomplished by replacing the standard ON-OFF switch with the NLN6496A Knob Kit. The knob kit is supplied with all handset models.

f. To Transmit

Hold the mouthpiece 1 to 2 inches from lips. Press the push-to-talk button in firmly and hold it. Speak slowly and clearly across the mouthpiece in a normal-to-loud voice. Release the button to listen. The receiver becomes inoperative when the push-to-talk button is pressed, there-

fore, the button must be released at the end of a transmission to receive.

**NOTE**

Additional range may be obtained when the radiophone is placed on the hood or top of a car. This furnishes a good ground plane for the antenna.

g. Frequency Selection  
(Two-Frequency Models Only)

The rotary switch on the top of the unit may be turned to position F1 or F2 to select either of the two operating frequencies.

h. To Turn Off

Replacing the microphone or handset in the mounting bracket automatically turns the receiver off. If the NLN6496A Knob Kit is used with handset models, switch to the OFF position to turn the receiver off before replacing the handset.

i. Storage

Remove the batteries before storing the unit for a long period of time. If the radiophone is equipped with nickel-cadmium batteries, refer to the BATTERY REPLACEMENT AND CHARGING SECTION for care and storage of the batteries.



Control Location Detail

**ACCESSORY TABLE**

MODEL	DESCRIPTION
NPN6032A	117 V AC Power Supply
NLN6268A	Shock Mount Rack
NLN6129A	Carrying Strap
NLN6262A	Carrying Bag
P-7208-A	RF Dummy Load for P21 Series Radiophone
P-7208	RF Dummy Load for P31 Series Radiophone
NLN6145A	Dummy Load Antenna for P21 Series Radiophone
NLN6040A	Dummy Load Antenna for P31 Series Radiophone
NLN6311A	Back Pack Harness complete with microphone, earpiece and volume control
NLN6312A	Back Pack Harness less microphone, earpiece and volume control
NMN6009B	Headset and Microphone
NLN6480A	Nickel-Cadmium Battery Charger (requires NKN6110A or NKN6111A Charging Cable)
NKN6110A	Battery Charging Cable (for NPN6031A Power Supply and NLN6480A Battery Charger)
NKN6111A	Battery Charging Cable (for NPN6267A Battery Kit and NLN6480A Battery Charger)
TEKA-40	Power extension cable for easy repair and/or alignment
NLN6270A	6/12 V DC Vehicular Charging Unit
NKN6074A	6 V DC Vehicular Cable for NLN6270A Charging Unit
NKN6075A	12 V DC Vehicular Cable for NLN6270A Charging Unit
NKN6076A	12 V DC Cigarette Lighter Cable for NLN6270A Charging Unit
NKN6042A	Antenna Extension Cable (20" RG-58 A/U)
NAB6101A	Long Wire Antenna 25-30 mc
NAB6102A	Long Wire Antenna 30-36 mc
NAB6103A	Long Wire Antenna 36-42 mc
NAB6104A	Long Wire Antenna 42-48 mc
NAB6105A	Long Wire Antenna 48-54 mc
NEN6048A	Test Jig for Servicing Radiophone

# ACCESSORIES



Carrying Case  
Model NLN6262A  
Weather Resistant Case



Back Pack Harness  
Model NLN6311A  
Kit is complete with microphone, ear-  
piece and volume control,  
Model NLN6312A  
Same as NLN6311A less microphone  
and earpiece.



Nickel-Cadmium  
Battery Charger  
Model NLN6480A



Headset and Microphone  
Model NMN6009B

# BATTERY REPLACEMENT AND CHARGING

## 1. BATTERY REPLACEMENT PROCEDURE




Figure 1.

To replace all types of batteries, dry or nickel-cadmium type: (Refer to Fig. 1)

- a. Unsnap the spring snap at each end of the radiophone.
- b. Pull bottom section of radio (battery section) down and away from upper section.
- c. Remove the battery compartment cover by unscrewing the 1/4 turn captive screw and lifting the cover up.
- d. To replace dry batteries, first remove the old batteries by turning the battery compartment upside down. Replace the new batteries in the compartment so the flat (negative) end of the batteries are making contact with the springs and the tip (positive) end of the batteries are making contact with the flat contact surfaces.
- e. To replace nickel-cadmium battery, proceed as follows:
  - (1) Remove two screws from corners of battery.
  - (2) Lift battery out of battery compartment.

(3) Remove three-prong plug from battery.

(4) Insert new battery by reversing this procedure.

Fast battery replacement can be accomplished by changing the entire power supply and replacing the batteries in the used supply at some later time. Additional power supplies can be purchased as separate accessories for fast changeover.

## 2. DRY BATTERIES

### a. General

All batteries, dry and wet, have a finite shelf life. Storing them for long periods of time reduces their closed circuit voltage and operating life. In some cases, when stored too long, dry batteries may leak electrolyte after partial use and damage the radio. Therefore, if radio equipment is to be stored for long periods of time, remove the batteries and store separately in a cool place. Never store batteries in a warm place as heat increases their chemical action and shortens life.

Shelf life of a dry battery is approximately 3-6 months. Therefore, they should be put into use within 3 months after purchase.

The batteries can be tested at the battery terminals under transmit load conditions.

The batteries should be replaced when the voltage under transmit load conditions is below 11 volts.

### **IMPORTANT**

**BATTERY VOLTAGES AND CAPACITY DECREASE MARKEDLY DURING LOW TEMPERATURE PERIODS.**

### b. Fuse Replacement

To replace the fuse in the battery compartment, proceed as follows:

- (1) Unsnap the spring snap at each end of the radiophone.
- (2) Pull bottom section of radio (battery section) down and away from upper section.

(3) Remove the battery compartment cover by unscrewing the 1/4 turn captive screw and lifting the cover up.

(4) Remove all batteries.

(5) Remove the screws from the battery separator and lift out.

(6) Unsolder the pigtail fuse from the under side of the battery separator.

(7) Solder a new fuse in place and reassemble.

### 3. NICKEL-CADMIUM BATTERIES

#### a. General

The battery comprises 11 hermetically sealed cells which are series connected to provide a nominal 14 volt output. The cells are cased, and fitted with a cable and connector.

The voltage of a nickel-cadmium battery remains approximately constant under load until the battery approaches the discharged condition. At this time, a marked decrease in this voltage occurs and the discharged condition (1.0 v per cell) is reached abruptly. These batteries should be recharged when the voltage under transmit load reaches 11.0 v.

#### **NOTE**

Battery voltage can not be measured at charging contacts.

#### b. Charging

The Motorola battery chargers and cables listed under ACCESSORIES at the front of this manual are recommended for charging these batteries. The use of other chargers will void the battery guarantee and may result in permanent damage to the batteries. Follow the charging instructions which accompany the charger.

#### c. Storage

The batteries may be stored at room temperature, in any state of charge without damage. These batteries are subject to self discharge however, and should be recharged after extended storage.

### 4. BATTERY LIFE

Under operating conditions of 10% transmit, 10% receive at rated audio output and 80% receive standby, dry batteries will give approximately the following life.

P21  
Series

NPN1007A - Nickel-Cadmium Power Pack (one NLN6267A Battery Kit) -- 16 hours before recharging is necessary.

NPN1008A, NPN1009A - Standard Power Packs (one NLN6310A Battery Kit) -- Fourteen 8-hour working days, each separated by a 16-hour off period.

P31  
Series

NPN1007A - Nickel-Cadmium Power Pack (one NLN6267A Battery Kit) -- 8 hours before recharging is necessary.

NPN1008A, NPN1009A - Standard Power Packs (one NLN6310A Battery Kit) -- Six 8-hour working days, each separated by a 16-hour off period.

Note that most actual transmit duty cycles are much smaller and approach 2% rather than 10%. Also in many types of operation, the unit is not kept turned on continuously. If this type of service is prevalent, battery life may be extended to many times those mentioned previously.

## THEORY OF OPERATION

### 1. GENERAL

The "Handie-Talkie" radiophone consists of a crystal controlled transmitter and receiver operating in the 25-54 mc frequency range. The transmitter contains an audio section and an r-f section. The audio section consists of an amplifier-limiter and an integrator stage. In P21 series models, the r-f section consists of a crystal-

controlled oscillator, a modulator, two frequency doublers, one frequency quadrupler, a driver amplifier, a power amplifier stage and a current limiter stage. In P31 series models, an additional chassis containing a power amplifier is added.

The receiver is a double-conversion, super-heterodyne unit consisting of one r-f amplifier,

two oscillators, two mixers, one first i-f amplifier, five second i-f amplifiers, a 455 kc filter, a limiter, discriminator, squelch amplifier, noise rectifier and two audio amplifiers. Speaker versions use a third stage of audio amplification.

Dual squelch "Private-Line" models include additional stages, some of which are shared by both the transmitter and receiver. The common stages are a "Vibrasender-sponder" circuit, tone amplifier circuits and a "Vibrasender-sponder" driver. High and low pass filters are unique to the receiver and a diode modulator is unique to the P21 series transmitter.

## 2. CIRCUIT THEORY

### a. Transmitter

A reluctance microphone produces a low level audio output which is directly coupled to a preamplifier, Q501, which is contained in the microphone housing. The output from this stage is capacitively coupled to the amplifier-clipper stage, Q110.

The amplifier-clipper and the integrator stages are part of the "Instantaneous Deviation Control" (IDC) circuit. Since the transmitter is phase modulated, the frequency deviation is dependent upon both the amplitude and frequency of the audio signal applied to the modulator. The combination of the integrator and the phase modulator has a "flat" response since the pre-emphasis characteristic of the phase modulator is offset by the de-emphasis of the integrator. Therefore, the frequency deviation of the modulator system is only dependent upon the amplitude of the input to the integrator. The amplitude of the audio signal is limited in the amplifier-clipper stage before reaching the integrator, thereby limiting maximum deviation to a fixed value within the desired frequency range. Audio frequencies above 3000 cps are attenuated in the "splatter" filter before reaching the integrator.

Oscillator stage, Q101 (and Q201 in 2-frequency units) is a fundamental, crystal-controlled, anti-resonant oscillator circuit. It generates a radio frequency which is multiplied 16 times in the succeeding stages to produce the desired carrier frequency. A variable capacitor across the crystal permits a fine tuning adjustment (warping) for the proper operating frequency. The oscillator output is coupled to the modulator stage Q102.

RF is applied to the base and collector while audio is applied to the emitter of the modulator transistor. The internal r-f gain of transistor, Q102, is varied by the applied audio voltage. With a fixed phase shift circuit shunting the transistor and a variable phase shift through the transistor, an overall variable phase shift is obtained at the output. The variable inductance in the output of the modulator stage allows matching of the output reactance of the stage to insure minimum distortion and maximum linear deviation. Generally, phase modulators are capable of modulating with low distortion over a small phase angle. This necessitates the addition of frequency multiplier stages which increase the frequency deviation to the desired value.

Transistor frequency multipliers, or class B amplifiers, in general do not require forward biasing. Without signal drive, zero-biased class B frequency multiplier stages will not draw any emitter current. With drive present, the transistor will draw current and this current is easily monitored by measuring the d-c voltage developed across the emitter resistor. An exception to this is the first doubler stage, Q103, where since the signal input level is very low, a small amount of forward bias is supplied to increase the gain of the stage.


The driver, Q106, provides the proper amount of r-f voltage to drive Q107 and Q108, the power amplifier. In P21 series units, the output power from this stage is coupled directly to the antenna.

In P31 series units, Q107 and Q108 function as an intermediate power amplifier. The output from Q107 and Q108 is coupled to final power amplifier Q401. This higher output is then coupled to the antenna via the transmit-receive relay.


### b. Receiver

The signal from the antenna is coupled to the r-f amplifier, Q1, where it is amplified before being injected into the first mixer. The oscillator Q2, is a crystal-controlled, series-resonant type. The crystal frequency is multiplied three times before being injected into the mixer. There, the incoming r-f signal and the oscillator frequency mix to produce the first intermediate frequency.

The first i-f signal is amplified in the next stage, Q3, and fed to the second mixer. The second mixer combines the first i-f signal and the output of the 2nd oscillator to produce the second i-f signal of 455 kc.



Transmitter Block Diagram



Receiver Block Diagram

The 455 kc signal is selected in the first section of the "Permakay" filter, amplified in the two following stages, Q6 and Q7, and selected again in the second section of the "Permakay" filter. The 455 kc signal is then amplified in the next three stages.

The limiter stage removes any AM noise present on the incoming signal. The discriminator translates the variations of frequency of the i-f signal to an audio frequency signal which is then coupled to the first audio amplifier.

Squelch action is provided by taking the noise produced at the supply voltage decoupling point of the limiter, removing the residual 455 kc signal, amplifying that portion of the noise above the normal voice frequency range, rectifying this noise and applying it as positive bias to the base of the audio output stage. When the receiver is not quieted (in the absence of an r-f carrier), this bias cuts off the audio output stage and eliminates the speaker noise. The degree of squelch action is regulated by a potentiometer.

The audio section consists of two low power amplifier stages in series where the recovered audio is amplified to 3 milliwatts. These two stages are directly coupled so that when the first stage is back biased by the squelch rectifier circuit, the second stage is also turned off. The output of the second stage is coupled to the handset earpiece and provides 3 milliwatts of audio power.

In versions using a speaker, the audio output of the second stage is coupled to a power stage which amplifies the audio signal to 500 milliwatts.

c. Dual Squelch "Private-Line" Transmitters And Receivers

The controlling element in the "Private-Line" circuit is the "Vibrasender-sponder" unit. The

unit acts similar to a control crystal in an oscillator stage. When the transmitter is keyed a resonant reed inside the unit vibrates at a predetermined frequency. The resulting tone is then amplified in tone amplifiers which raise the signal to the proper level to drive the diode modulator, CR104. The diode modulator varies the first oscillator frequency at the tone frequency rate. Modulation is accomplished by varying the effective resistance of the modulator diode. This in turn, varies the effective reactance of a capacitor in parallel with the crystal which modulates the oscillator frequency.

In the receive mode of operation with the "Private-Line" switch in the OFF position, the squelch circuit detects noise on the receiver channel. This noise is amplified in the squelch amplifier and rectified. The resulting current overcomes the forward bias to turn off the 1st audio transistor. Moving the "Private-Line" switch to the ON position changes the bias on the 1st audio transistor to a condition where it is biased off. The normal squelch circuitry now has no effect for it can only bias the transistor off further.

When a properly coded "Private-Line" carrier comes on the air, the tone signal is sent to the "Private-Line" circuitry where it is amplified by the three transistor stages which drive the "Vibrasender-sponder" unit. The contacts in this reed will then close and a negative d-c voltage is sent to the 1st audio transistor where it is used to bias this transistor to a conducting condition, unquenching the audio amplifiers.

This receiver makes use of two separate and distinct squelch circuits, i. e., tone-coded squelch and noise squelch. On dual squelch receivers, when the incoming signal is properly tone-coded, the squelch sensitivity is never greater than the tone-coded squelch sensitivity.

# MAINTENANCE

## 1. TEST EQUIPMENT

All the required test equipment for aligning and testing the "Handie-Talkie" FM

radiophone is listed in the following TEST EQUIPMENT CHART. The listed items or their equivalents may be used.

TEST EQUIPMENT CHART

EQUIPMENT	USED FOR
Motorola DC Multimeter with r-f probe.	All d-c and r-f measurements. Monitoring the input current when external power supply is used.
Motorola AC Voltmeter FM signal generator - Motorola T1034C Signal Generator.	All a-c signal measurements. Alignment of all r-f and first i-f stages, 20 db quieting sensitivity measurements.
455 kc crystal-controlled oscillator - Motorola S1056A-9A or TU546 Series Test Set with 455 kc crystal.	Alignment of 455 kc i-f limiter and discriminator stages.
Audio generator - Motorola TEK-1A Transistorized Tone Generator, 1000 cps.	IDC Adjustment
Oscilloscope - Motorola T1015A General Purpose Oscilloscope or Motorola T1014B Precision Wide Band Oscilloscope.	IDC Adjustment
Motorola Model P-7208 or P-7208-A RF Dummy Load and a field strength meter.	All r-f output power measurements.
Motorola NLN6252A Alignment Tool (supplied with the radiophone)	Adjusting the variable capacitors and tuning coil slugs.
DC power supply capable of supplying -14 v d-c at 1.5 amperes (optional) Motorola TEK-23 Power Supply.	Supplying d-c power to the unit during extended servicing.
Motorola Model TEKA-40 Power Extension Cable.	Connecting batteries to radio for servicing.
Motorola NEN6048A Test Jig	Holding the radiophone for alignment or testing.

## 2. TEST PROCEDURE

When a radiophone requires servicing, use the following procedures to localize the fault.

### a. Check Batteries

The first step in localizing the trouble is to check the battery voltage under load. With the transmitter turned on (keyed), check the battery voltage. A convenient way to do this is to separate the battery compartment and radio compartment. Using the TEKA-40 Power Extension Cable (or equivalent), connect the batteries to the radio.

### CAUTION

Do not key transmitter unless antenna, dummy load, or equivalent is connected to the antenna receptacle.

Place the voltmeter ground lead on a convenient ground and measure the voltage at the transmitter A- input while the transmitter is keyed. The measured loaded voltage should be not less than 11 volts for either the dry or nickel-cadmium batteries. Even though the transmitter may operate at this lower voltage, its operation would be marginal and for only a short additional period of time. The recommended procedure is to replace, or recharge, the batteries if the voltage

# RECOMMENDED TEST EQUIPMENT



S1059A Test Set



P-7208 for P31 Series Units  
P-7208-A for P21 Series Units  
RF Dummy Load



DC Multimeter



Transistorized AC Voltmeter



TEK-1A  
Transistorized Tone  
Generator



T1034C  
Signal Generator



T1015A  
General Purpose  
Oscilloscope



T1014C  
Precision Wide Band  
Oscilloscope



NLN6252A  
Tuning Tool



NLN6145A for P21 Series Units  
NLD6060A for P31 Series Units  
Dummy Load Antenna

is below 11 volts under load. Refer to the BATTERY REPLACEMENT AND CHARGING section of this manual for additional information.

**NOTE**

Only the nickel-cadmium batteries are rechargeable.

b. Check Overall Transmitter Operation

If the battery voltage is sufficient, check the overall performance of the transmitter. A good overall check of the transmitter is the r-f power output measurement. This one check indicates the proper operation of all the transmitter stages (oscillator, frequency multipliers, drivers and final amplifier) with the exception of the modulator and audio circuitry. A P31 series transmitter, when properly tuned and operating at 13.5 v d-c, will produce 5.0 w r-f output into a 50-ohm load. A P21 series transmitter, when properly tuned and operating at 14.0 v d-c, will produce 1.4 w r-f output into a 50-ohm load. It may be necessary to retune the output circuits slightly to match the 50-ohm load. This measurement should be made using a 50-ohm wattmeter connected to one end of the 50-ohm test cable with the other end connected to the antenna receptacle.

For further details, refer to the Transmitter Alignment Procedure. If the power output is less than indicated in the chart, further checking is required. Refer to paragraph 5. TRANSMITTER SERVICE NOTES.

c. Check Overall Receiver Operation

(1) 20 DB Quieting Sensitivity Check

A good overall check of the receiver operation is the 20 db quieting sensitivity measurement. This check will indicate that the receiver has sufficient gain and that all the included circuitry is working properly. The quieting signal is that r-f signal input necessary to reduce the audio output at the speaker by 20 decibels. The measurement should be made in the absence of extraneous signals. Since the receiver squelch circuitry reduces the noise at the speaker, the squelch control should be set for maximum noise while making this measurement.

The actual measurement is made by observing the noise voltage at the microphone connector on an a-c voltmeter with no r-f signal received at the antenna.

**NOTE**

On handset models not incorporating a speaker, a 120-ohm resistor must be connected across the a-c voltmeter terminals.

Sufficient carrier signal from a recommended signal generator is then introduced via the antenna receptacle to reduce the noise output voltage to 1/10 of the previous reading. If all circuitry is operating properly, the quieting signal should be 0.35 microvolts or less. Refer to the Alignment Procedure.

(2) Squelch Check

With no r-f input signal, set the squelch control until the speaker noise just cuts out (threshold squelch). Sufficient carrier signal from a recommended signal generator is then introduced until speaker noise is just heard. The signal level at which the squelch begins to open should be less than one-half the 20 db quieting sensitivity voltage measured in subparagraph (1).

(3) Audio Check


The last check to be made is the audio check. This procedure will test the audio circuits exclusive of the squelch circuitry. Refer to the AUDIO AMPLIFIER MEASUREMENTS CHART, which appears later in this manual, for typical measurements and procedures.

**3. DISASSEMBLY PROCEDURE**

(Refer to Figures 2-4)

To gain access to the transmitter and receiver printed circuit boards, proceed as follows:

- a. Remove the battery compartment as described in the BATTERY REPLACEMENT AND CHARGING SECTION.
- b. Turn the radiophone upside down and loosen the two captive cover screws.
- c. Lift the radio compartment cover up.
- d. The transmitter and receiver printed circuit boards are now accessible. They may be lifted up and out for access to the component side.
- e. Access to the power amplifier (P31 series only) is accomplished by loosening two additional captive mounting screws.



TO GAIN ACCESS TO  
COMPONENT SIDE OF  
CHASSIS, REMOVE SCREWS

Figure 2.




Figure 3.




Figure 4.

**NOTE**

To aid circuit tracing, the components side of the circuit board is screened in the pattern of the etched circuitry. This paint does not conduct and has no electrical function.

**4. RECEIVER STAGE ANALYSIS**

The information contained in the following paragraphs will aid the serviceman in localizing the trouble to a particular stage.

a. Test Points

The test points on the printed circuitry are color coded for easy location. The locations of these test points may be seen on the alignment chart, the schematic diagram, and the wiring diagrams at the back of this manual.

b. Stage Measurements Charts

In addition to the 20 db quieting sensitivity measurement, all stage gain measurements can be checked against those shown in the following AUDIO AMPLIFIER MEASUREMENTS CHART and RF AND IF STAGE MEASUREMENTS CHART.

**AUDIO AMPLIFIER MEASUREMENTS CHART**NOTES

1. Remove the GRN-RED lead from test point M4.
2. Connect an audio oscillator capable of generating 1000 cps, to this GRN-RED lead with a 47K ohm resistor in series.
3. Set the frequency and voltage according to the chart below. The input voltage is measured at the junction of the 47K ohm resistor and GRN-RED lead.
4. The output readings are referenced to ground unless otherwise indicated and are taken with a Motorola transistorized a-c voltmeter, or equivalent.
5. All measurements made with -14.0 volts d-c input.

FREQUENCY	VOLTS INPUT	INPUT TO	OUTPUT AT	READING	REMARKS
1000 cps	.02 (-32 dbm)	GRN-RED lead (top of volume control)	Base of Q13	-41 dbm (0.007 v)	Volume control set at maximum
			Collector of Q13	-9 dbm (0.28 v)	
			Base of Q14	-21 dbm (0.07 v)	
			Collector of Q14	+17 dbm (5.6 v)	Volume control set at maximum. Spkr-mic & Spkr- handset models only
			Bases of Q15 and Q16	+17 dbm (5.6 v)	
			Emitters of Q15 and Q16	+16 dbm (5.0 v)	Spkr-mic & Spkr- handset models only
			Collector of Q14	+10 dbm (2.4 v)	Handset models only. Volume control set at max- imum. A 120 ohm resistor connec- ted from pin 4 to pin 1 of the mic receptacle.
			Secondary of transformer (T3)	-2 dbm (0.6 v)	

## RF AND IF STAGE MEASUREMENTS CHART

### NOTES

1. Output readings taken with a Motorola Transistorized AC Voltmeter, or equivalent.
2. The carrier frequency is injected at the antenna receptacle using an adapter cable coupled to a Motorola Model T1034C Signal Generator, or equivalent.
3. The 1st i-f signal is injected at the points indicated in the chart using a 50 ohm coaxial cable and a series connected .02 uf capacitor.
4. All readings taken with -14.0 volts d-c input.

FREQUENCY	UV INPUT	PROCEDURE	OUTPUT AT	READING (NOTE 1)
-	Noise	-	output of 2nd section of 455 kc filter	-55 dbm (0.0014 v)
-	Noise	-	Base of Q10 (M2)	-5 dbm (0.44 v)
-	Noise	-	Base of Q11 (M3)	-10 dbm (0.245 v)
-	Noise	- (Short collector of Q1 to collector coil ground with .002 uf capacitor)	Base of Q8 (M1)	-59 dbm (0.0009 v)
-	Noise	- (Short collector of Q3 to ground with .02 uf capacitor)	output of 2nd section of 455 kc filter	-70 dbm (0.00025 v)
Carrier	3	Connect input to external antenna connector	output of 2nd section of 455 kc filter	-30 dbm (0.025 v)
Carrier	3	Connect input to external antenna connector	Input to second section of 455 kc filter	-25 dbm (0.045 v)
Carrier	20	Connect input to external antenna connector	Output of 1st section of 455 kc filter	-50 dbm (0.0025 v)
5.7 mc	3	Connect input to top of T3 (primary)	output of 2nd section of 455 kc filter	-40 dbm (0.0077 v)
5.7 mc	10,000	Connect input to top of T5 (primary)	output of 2nd section of 455 kc filter	-30 dbm (0.025 v)

## 5. TRANSMITTER SERVICE NOTES

The following information will aid the serviceman in troubleshooting the radiophone transmitter.

### CAUTION

Do not key transmitter unless antenna, dummy load or equivalent is connected to the antenna receptacle.

#### a. Metering Points

The test points on the printed circuit board are supplied for ease in checking. These points are indicated on the schematic diagram, wiring diagrams, and the photograph on the Alignment Procedure. The chart on the Alignment Procedure provides nominal voltage readings corresponding to these test points for a fully tuned transmitter with -14 volts d-c input.

#### b. DC Voltage Measurements

If the r-f power output is lower than normal for a fully tuned transmitter, the d-c voltages on the printed circuit board should be checked. These voltages should all be referenced to ground.

### CAUTION

When checking a transistor, either in or out of the circuit, do not use an ohmmeter having more than 1.5 volts d-c appearing across the test leads.

The transistor is a dependable component and is not subjected to replacement as frequently as tubes. Therefore, the serviceman is cautioned not to replace transistors before a thorough check is made. The transistor terminal voltages should be checked first. If these voltages are not reasonably close to those specified, the associated components should be checked. A low impedance meter should not be used for measurement. If all d-c voltages are correct, the signal should be traced through the circuit to show any possibility of breaks in the signal path.

#### c. RF Signal Tracing

An r-f probe attachment for a d-c multimeter may be used to good advantage in checking the radiophone transmitter. The presence of r-f can be checked throughout the r-f circuitry for continuity of signal path. This would include the oscillator, modulator, frequency multipliers, and the driver and final amplifier. Following the heavy signal flow line through the r-f stages, as

indicated on the schematic diagram, is recommended.

#### d. Frequency Multipliers

Transistor frequency multipliers, or class B amplifiers in general, do not require forward biasing. Without signal drive, a zero-biased, class B frequency multiplier stage will not draw any emitter current. With drive present, the transistor will draw current and this current is monitored best by measuring the d-c voltage developed across the emitter resistor. In the transmitter, these checks are made using test points M1 and M2. The 1st doubler stage Q103 operates at a very low signal level. Therefore, a small amount of forward bias is supplied to increase the gain of this stage.

#### e. Driver and Final Amplifiers

When tuning up the driver, the intermediate power amplifiers and the final amplifiers, it may be necessary to retune previously tuned circuits. This includes coils L107, L108, L109 and capacitor C141, (all models) C403, C406 and C408 (P31 series only). All these components interact to some extent. By using care in tuning these stages, rated power output will be obtained with minimum current drain.

#### f. Audio Circuits

If the transmitter does not modulate properly, the audio circuits should be checked to make sure that the audio modulating voltage is reaching the modulator. The audio circuit is a transistorized version of the Motorola audio and IDC circuit. External audio test signals can be coupled into the amplifier-clipper stage, Q110, through a 0.1 microfarad capacitor. In this manner, the audio circuitry can be signal traced.

The IDC control is a printed circuit potentiometer. Care should be taken when setting this control for the proper deviation.

### CAUTION

Do not use a sharp metallic tool to adjust the IDC control. This may result in damage to the carbon track which could alter the resistance of the control.

## 6. REPAIR

The information contained in the following paragraphs will aid the serviceman in repairing the "Handie-Talkie" FM radiophone.



**TEST EQUIPMENT REQUIRED FOR TRANSMITTER ALIGNMENT**

1. Motorola NLN6252A Alignment Tool (supplied) or equivalent.
2. Motorola DC Multimeter with r-f probe or equivalent.
3. RF Wattmeter (50-ohm impedance).
4. Motorola TEK-23 Power Supply or equivalent.
5. Motorola Model T1100A Series FM Station Monitor or equivalent.
6. Motorola TEK-1A Transistorized Tone Oscillator or equivalent.
7. Motorola T1014B Precision Wide Band Oscilloscope or Model T1015A General Purpose Oscilloscope or equivalent.

**NOMINAL VOLTAGE READINGS**

**NOTE**

The following readings apply to a fully tuned transmitter with -13.5 v d-c input.


METER POINT	M1 BRN	M2 RED
READING (V DC)	-1.7	-2.5

**PRELIMINARY SET-UP FOR TRANSMITTER ALIGNMENT**

1. Remove the cover from the radio section of the unit.
2. When aligning a two-frequency unit, align on the primary or higher of the two frequencies.
3. The d-c multimeter ground lead should be connected to a convenient ground.
4. For complete alignment, the battery should be removed and a 15 volt d-c power supply and ammeter connected to the battery plug. All tuning slugs except L101 should be unscrewed so they protrude 1/8 inch above the printed circuit board.
5. Remove the antenna by unscrewing it from the receptacle. Connect a wattmeter to the external antenna receptacle.
6. Tuning capacitors on power amplifier should be set as shown in the photograph.
7. The drive adjustment, R137, should be set for minimum resistance (fully clockwise).

**FREQUENCY CALCULATIONS**

$$f_o = \frac{f_c}{16} \text{ where: } f_o = \text{oscillator frequency and } f_c = \text{carrier frequency}$$




CAPACITOR DETAIL


AEPD-8291-0

**NOTE**

To adjust C141, C101 or C201 for maximum capacity, turn screwdriver slot so color dot is nearest the grounded side of the capacitor housing.



METERING AND ALIGNMENT POINTS



AEPD-8876-0

POWER AMPLIFIER

**ALIGNMENT PROCEDURE**

STEP	TEST EQUIPMENT	METER POINT & COLOR	ADJUSTMENT	PROCEDURE
1	-----	-----	-----	Key the transmitter and adjust the power supply voltage to -12 volts d-c.
2	DC multimeter	M1 (BRN)	L102 1st Doubler	Adjust L102 for a maximum reading. This circuit is tuned to twice the crystal frequency.
3	DC multimeter	M2 (RED)	L103 L104 Quadrupler	<p>QUADRUPLER: <b>NOTE</b> - When aligning the Quadrupler coil L103 in the 30-42 mc and the 42-54 mc band, it is possible to tune the coil to the incorrect harmonic at the upper and lower ends of the frequency range.</p> <p>Place the multimeter probe on meter point M2.</p> <p>At 30 mc in the 30-42 mc (M) band, or 42 mc in the 42-54 mc (H) band tune to 4th peak                      At 33 mc in the 30-42 mc (M) band, or 45 mc in the 42-54 mc (H) band tune to 3rd peak                      At 36 mc in the 30-42 mc (M) band, or 48 mc in the 42-54 mc (H) band tune to 2nd peak                      At 42 mc in the 30-42 mc (M) band, or 54 mc in the 42-54 mc (H) band tune to 1st peak</p> <p>At a frequency between those given above, tune to the peak(s) for the next higher frequency, for example: at 50 mc tune to 1st real peak. (If no peaks are obtained, turn the slug of L104 into the coil about 1/8".)</p> <p>Adjust L104 for a maximum reading.</p>
4	DC multimeter	M2 (RED)	L105 2nd Doubler	Adjust L105 for a minimum reading. This circuit is tuned to 16 times the crystal frequency.
5	RF probe	M4	C141, L105, L106	Adjust C141 for maximum output. (If no reading can be obtained, tune L106 for a maximum reading and readjust C141.) Peak L105 and L106 for a maximum reading.
6	RF probe	M4	L107, L108, L109	Adjust L107, L108, L109 for a maximum reading. (If L108 and L109 cannot be adjusted for such a reading turn the slugs of each coil into the form about 1/8", and readjust them.)
7	RF wattmeter	-----	C406, C408, C403	Adjust C406, C408 and C403, in that order for maximum power output.
8	RF wattmeter	-----	L106, L107, L108, C141, C403, C406, C408	Replace the cover plate and repeak L106, L107, L108, C141, C403, C406 and C408 for maximum power output

**ALIGNMENT PROCEDURE (CONT'D)**

STEP	TEST EQUIPMENT	METER POINT & COLOR	ADJUSTMENT	PROCEDURE
9	RF wattmeter	-----	L108, L109, C403, C406, C408	Increase the power supply voltage to -13.5 volts d-c and adjust L108, L109, C403, C406, and C408 for 5.0 watts output while minimizing current. <b>NOTE:</b> For optimum performance, adjust C408 for proper current while peaking C406 for power output. Once proper power and current levels are reached, do not repeak C408. <b>DO NOT EXCEED 900 MA TOTAL CURRENT DRAIN INCLUDING RELAY CURRENT.</b>
10	RF wattmeter	-----	L108, L109, C403, C406, C408, R137	If current drain exceeds 900 ma total, decrease current by rotating drive adjusting resistor, R137, and repeating STEP 9.
11	-----	-----	-----	<p>OSCILLATOR: C101 is preset to the assigned frequency at the factory. Do not readjust unless the crystal is replaced or the setting was accidentally changed.</p> <p>If it is necessary to readjust C101, set up the frequency monitor for frequency measurement and replace the cover plate on the unit and tighten securely. Adjust C101 for zero reading on the monitor CARRIER FREQUENCY meter. <b>IMPORTANT</b> - When the cover plate is attached, the frequency may shift; therefore, always set the carrier frequency on the frequency monitor with the cover plate attached.</p> <p>TWO-FREQUENCY TRANSMITTERS ONLY                      OSCILLATOR NO. 2: Use the same procedure as above, substituting C201 for C101.</p>
12	-----	-----	L101	DEVIATION CHECK: See "IDC" ADJUSTMENT PROCEDURE on the reverse side of this chart.
13	-----	-----	-----	ANTENNA PEAKING: Completely assemble unit. Perform the antenna peaking procedure while connected to an external power supply set for 14.0 v d-c. Each power supply lead must be isolated by an r-f choke (Motorola Part No. 24C83961B01) at the radio. Connect the loading coil and antenna to the antenna receptacle and turn the core in the antenna loading coil clockwise until it is stopped. Slowly adjust the core in the loading coil counterclockwise until a peak is reached on the field strength meter.

## "IDC" ADJUSTMENT (PREFERRED METHOD USING OSCILLOSCOPE)

### 1. INTRODUCTION

Accuracy of test equipment is of prime importance to any user of radio communications equipment; but of equal importance is a knowledge of the characteristics of the measuring equipment under various conditions. The Motorola Model T1100A Series FM Station Monitor is the leader in the field with respect to sensitivity, accuracy under conditions of variation in r-f signal level line voltage, and other environmental conditions. In common with most other meters, however, they have the characteristic of responding differently to different wave shapes. Therefore, the use of most present-day deviation meters can lead to confusion and errors in deviation setting, if the pitfalls are unknown or disregarded.

The "ideal" deviation indicator would be one which would respond instantaneously to the peak value of the modulation deviation, regardless of waveform. The only device which meets all these requirements is an oscilloscope. It responds instantaneously, and it shows the peak value of any waveform, no matter how complex. Properly calibrated, an oscilloscope is the most accurate and reliable means for measuring and setting transmitter deviation.

The oscilloscope must be used in conjunction with a receiver which has a stable discriminator characteristic, since the oscilloscope displays the demodulated signal. In addition to the oscilloscope a receiver and a means to accurately calibrate the system is required. The Motorola monitors fill these requirements, since they provide both a sensitive receiver with the proper discriminator characteristic and a reliable means of calibrating the oscilloscope. They have convenient terminals on the front panel for connection of the oscilloscope. Furthermore, the Motorola FM Station Monitor is provided with two modulation meter scales, 0-20 kc for wide-band systems, and 0-10 kc for split-channel systems.

Split-channel conversion kits are available for modification of older models, so that they too are provided with convenient oscilloscope terminals and can be more accurate measurement devices for such systems.

### 2. TEST EQUIPMENT REQUIRED

- Motorola T1100A Series FM Station Monitor (or equivalent)
- Motorola Transistorized AC Voltmeter (or equivalent)
- Motorola Model TEK-1A Transistorized Tone Generator, 400 & 1000 cps (or equivalent)
- Motorola Model T1015A General Purpose Oscilloscope, Motorola Model T1014B Precision Wide Band Oscilloscope (or equivalent)
- Motorola Model S1056A-9A or TU546 Series Portable Test Set (or equivalent) for "Private-Line" models only

### 3. OSCILLOSCOPE CALIBRATION

The first step in the measurement of transmitter deviation is to calibrate the oscilloscope. This can be done by using the transmitter which is to be measured. A "Private-Line" unit can be used for this purpose if the tone oscillator is disabled by removal of the "Vibrasender-sponder" unit. This is necessary since the "Private-Line" tone contributes to the maximum deviation.

Proceed as follows:

- The oscilloscope should be connected to the monitor oscilloscope terminals, and the monitor controls should be set up in accordance with the monitor instruction manuals.
- Turn the IDC control on the transmitter chassis to the full clockwise position.
- Feed a 1000 cps test tone into pin 2 of the microphone input jack (base of the amplifier-clipper stage Q110 in the IDC circuit). A 0.33 uf capacitor should be placed in series with the tone generator output. Modulate the transmitter with this tone so adjusted that the deviation as read on the FM monitor deviation meter is 2 kc (6 kc in a wide-band system). An audio oscillator must be used for generation of this tone, since a sinusoidal waveform is very important. The Motorola TEK-1A Transistorized Tone Generator is excellent for this purpose.
- Adjust the vertical gain of the oscilloscope so that the total recovered audio pattern occupies some convenient height, e.g., four small squares. (12 squares in a wide-band system.) The split-channel indication is shown in figure 1.




Figure 1.  
Oscilloscope Calibration for  
Split-Channel Transmitter

Having calibrated the oscilloscope, there is no further need for the modulation deviation meter and its reading should be ignored from this point on. It has already performed its important function of calibrating the oscilloscope.

With the oscilloscope calibrated as indicated, a recovered signal which occupies 10 squares (peak-to-peak) is equivalent to  $\pm 5$  kc deviation. For wide-band systems, a recovered signal occupying 30 squares (peak-to-peak) is equivalent to  $\pm 15$  kc deviation.

### 4. MEASUREMENT AND SETTING OF TRANSMITTER DEVIATION

#### a. Models for Carrier Squelch Application

Once the oscilloscope has been calibrated the transmitter deviation can be properly adjusted by the following method:

- Adjust the 1000 cps input signal to 1.5 volt. This should drive the IDC circuit into full clip. See Figure 2.




Figure 2.  
5 KC Peak Deviation as seen on the Oscilloscope  
(NOTE: Waveform is clipped fully)

- With this input signal level adjust the IDC control on the transmitter to provide a peak-to-peak recovered signal on the oscilloscope of 10 squares, which is equivalent to  $\pm 5$  kc deviation as shown in figure 2. A wide-band system should be adjusted for 30 squares ( $\pm 15$  kc). If the waveform under the above conditions does not resemble the waveform shown in figure 2 adjust L101 until a symmetrical waveform is obtained. Re-adjust the IDC control.

- Reduce 1000 cps input to 0.3 volt. Essentially full deviation should still be observed on the oscilloscope. Less than full deviation may indicate a weak audio transistor or other lack of audio gain.

#### b. "Private-Line" Models

- Remove "Vibrasender-sponder" resonant reed from its socket.

- Adjust the 1000 cps input signal to 1.5 volts. This should drive the IDC circuit into full clip. See Figure 2.

- With this input signal level adjust the IDC control on the transmitter to provide a peak-to-peak recovered signal on the oscilloscope of 10 squares, which is equivalent to  $\pm 5$  kc deviation as shown in figure 2. If the waveform under the above conditions does not resemble the waveform shown in figure 2, adjust L101 until a symmetrical waveform is obtained. Re-adjust the IDC control.

- Reduce 1000 cps input to 0.3 volt. Essentially full deviation should still be observed on the oscilloscope. Less than full deviation may indicate a weak audio transistor or other lack of audio gain.

- Remove the 1000 cps tone signal. Insert the "Vibrasender-sponder" unit in its socket.

- Check the "Private-Line" tone deviation. This may be read directly from the oscilloscope by pressing the transmitter on switch on the test set. The tone deviation should be 0.5 to 1 kc.

#### NOTE

If the tone deviation is less than 0.5 kc with jumper JU1 on position 2 (see circuit board diagram), move the jumper to position 3. If the deviation is greater than 1.0 kc, move the jumper to position 1M for the 30-42 mc band or 1H for the 42-54 mc band. Always choose the jumper position which produces a tone deviation between 0.5 and 1.0 kc.

Due to a slight increase in discriminator response at the lower frequencies, the oscilloscope will read high, thus, an indication of 1.4 to 2.8 squares (peak-to-peak) is equivalent to 0.5 to 1 kc. This slight variation is only important when checking tone deviation. When setting maximum transmitter deviation as described in the following paragraphs, it may be ignored.

(7) Apply a 1000 cps test tone to pin 2 of the microphone input jack (base of the amplifier-clipper stage Q110). Place a 0.33 uf capacitor in series with the tone generator output.

(8) Adjust the 1000 cps input signal level for 1 volt and note the resultant combined deviation of the 1000 cps modulation and tone signal modulation on the oscilloscope.

(9) The IDC control on the transmitter should be adjusted to provide a peak-to-peak combined signal of 10 squares, equivalent to full 5 kc as shown in figure 3.




Figure 3.

5 KC Peak Deviation for Combined PL Tone and  
1000 CPS Modulation

(10) Reduce the 1000 cps input to 0.35 volt. Essentially full combined 1000 cps tone and "Private-Line" tone deviation should still be observed on the oscilloscope. Less than full combined deviation may indicate a defective transistor or other lack of audio gain.

#### 5. EMERGENCY MEASUREMENT OF DEVIATION

If an audio oscillator is not available, a loud sustained whistle of approximately 1000 cycles can be used for a rough measurement of deviation. If this rough check indicates the need for resetting deviation, do so only under controlled conditions, using a 1000 cps tone as previously indicated. The calibration of the oscilloscope should always be performed with a steady controlled signal. Do not attempt to calibrate the oscilloscope with a sustained whistle as waveform distortion will prevent an accurate calibration.

#### 6. OTHER MEANS FOR MEASUREMENT OF DEVIATION

Another accurate means of measuring transmitter deviation is to use the Motorola T1020A Portable Frequency and Deviation Meter. This unit, properly used, permits the accurate measurement and setting of transmitter deviation from a peak-reading meter which is unaffected by waveform. An oscilloscope is not required with this instrument. With this device, the transmitter deviation can be measured accurately even with voice modulation.

#### 7. MICROPHONE LEVELS

If the modulation level in the system still appears to be too low after setting deviation as indicated above, check the microphone and audio amplifier.

The foregoing procedure will insure that the transmitter will comply with FCC requirements for maximum deviation.

The importance of the correct deviation setting can not be overemphasized. Optimum system performance demands accurate deviation setting, both from the standpoint that over deviation will interfere with the user on the adjacent channel, and underdeviation may reduce system range.

**TEST EQUIPMENT REQUIRED FOR TRANSMITTER ALIGNMENT**

1. Motorola NLN6252A Alignment Tool (supplied) or equivalent.
2. Motorola DC Multimeter with r-f probe or equivalent.
3. RF Wattmeter (50-ohm impedance).
4. Motorola TEK-23 Power Supply or equivalent.
5. Motorola Model T1100A Series FM Station Monitor or equivalent.
6. Motorola TEK-1A Transistorized Tone Oscillator or equivalent.
7. Motorola T1014B Precision Wide Band Oscilloscope or Model T1015A General Purpose Oscilloscope or equivalent.

**NOMINAL VOLTAGE READINGS**

**NOTE**

The following readings apply to a fully tuned transmitter with -14 v d-c input.


METER POINT	M1 BRN	M2 RED
READING (V DC)	-1.7	-2.5

**PRELIMINARY SET-UP FOR TRANSMITTER ALIGNMENT**

1. Remove the cover from the radio section of the unit.
2. When aligning a two-frequency unit, align on the primary or higher of the two frequencies.
3. The d-c multimeter ground lead should be connected to a convenient ground.
4. For complete alignment, the battery should be removed and a 15 volt d-c power supply and ammeter connected to the battery plug. All tuning slugs except L101 should be unscrewed so they protrude 1/8 inch above the printed circuit board.
5. Remove the antenna by unscrewing it from the receptacle. Connect a wattmeter to the external antenna receptacle.


**FREQUENCY CALCULATIONS**

$f_o = \frac{f_c}{16}$  where:  $f_o$  = oscillator frequency and  $f_c$  = carrier frequency



**NOTE**

To adjust C141, C101 or C201 for maximum capacity, turn screwdriver slot so color dot is nearest the grounded side of the capacitor housing.



METERING AND ALIGNMENT POINTS

**ALIGNMENT PROCEDURE**

STEP	TEST EQUIPMENT	METER POINT & COLOR	ADJUSTMENT	PROCEDURE
1	----	----	----	Key the transmitter and adjust the power supply voltage to -12 volts d-c.
2	DC multimeter	M1 (BRN)	L102 1st Doubler	Adjust L102 for a maximum reading. This circuit is tuned to twice the crystal frequency.
3	DC multimeter	M2 (RED)	L103 L104 Quadrupler	<p><b>QUADRUPLER: NOTE</b> - When aligning the Quadrupler coil L103 in the 30-42 mc and the 42-54 mc band, it is possible to tune the coil to the incorrect harmonic at the upper and lower ends of the frequency range.</p> <p>Place the multimeter probe on meter point M2.</p> <p>At 30 mc in the 30-42 mc (M) band, or 42 mc in the 42-54 mc (H) band tune to 4th peak                      At 33 mc in the 30-42 mc (M) band, or 45 mc in the 42-54 mc (H) band tune to 3rd peak                      At 36 mc in the 30-42 mc (M) band, or 48 mc in the 42-54 mc (H) band tune to 2nd peak                      At 42 mc in the 30-42 mc (M) band, or 54 mc in the 42-54 mc (H) band tune to 1st peak</p> <p>At a frequency between those given above, tune to the peak(s) for the next higher frequency, for example; at 50 mc tune to 1st real peak. (If no peaks are obtained, turn the slug of L104 into the coil about 1/8".)</p> <p>Adjust L104 for a maximum reading.</p>
4	DC multimeter	M2 (RED)	L105 2nd Doubler	Adjust L105 for a minimum reading. This circuit is tuned to 16 times the crystal frequency.
5	RF wattmeter	----	C141, L105, L106	Adjust C141 for maximum output. (If no reading can be obtained, tune L106 for a maximum reading and readjust C141.) Peak L105 and L106 for a maximum reading.
6	RF wattmeter	----	L107, L108, L109	Adjust L107, L108, L109 for a maximum reading. (If L108 and L109 cannot be adjusted for such a reading turn the slugs of each coil into the form about 1/8", and readjust them.)
7	----	----	L108, L109	Increase the power supply voltage to -14 v d-c and adjust L108 and L109 for a maximum reading.
8	----	----	----	Replace the cover plate and repeat Step 6.
9	----	----	----	<p><b>ANTENNA PEAKING:</b> Completely assemble unit. Perform the antenna peaking procedure while connected to an external power supply set for 14.0 v d-c. Each power supply lead must be isolated by an r-f choke (Motorola Part No. 24C83961B01) at the radio. Connect the loading coil and antenna to the antenna receptacle and turn the core in the antenna loading coil clockwise until it is stopped. Slowly adjust the core in the loading coil counterclockwise until a peak is reached on the field strength meter.</p>
10	----	----	----	<p><b>OSCILLATOR:</b> C101 is preset to the assigned frequency at the factory. Do not readjust unless the crystal is replaced or the setting was accidentally changed.</p> <p>If it is necessary to readjust C101, set up the frequency monitor for frequency measurement and replace the cover plate on the unit and tighten securely. Adjust C101 for zero reading on the monitor <b>CARRIER FREQUENCY</b> meter. Replace the back cover on the transmitter unit and tighten securely. <b>IMPORTANT</b> - When the cover plate is attached, the frequency may shift; therefore, always set the carrier frequency on the frequency monitor with the cover plate attached.</p> <p style="text-align: center;">TWO-FREQUENCY TRANSMITTERS ONLY</p> <p><b>OSCILLATOR No. 2:</b> Use the same procedure as above, substituting C201 for C101.</p>
11	----	----	L101	<b>DEVIATION CHECK:</b> See "IDC" ADJUSTMENT PROCEDURE on the reverse side of this chart.

## "IDC" ADJUSTMENT (PREFERRED METHOD USING OSCILLOSCOPE)

### 1. INTRODUCTION

Accuracy of test equipment is of prime importance to any user of radio communications equipment; but of equal importance is a knowledge of the characteristics of the measuring equipment under various conditions. The Motorola Model T1100A Series FM Station Monitor is the leader in the field with respect to sensitivity, accuracy under conditions of variation in r-f signal level line voltage, and other environmental conditions. In common with most other meters, however, they have the characteristic of responding differently to different wave shapes. Therefore, the use of most present-day deviation meters can lead to confusion and errors in deviation setting, if the pitfalls are unknown or disregarded.

The "ideal" deviation indicator would be one which would respond instantaneously to the peak value of the modulation deviation, regardless of waveform. The only device which meets all these requirements is an oscilloscope. It responds instantaneously, and it shows the peak value of any waveform, no matter how complex. Properly calibrated, an oscilloscope is the most accurate and reliable means for measuring and setting transmitter deviation.

The oscilloscope must be used in conjunction with a receiver which has a stable discriminator characteristic, since the oscilloscope displays the demodulated signal. In addition to the oscilloscope a receiver and a means to accurately calibrate the system is required. The Motorola monitors fill these requirements, since they provide both a sensitive receiver with the proper discriminator characteristic and a reliable means of calibrating the oscilloscope. They have convenient terminals on the front panel for connection of the oscilloscope. Furthermore, the Motorola FM Station Monitor is provided with two modulation meter scales, 0-20 kc for wide-band systems, and 0-10 kc for split-channel systems.

Split-channel conversion kits are available for modification of older models, so that they too are provided with convenient oscilloscope terminals and can be more accurate measurement devices for such systems.

### 2. TEST EQUIPMENT REQUIRED

- Motorola T1100A Series FM Station Monitor (or equivalent)
- Motorola Transistorized AC Voltmeter (or equivalent)
- Motorola Model TEK-1A Transistorized Tone Generator, 400 & 1000 cps (or equivalent)
- Motorola Model T1015A General Purpose Oscilloscope, Motorola Model T1014B Precision Wide Band Oscilloscope (or equivalent)
- Motorola Model S1056A-9A or TU546 Series Portable Test Set (or equivalent) for "Private-Line" models only

### 3. OSCILLOSCOPE CALIBRATION

The first step in the measurement of transmitter deviation is to calibrate the oscilloscope. This can be done by using the transmitter which is to be measured. A "Private-Line" unit can be used for this purpose if the tone oscillator is disabled by removal of the "Vibrasender-sponder" unit. This is necessary since the "Private-Line" tone contributes to the maximum deviation.

Proceed as follows:

- The oscilloscope should be connected to the monitor oscilloscope terminals, and the monitor controls should be set up in accordance with the monitor instruction manuals.
- Turn the IDC control on the transmitter chassis to the full clockwise position.
- Feed a 1000 cps test tone into pin 2 of the microphone input jack (base of the amplifier-clipper stage Q110 in the IDC circuit). A 0.33 uf capacitor should be placed in series with the tone generator output. Modulate the transmitter with this tone so adjusted that the deviation as read on the FM monitor deviation meter is 2 kc (6 kc in a wide-band system). An audio oscillator must be used for generation of this tone, since a sinusoidal waveform is very important. The Motorola TEK-1A Transistorized Tone Generator is excellent for this purpose.
- Adjust the vertical gain of the oscilloscope so that the total recovered audio pattern occupies some convenient height, e.g., four small squares. (12 squares in a wide-band system.) The split-channel indication is shown in figure 1.




Figure 1.  
Oscilloscope Calibration for  
Split-Channel Transmitter

Having calibrated the oscilloscope, there is no further need for the modulation deviation meter and its reading should be ignored from this point on. It has already performed its important function of calibrating the oscilloscope.

With the oscilloscope calibrated as indicated, a recovered signal which occupies 10 squares (peak-to-peak) is equivalent to  $\pm 5$  kc deviation. For wide-band systems, a recovered signal occupying 30 squares (peak-to-peak) is equivalent to  $\pm 15$  kc deviation.

### 4. MEASUREMENT AND SETTING OF TRANSMITTER DEVIATION

#### a. Models for Carrier Squelch Application

Once the oscilloscope has been calibrated the transmitter deviation can be properly adjusted by the following method:

- Adjust the 1000 cps input signal to 1.5 volt. This should drive the IDC circuit into full clip. See Figure 2.




Figure 2.  
5 KC Peak Deviation as seen on the Oscilloscope  
(NOTE: Waveform is clipped fully)

(2) With this input signal level adjust the IDC control on the transmitter to provide a peak-to-peak recovered signal on the oscilloscope of 10 squares, which is equivalent to  $\pm 5$  kc deviation as shown in figure 2. A wide-band system should be adjusted for 30 squares ( $\pm 15$  kc). If the waveform under the above conditions does not resemble the waveform shown in figure 2 adjust L101 until a symmetrical waveform is obtained. Re-adjust the IDC control.

(3) Reduce 1000 cps input to 0.3 volt. Essentially full deviation should still be observed on the oscilloscope. Less than full deviation may indicate a weak audio transistor or other lack of audio gain.

#### b. "Private-Line" Models

(1) Remove "Vibrasender-sponder" resonant reed from its socket.

(2) Adjust the 1000 cps input signal to 1.5 volts. This should drive the IDC circuit into full clip. See Figure 2.

(3) With this input signal level adjust the IDC control on the transmitter to provide a peak-to-peak recovered signal on the oscilloscope of 10 squares, which is equivalent to  $\pm 5$  kc deviation as shown in figure 2. If the waveform under the above conditions does not resemble the waveform shown in figure 2, adjust L101 until a symmetrical waveform is obtained. Re-adjust the IDC control.

(4) Reduce 1000 cps input to 0.3 volt. Essentially full deviation should still be observed on the oscilloscope. Less than full deviation may indicate a weak audio transistor or other lack of audio gain.

(5) Remove the 1000 cps tone signal. Insert the "Vibrasender-sponder" unit in its socket.

(6) Check the "Private-Line" tone deviation. This may be read directly from the oscilloscope by pressing the transmitter on switch on the test set. The tone deviation should be 0.5 to 1 kc.

#### NOTE

If the tone deviation is less than 0.5 kc with jumper JU1 on position 2 (see circuit board diagram), move the jumper to position 3. If the deviation is greater than 1.0 kc, move the jumper to position 1M for the 30-42 mc band or 1H for the 42-54 mc band. Always choose the jumper position which produces a tone deviation between 0.5 and 1.0 kc.

Due to a slight increase in discriminator response at the lower frequencies, the oscilloscope will read high, thus, an indication of 1.4 to 2.8 squares (peak-to-peak) is equivalent to 0.5 to 1 kc. This slight variation is only important when checking tone deviation. When setting maximum transmitter deviation as described in the following paragraphs, it may be ignored.

(7) Apply a 1000 cps test tone to pin 2 of the microphone input jack (base of the amplifier-clipper stage Q110). Place a 0.33 uf capacitor in series with the tone generator output.

(8) Adjust the 1000 cps input signal level for 1 volt and note the resultant combined deviation of the 1000 cps modulation and tone signal modulation on the oscilloscope.

(9) The IDC control on the transmitter should be adjusted to provide a peak-to-peak combined signal of 10 squares, equivalent to full 5 kc as shown in figure 3.




Figure 3.

5 KC Peak Deviation for Combined PL Tone and  
1000 CPS Modulation

(10) Reduce the 1000 cps input to 0.35 volt. Essentially full combined 1000 cps tone and "Private-Line" tone deviation should still be observed on the oscilloscope. Less than full combined deviation may indicate a defective transistor or other lack of audio gain.

#### 5. EMERGENCY MEASUREMENT OF DEVIATION

If an audio oscillator is not available, a loud sustained whistle of approximately 1000 cycles can be used for a rough measurement of deviation. If this rough check indicates the need for resetting deviation, do so only under controlled conditions, using a 1000 cps tone as previously indicated. The calibration of the oscilloscope should always be performed with a steady controlled signal. Do not attempt to calibrate the oscilloscope with a sustained whistle as waveform distortion will prevent an accurate calibration.

#### 6. OTHER MEANS FOR MEASUREMENT OF DEVIATION

Another accurate means of measuring transmitter deviation is to use the Motorola T1020A Portable Frequency and Deviation Meter. This unit, properly used, permits the accurate measurement and setting of transmitter deviation from a peak-reading meter which is unaffected by waveform. An oscilloscope is not required with this instrument. With this device, the transmitter deviation can be measured accurately even with voice modulation.

#### 7. MICROPHONE LEVELS

If the modulation level in the system still appears to be too low after setting deviation as indicated above, check the microphone and audio amplifier.

The foregoing procedure will insure that the transmitter will comply with FCC requirements for maximum deviation.

The importance of the correct deviation setting can not be overemphasized. Optimum system performance demands accurate deviation setting, both from the standpoint that over deviation will interfere with the user on the adjacent channel, and underdeviation may reduce system range.

**TEST EQUIPMENT REQUIRED FOR RECEIVER ALIGNMENT**

1. Motorola DC Multimeter with r-f probe.
2. Motorola Transistorized AC Voltmeter or equivalent.
3. Motorola T1034C Signal Generator or equivalent.
4. Motorola S1056A-9A or TU546 Series Test Set with 455 kc crystal or equivalent crystal-controlled oscillator.
5. Motorola NLN6252A Alignment Tool (supplied).

**PRELIMINARY SET-UP FOR RECEIVER ALIGNMENT**


1. Remove the cover from the radio section of the unit.
2. When aligning a two-frequency unit, align on the primary or higher of the two frequencies.
3. The d-c multimeter ground lead should be connected to a convenient ground.
4. For complete alignment, the battery should be removed and a 15 volt d-c power supply and ammeter connected to the battery plug. All tuning slugs should be unscrewed so they protrude 1/8 inch above the printed circuit board.
5. Remove the antenna by unscrewing it from the receptacle. Connect a signal generator to the antenna receptacle.

**FREQUENCY CALCULATIONS**

**LEGEND**

- $f_c$  = carrier frequency (25-54 mc)
- $f_{01}$  = 1st oscillator crystal frequency (30.7-48.3 mc)
- $f_{02}$  = 2nd oscillator frequency
- $f_1$  = 1st intermediate frequency (5.7 mc)
- $f_2$  = 2nd intermediate frequency (455 kc)
- $f_{01} = f_c + f_1$  (25-42 mc)
- $f_{01} = f_c - f_1$  (42-54 mc)

$f_c$	$f_{02}$
25.00-30.00 mc	6.155 mc
30.02-30.86 mc	5.245 mc
30.90-36.84 mc	6.155 mc
36.86-37.00 mc	5.245 mc
37.02-41.98 mc	6.155 mc
42.00-42.98 mc	6.155 mc
43.00-43.16 mc	5.245 mc
43.18-49.14 mc	6.155 mc
49.16-49.32 mc	5.245 mc
49.34-54.00 mc	6.155 mc




**ALIGNMENT PROCEDURE**

**NOTES**

1. All slugs should be tuned to the peak nearest the printed circuit board end of the coil.
2. Turn on the radiophone and set the squelch control for maximum noise.

STEP	TEST EQUIPMENT	METER POINT & COLOR CODE	ADJUSTMENT	PROCEDURE
1	DC multimeter with r-f probe	M-6 (BLU)	L5 1st Osc	Tune L5 for max. d-c reading on the meter.
2	DC multimeter and 455 kc crystal osc	M-7 (VIO)	L9 Limiter	Couple a 455 kc signal into the 455 kc filter input terminals. Tune L9 for a maximum positive d-c reading.
3	DC multimeter and 455 kc crystal osc	M-4 (YEL)	L10 Disc.	Tune L10 for a zero d-c meter reading. NOTE: As the slug is moved into the discriminator coil, the meter reading may move slowly through zero and then sharply return through zero again. Tune the slug to the latter point.
4	T1034C Signal Generator and d-c multimeter	M-4 (YEL)	Signal Generator to carrier frequency	Connect the signal generator to the test jig. Set the attenuator for 5,000 microvolts and adjust the signal frequency for a zero d-c reading on the meter. *Do not set the frequency to the 2nd i-f image frequency.
5	T1034C Signal Generator and a-c voltmeter	M-1 (BRN)	L1, L2, T1, L3, T2, T3, T4, L4, T5	Tune these slugs successively for a maximum meter reading. Keep the meter reading below -30 dbm on the a-c voltmeter.
6	DC multimeter	M-4 (YEL)	L5 1st Osc	Use the base station transmitter or a frequency standard as a signal source and adjust L5 for a zero d-c reading. NOTE: Set JU2 (and JU3 on 2-freq.) to tap ① or ② to obtain proper frequency.
7	T1034C Signal Generator and a-c voltmeter.	Pin #4 of Mic. connector	Signal Generator for 20 db quieting sensitivity	A 120 ohm resistor must be connected across the a-c voltmeter (handset only models). Set squelch control for maximum noise. Connect the adapter cable from the voltmeter to the antenna receptacle. Adjust the volume control for an output voltage of 0.44 v a-c (noise only-no signal input) for receivers with speakers and 0.12 v a-c for handset only models. Using the test set this reading should be about 50 ua with the multiplier switch in the 0.2 v a-c position. Zero the signal generator on the discriminator. Increase the signal intensity until the noise reading is reduced to one-tenth of the reading with no signal (maximum noise). Read the attenuator scale in microvolts (should be less than 0.35 microvolts). This is the 20 db quieting sensitivity.

**\*CAUTION:** After adjusting the signal generator to the carrier in the 42-54 mc (H) band look for the image frequency at 910 kc below this setting if the 2nd oscillator frequency is 5.245 mc or 910 kc above this setting if the 2nd oscillator frequency is 6.155 mc. After adjusting the signal generator to the carrier in 25-30 mc (L) band or 30-42 mc (M) band look for the image frequency 910 kc above this setting if the 2nd oscillator frequency is 5.245 mc or 910 kc below this setting if the 2nd oscillator frequency is 6.155 mc. This is a check on the accuracy of the setting. Upon locating the image, return to the proper setting for the carrier frequency.



APPLICABLE CONTROL PANELS	
NCN6039A	NCN6049A
NCN6041A	NCN6052A
NCN6043A	NCN6054A
NCN6044A	NCN6056A
NCN6045A	NCN6058A
NCN6047A	NCN6060A

- NOTES:
- 2-FREQ. RECEIVER ONLY.
  - 2-FREQ. TRANSMITTER ONLY.
  - SPEAKER AND GROUND OMITTED IN HANDSET MODELS.
  - SWITCH VIEWED FROM THE REAR.
  - TO K1-8 IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.
  - CONNECTED TO THE RF OUTPUT OF THE TRANSMITTER IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.

EPD-13959-O


DIAGRAM NO. 63D81039A72-0


APPLICABLE CONTROL PANELS	
NCN6043B	NCN6054B
NCN6044B	

NOTES:

- 2-FREQ. RECEIVER ONLY.
- 2-FREQ. TRANSMITTER ONLY.
- SPEAKER AND GROUND OMITTED IN HANDSET MODELS.
- SWITCH VIEWED FROM THE REAR.
- TO K1-4 IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.
- CONNECTED TO THE RF OUTPUT OF THE TRANSMITTER IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.

EPD-13960-O





APPLICABLE CONTROL PANELS	
NCN6040A	NCN6053A
NCN6042A	NCN6055A
NCN6046A	NCN6057A
NCN6048A	NCN6059A
NCN6050A	NCN6061A
NCN6051A	NCN6065A

- NOTES:
- 2-FREQ. RECEIVER ONLY.
  - 2-FREQ. TRANSMITTER ONLY.
  - SPEAKER AND GROUND OMITTED IN HANDSET MODELS.
  - SWITCH VIEWED FROM THE REAR.
  - TO K1-8 IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.
  - CONNECTED TO THE RF OUTPUT OF THE TRANSMITTER IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.

EPD-13961-O

DIAGRAM NO. 63D81039A74-0

APPLICABLE CONTROL PANELS	
NCN6040B	NCN6065B

- NOTES:
1. 2-FREQ. RECEIVER ONLY.
  2. 2-FREQ. TRANSMITTER ONLY.
  3. SPEAKER AND GROUND OMITTED IN HANDSET MODELS.
  4. SWITCH VIEWED FROM THE REAR.
  5. TO K1-4 IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.
  6. CONNECTED TO THE RF OUTPUT OF THE TRANSMITTER IN P21DDN SERIES MODELS OR TO HIGH POWER FINAL AMPLIFIER IN P31DDN SERIES MODELS.

EPD-13962-O







DIAGRAM NO. 63D81039A77-O




- NOTES:
1. DASHED CIRCUITRY USED IN TWO FREQUENCY OPERATION ONLY.
  2. REFER TO PARTS LISTS FOR COMPONENT VALUES.
  3. USED ON I-FREQ. MODELS ONLY.
  4. APPEARS ON 30-42 MC UNITS ONLY.
  5. USED IN "PRIVATE-LINE" MODELS ONLY.
  6. USED IN CARRIER SQUELCH MODELS ONLY.
  7. USED IN NTB6060 SERIES ONLY.

MODEL	SUFFIX
NTB6051AC	1
NTB6052AC	3
NTB6061AC	1
NTB6062AC	3

FOR UNITS SUFFIXED LATER THAN INDICATED IN THIS CHART, REFER TO CIRCUIT BOARD DIAGRAM EPD-13429.

REVISIONS

DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION
M	NTB6051AA-5 NTB6052AA-7 NTB6053AA-6 NTB6061AA-5 NTB6062AA-7 NTB6063AA-6 NTB6051AB-5 NTB6052AB-8 NTB6053AB-6 NTB6061AB-5 NTB6062AB-8 NTB6063AB-6 NTB6051AC-1 NTB6052AC-3 NTB6053AC-5 NTB6061AC-1 NTB6062AC-3 NTB6063AC-5 NTB6051AD-2 NTB6052AD-4 NTB6053AD-4 NTB6061AD-2 NTB6062AD-4 NTB6063AD-4		ADDED MODEL TABLE.	BELOW CKT. BOARD
N	NTB6051AA-5 NTB6052AA-7 NTB6053AA-6 NTB6061AA-5 NTB6062AA-7 NTB6063AA-6 NTB6051AB-5 NTB6052AB-8 NTB6053AB-6 NTB6061AB-5 NTB6062AB-8 NTB6063AB-6 NTB6051AC-1 NTB6052AC-3 NTB6053AC-5 NTB6061AC-1 NTB6062AC-3 NTB6063AC-5 NTB6051AD-2 NTB6052AD-4 NTB6053AD-4 NTB6061AD-2 NTB6062AD-4 NTB6063AD-4		ADDED NOTES	



AEPD-9005-O


MODEL TABLE

SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF FREQ.	FREQUENCY RANGE	RF POWER OUTPUT
NTB6050AA	NTB6051AA	5	1	25-30 MC	1.4 W
	NTB6052AA	7	1	30-42 MC	1.4 W
	NTB6053AA	6	1	42-54 MC	1.4 W
NTB6050AB	NTB6051AB	5	2	25-30 MC	1.4 W
	NTB6052AB	8	2	30-42 MC	1.4 W
	NTB6053AB	6	2	42-54 MC	1.4 W
NTB6060AA	NTB6061AA	5	1	25-30 MC	5 W
	NTB6062AA	7	1	30-42 MC	5 W
	NTB6063AA	6	1	42-54 MC	5 W
NTB6060AB	NTB6061AB	5	2	25-30 MC	5 W
	NTB6062AB	8	2	30-42 MC	5 W
	NTB6063AB	6	2	42-54 MC	5 W
NTB6050AC	NTB6051AC	1	1	25-30 MC	1.4 W
	NTB6052AC	3	1	30-42 MC	1.4 W
	NTB6053AC	5	1	42-54 MC	1.4 W
NTB6050AD	NTB6051AD	2	2	25-30 MC	1.4 W
	NTB6052AD	4	2	30-42 MC	1.4 W
	NTB6053AD	4	2	42-54 MC	1.4 W
NTB6060AC	NTB6061AC	1	1	25-30 MC	5 W
	NTB6062AC	3	1	30-42 MC	5 W
	NTB6063AC	5	1	42-54 MC	5 W
NTB6060AD	NTB6061AD	2	2	25-30 MC	5 W
	NTB6062AD	4	2	30-42 MC	5 W
	NTB6063AD	4	2	42-54 MC	5 W

EPD-15503-O

Transmitter Printed Circuit Board And Wiring Diagram  
Motorola No. EPD-8838-N  
9/23/66-AP


MODEL TABLE (HANDSET ONLY)			
MODEL SERIES	NO. OF FREQ	CHANNEL WIDTH	TYPE OF SQUELCH
NRB1150AA	1	40 KC	CARRIER
NRB1150AB	1	20 KC	
NRB1150AC	2	40 KC	
NRB1150AD	2	20 KC	
NRB1150AF	1	20 KC	DUAL




- NOTES:
1. REFER TO PARTS LIST FOR COMPONENT VALUES.
  2. FOR UNITS 48-54 MC & 36-42 MC, JU2/JU3 IS CONNECTED TO POSITION ② FOR UNITS 25-30, 30-36, & 42-48 JU2/JU3 IS CONNECTED TO POSITION ①
  3. WIDE BAND ONLY.
  4. DASHED CIRCUITRY USED IN DUAL SQUELCH MODELS UNLESS OTHERWISE STATED.

REVISIONS

DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION
K	NRB1151AF-8 NRB1152AF-7 NRB1153AF-7	C61	WAS 21K861443, .01 uf	LOWER RIGHT OF Q12
L	NRB1151AF-8 NRB1152AF-7 NRB1153AF-7	R805	R805 WAS R66	BOTTOM CENTER OF BD.
M	NRB1151AA-8 NRB1152AA-7 NRB1153AA-7 NRB1151AB-7 NRB1153AB-6 NRB1151AC-8 NRB1152AC-7 NRB1153AC-7 NRB1151AD-7 NRB1153AD-6 NRB1151AF-8 NRB1152AF-7 NRB1153AF-7	C17	WAS 21D82877B17, 5 uf	CENTER OF BOARD
		C86	ADDED 100 uf	TOP MIDDLE OF BD.
		Q3	WAS 48R869238, TYPE M9238	
		R63	WAS 6K129269, 1.8K	Q13 BASE CKT.






OL DEP-13428-D  
50-3990-391b-1

- NOTES:  
 2. REFER TO PARTS LISTS FOR COMPONENT VALUES.  
 3. USED IN SINGLE FREQUENCY MODELS ONLY.  
 4. APPEARS ON 30-42 MC UNITS ONLY.  
 12. PART OF UNIT COMPONENT KIT.

REVISIONS

DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION
E	NTB6051AA-7 NTB6052AA-9 NTB6053AA-8 NTB6051AB-7 NTB6052AB-10 NTB6053AB-8 NTB6061AA-7 NTB6062AA-9 NTB6063AA-8 NTB6061AB-7 NTB6062AB-10 NTB6063AB-8 NTB6051AC-6 NTB6052AC-9 NTB6061AC-6 NTB6062AC-9	L111	WAS 24B82872B01	Q110 COLLECTOR
F	NTB6051AA-7 NTB6052AA-9 NTB6053AA-8 NTB6051AB-7 NTB6052AB-10 NTB6053AB-8 NTB6061AA-7 NTB6062AA-9 NTB6063AA-8 NTB6061AB-7 NTB6062AB-10 NTB6063AB-8 NTB6051AC-6 NTB6052AC-9 NTB6061AC-6 NTB6062AC-9		9 uh WAS 9 mh	LEFT CENTER OF BOARD



AEPD-9005-O

MODEL TABLE

SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF FREQ.	FREQUENCY RANGE	RF POWER OUTPUT
NTB6050AC	NTB6051AC	6	1	25-30 MC	1.4 W
	NTB6052AC	9	1	30-42 MC	1.4 W
NTB6050AD	NTB6051AD	2	2	25-30 MC	1.4 W
	NTB6052AD	4	2	30-42 MC	1.4 W
	NTB6053AD	4	2	42-54 MC	1.4 W
NTB6060AC	NTB6061AC	6	1	25-30 MC	5 W
	NTB6062AC	9	1	30-42 MC	5 W
NTB6060AD	NTB6061AD	2	2	25-30 MC	5 W
	NTB6062AD	4	2	30-42 MC	5 W
	NTB6063AD	4	2	42-54 MC	5 W

EPD-15463-O


MODEL	SUFFIX
NTB6051AC	2
NTB6052AC	4
NTB6061AC	2
NTB6062AC	4

FOR UNITS SUFFIXED EARLIER THAN INDICATED IN THIS CHART, REFER TO CIRCUIT BOARD DIAGRAM EPD-8838.

EPD-13473-O


Transmitter Printed Circuit Board  
 And Wiring Diagram  
 Motorola No. EPD-13429-F  
 9/23/66-AP

MODEL TABLE (SPEAKER MODELS)			
MODEL SERIES	NO OF FREQ	CHANNEL WIDTH	TYPE OF SQUELCH
NRB1120AA		40 KC	CARRIER
NRB1120AB		20 KC	
NRB1120AC		40 KC	
NRB1120AD		20 KC	
NRB1120AF	1	20 KC	DUAL
NRB1120AH	2	20 KC	DUAL



- NOTES:
- REFER TO PARTS LIST FOR COMPONENT VALUES.
  - FOR UNITS 48-54 MC & 36-42MC, JU2/JU3 IS CONNECTED TO POSITION ② FOR UNITS 25-30, 30-36, & 42-48 JU2/JU3 IS CONNECTED TO POSITION ①
  - WIDE BAND ONLY.
  - DASHED CIRCUITRY USED IN DUAL SQUELCH MODELS UNLESS OTHERWISE STATED.
  - PART OF UNIT COMPONENT KIT.

REVISIONS				
DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION
P	NRB1121AC-12 NRB1122AC-15 NRB1123AC-15 NRB1121AD-11 NRB1122AD-14 NRB1123AD-13	R70	WAS 2.2K	Q1 COLLECTOR
R	NRB1121AA-12 NRB1122AA-15 NRB1123AA-15 NRB1121AB-11 NRB1122AB-14 NRB1123AB-13 NRB1121AC-12 NRB1122AC-15 NRB1123AC-15 NRB1121AD-11 NRB1122AD-14 NRB1123AD-13 NRB1121AF-12 NRB1122AF-15 NRB1123AF-14 NRB1121AH-7 NRB1122AH-6 NRB1123AH-6	C17	WAS 21D82877B17, 5 uuf	CENTER OF BOARD
		C86	ADDED 100 uuf	TOP MIDDLE OF BD.
		Q3	WAS 48R869238, TYPE M9238	
		R63	WAS 6K129269, 1.8K	Q13 BASE CKT.




RECEIVER PRINTED CIRCUIT BOARD AEPD-8482-O


Speaker-Microphone and Speaker-Handset Models Receiver Printed Circuit Board And Wiring Diagram Motorola No. EPD-8841-R 9/23/66-AP

REVISIONS

DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION
A	NTB6051AA-7 NTB6052AA-9 NTB6053AA-8 NTB6051AB-7 NTB6052AB-10 NTB6053AB-8 NTB6061AA-7 NTB6062AA-9 NTB6063AA-8 NTB6061AB-7 NTB6062AB-10 NTB6063AB-8 NTB6053AC-7 NTB6063AC-7	Q101, 201	WERE M9189	BOTTOM OF BOARD



NOTES:  
 2. REFER TO PARTS LISTS FOR COMPONENT VALUES.  
 3. USED IN SINGLE FREQUENCY MODELS ONLY  
 4. APPEARS ON 30-42 MC UNITS ONLY  
 12. PART OF UNIT COMPONENT KIT.



AEPD-9005-O

MODEL TABLE


SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF FREQ.	FREQUENCY RANGE	RF POWER OUTPUT
NTB6050AA	NTB6051AA	7	1	25-30 MC	1.4 W
	NTB6052AA	9	1	30-42 MC	1.4 W
	NTB6053AA	8	1	42-54 MC	1.4 W
NTB6050AB	NTB6051AB	7	2	25-30 MC	1.4 W
	NTB6052AB	10	2	30-42 MC	1.4 W
	NTB6053AB	8	2	42-54 MC	1.4 W
NTB6060AA	NTB6061AA	7	1	25-30 MC	5 W
	NTB6062AA	9	1	30-42 MC	5 W
	NTB6063AA	8	1	42-54 MC	5 W
NTB6060AB	NTB6061AB	7	2	25-30 MC	5 W
	NTB6062AB	10	2	30-42 MC	5 W
	NTB6063AB	8	2	42-54 MC	5 W
NTB6050AC	NTB6053AC	7	2	42-54 MC	5 W
NTB6060AC	NTB6063AC	7	2	42-54 MC	5 W

EPD-15462-O


Transmitter Printed Circuit Board  
 And Wiring Diagram  
 Motorola No. EPD-15460-A  
 9/23/66-AP

REVISIONS

DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION
A	NLB6141A-1	C727	ADDED 21K831126 .02 uf	"VIBRA-SENDER-SPONDER" UNIT CONTACT A
B	NLB6141A-2	R719	WAS 6K127806 (27K)	"VIBRA-SENDER-SPONDER" RESONANT REED CONTACT E
C	NLB6141A-3	C718	WAS 23D82397D07	LOWER LEFT OF BOARD
D	NLB6141A-3	C729	ADDED	"VIBRA-SENDER-SPONDER" UNIT CONTACT E
E	NLB6141A-4	R706	WAS 6K129862, 150 OHMS	Q701 EMITTER
F	NLB6141A-5	R726	ADDED 56K OHMS	Q701 BASE
		R727	ADDED 470 OHMS	LOWER RIGHT OF BOARD
G	NLB6141A-6	C702A, 702B	WAS 21B861469, DUAL .01 uf	LOWER LEFT OF BOARD
H	NLB6141A-7	C730	ADDED	LOWER LEFT OF BOARD
J	NLB6141A-7	C703	REMOVED 23D82397D11, .068 uf	UPPER LEFT OF BOARD
		C706	REMOVED 23 23D82397D12, 0.12 uf	
		L701	REPLACED 25C82750D01, CHOKE 5H WITH JUMPER CKT WAS AS SHOWN BELOW	
		R701, R708	WERE 6S127805, 1/4 W	PARTS LIST
		R703	WAS 6S128686, 1/4 W	
		R704, 705, 714, 716	WERE 6K129242, 1/4 W	
		R726	WAS 6K128570, 1/10 W	
		R706	WAS 6K129662, 1/4 W	
		R709	WAS 6K128987, 1/4 W	
		R710, 711, 712	WERE 6S127804, 1/4 W	
		R713	WAS 6K128558, 1/10 W	
		R721	WAS 6K129620, 1/4 W	
		R727	WAS 6K128545, 1/10 W	
		R715, 717, 723	WERE 6S128689, 1/4 W	
K	NLB6141A-8	C716	WAS 23D82397D16, 22 uf, 15 V	



Model NLB6141A 25-42 MC "Private-Line"  
 Printed Circuit Board & Wiring Diagram  
 Motorola No. EPD-9204-K  
 9/23/66-AP



MODEL TABLE		
MODEL	SUFFIX	DESCRIPTION
NLB6142A	7	"PRIVATE-LINE" SQUELCH BOARD

LEGEND:  
(T) = TRANSMIT MODE  
(R) = RECEIVE MODE

REVISIONS

DIAG. ISSUE	BOARD AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION																																				
A	NLB6142A-1	C727	ADDED 21K831126 .02 uf	"VIBRASENDER-SPONDER" UNIT CONTACT A																																				
B	NLB6142A-2	R719	WAS 6K127906 (27K)	"VIBRASENDER-SPONDER" RESONANT REED CONTACT E																																				
C	NLB6142A-3	C718	WAS 23D82397D07 1 uf	LOWER LEFT OF BOARD																																				
D	NLB6142A-4	R706	WAS 6K129862, 150 OHMS	Q701 EMITTER																																				
		R726	ADDED 56K OHMS	Q701 BASE																																				
E	NLB6142A-5	R727	ADDED 470 OHMS	LOWER RIGHT OF BOARD																																				
F	NLB6142A-6	C702A, 702B	WAS 21B861469, DUAL .01 uf	LOWER LEFT OF BOARD																																				
G	NLB6142A-6	C703	REMOVED 23D82397D11, .068 uf	UPPER LEFT OF BD.																																				
		C706	REMOVED 23D82397D12, 0.12 uf																																					
		L701	REPLACED 25C82750D01, CHOKE 5H WITH JUMPER. CKT WAS AS SHOWN BELOW																																					
				<table border="1"> <thead> <tr> <th colspan="3">PARTS LIST</th> </tr> <tr> <th>REF. SYMBOL</th> <th>DESCRIPTION</th> <th>QUANTITY</th> </tr> </thead> <tbody> <tr> <td>R701, 708</td> <td>WERE 6S127805, 1/4 W</td> <td></td> </tr> <tr> <td>R703</td> <td>WAS 6S128686, 1/4 W</td> <td></td> </tr> <tr> <td>R704, 705, 714, 716</td> <td>WERE 6K129242, 1/4 W</td> <td></td> </tr> <tr> <td>R726</td> <td>WAS 6K128570, 1/10 W</td> <td></td> </tr> <tr> <td>R706</td> <td>WAS 6K129662, 1/4 W</td> <td></td> </tr> <tr> <td>R709</td> <td>WAS 6K128987, 1/4 W</td> <td></td> </tr> <tr> <td>R710, 711, 712</td> <td>WERE 6S127804, 1/4 W</td> <td></td> </tr> <tr> <td>R713</td> <td>WAS 6K128558, 1/10 W</td> <td></td> </tr> <tr> <td>R721</td> <td>WAS 6K129620, 1/4 W</td> <td></td> </tr> <tr> <td>R715, 717, 723</td> <td>WERE 6S128689, 1/4 W</td> <td></td> </tr> </tbody> </table>	PARTS LIST			REF. SYMBOL	DESCRIPTION	QUANTITY	R701, 708	WERE 6S127805, 1/4 W		R703	WAS 6S128686, 1/4 W		R704, 705, 714, 716	WERE 6K129242, 1/4 W		R726	WAS 6K128570, 1/10 W		R706	WAS 6K129662, 1/4 W		R709	WAS 6K128987, 1/4 W		R710, 711, 712	WERE 6S127804, 1/4 W		R713	WAS 6K128558, 1/10 W		R721	WAS 6K129620, 1/4 W		R715, 717, 723	WERE 6S128689, 1/4 W	
PARTS LIST																																								
REF. SYMBOL	DESCRIPTION	QUANTITY																																						
R701, 708	WERE 6S127805, 1/4 W																																							
R703	WAS 6S128686, 1/4 W																																							
R704, 705, 714, 716	WERE 6K129242, 1/4 W																																							
R726	WAS 6K128570, 1/10 W																																							
R706	WAS 6K129662, 1/4 W																																							
R709	WAS 6K128987, 1/4 W																																							
R710, 711, 712	WERE 6S127804, 1/4 W																																							
R713	WAS 6K128558, 1/10 W																																							
R721	WAS 6K129620, 1/4 W																																							
R715, 717, 723	WERE 6S128689, 1/4 W																																							
H	NLB6142A-7	C716	WAS 22 uf, 23D82397D16 15 V	Q703 EMITTER																																				

REVISIONS

DIAG. ISSUE	CHASSIS AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION	REFER TO CIRCUIT BOARD
AK	NTB6051AA-7 NTB6052AA-9 NTB6053AA-8 NTB6051AB-7 NTB6052AB-10 NTB6053AB-8 NTB6061AA-7 NTB6062AA-9 NTB6063AA-8 NTB6061AB-7 NTB6062AB-10 NTB6063AB-8	L111	WAS 25B82872B01	PARTS LIST	XMTR. CKT. BD. EPD-13429-E
AK1	NRB1121AA-11 NRB1122AA-14 NRB1123AA-14 NRB1121AB-10 NRB1122AB-13 NRB1123AB-12 NRB1121AC-11 NRB1122AC-14 NRB1123AC-14 NRB1121AD-10 NRB1122AD-13 NRB1123AD-12	C17	WAS 21D82877B17, 5 uuf; N150	Q3 BASE	EPD-8978-M, EPD-8841-R
		C86	ADDED 100 uuf	Q13 BASE	
		Q3	WAS 48R869238, TYPE M9238	1ST IF AMP	
		R63	WAS 6K129269, 1.8K	PARTS LIST	
	NTB6051AA-7 NTB6052AA-9 NTB6053AA-8 NTB6051AB-7 NTB6052AB-10 NTB6053AB-8 NTB6061AA-7 NTB6062AA-9 NTB6063AA-8 NTB6061AB-7 NTB6062AB-10 NTB6063AB-8	Q101, 201 C124H C125M C135M C139M C148	WERE 48R869189, TYPE M9189 WAS 21D82877B02, 150 uuf WAS 21K861435, 500 uuf WAS 21K861435, 70 uuf WAS 21K861441, 500 uuf ADDED 15 uuf	OSC. PARTS LIST	EPD-8838-N, EPD-15460-A
	NPN6030B	C601 THRU 605	WERE 21C82187B16	PARTS LIST	NONE
	NPN6031A	C601, 602	ADDED .003 uf	LOWER RIGHT OF DIAG.	NONE
	NLN6234A-3	C81, 90, 91 R35, 36	WERE 50 uuf WERE 6K128563, 15K, 1/10 W	PARTS LIST	EPD-8978-M

PARTS LIST for Schematic Diagram 63E81017A21-AK1

LEGEND  
L = 25-30 MC  
M = 30-42 MC  
H = 42-54 MC

RECEIVER

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
NRB1121AA	NRB1121AD	NRB1151AC
NRB1122AA	NRB1122AD	NRB1152AC
NRB1123AA	NRB1123AD	NRB1153AC
NRB1121AB	NRB1151AA	NRB1151AD
NRB1122AB	NRB1152AA	NRB1152AD
NRB1123AB	NRB1153AA	NRB1153AD
NRB1121AC	NRB1151AB	
NRB1122AC	NRB1152AB	
NRB1123AC	NRB1153AB	
C11L, 1M, 10M	21K861433	CAPACITOR, fixed: uuf ±10%; 75 v; unl. stated
C1H, 10H, 12H	21K861462	36; N150
C2L, 2H, 32, 59	21D82877B02	150; N150
C2M, 82	21K868829	220; N1400
C3	21C82450B27	1.5; 500 v
C4L	21K861433	36; N150; handset models
C4M, 5M, 81	or21K861434	40; N150; speaker models
C4H, 34, 305	21K864013	50; N150
C5L	21K861432	20; N150
C5H, 8M, 12M	21K861435	70; N150
C6, 9L, 11L	21D82877B06	30; N150
C7L, 7M, 13L, 13M, 14L, 14M, 21, 27, 31, 37, 75, 77, 301, 303, 306	21C82450B30	1.8 ±5%
C7H, 13H, 14H, 43, 47, 54, 83	21K861442	.002 uf +100-20%
C8L	21D82877B01	24; N150
C8H	21K861431	12; N150
C9H, 11H	21C82450B24	0.47; 500 v
C9M, 11M, 33, 304	21C82450B28	1.0; 500 v
C10L, 12L	21D82877B01	24; N150; handset models
C15	or21D82877B06	30; N150; speaker models
C16	21D82877B15	120; N150
C17	21K861440	470; N2200
C18, 20, 26, 28, 50	21K861603	3.3 ±5%; NPO
C19	21K861444	.02 uf +100-20%
C22, 23	21D82877B14	91; N470
C24, 25	21C82450B22	0.75; 500 v
C29	21K864522	90; N080
C30	21K861429	8; N150
C33, 304	21K865197	25; N150
C35, 302	21C82450B28	1.0; 500 v
C42, 44, 46, 48, 49, 51, 56, 61, 79, 80	21K861427	4; N150
C52	21K861443	.01 uf +100-20%
C53	21D82239E02	800 ±5%; 200 v
C55	23D82397D06	0.22 uf +40-20%; 35 v
C57	23D82397D16	22 uf ±20%; 15 v
C58, 62	21K864457	.002 uf +100-20%
C60	8C82317B03	.03 uf; 50 v
C63, 78	21D82239E03	250 ±5%; 200 v
C64	23D82397D19	2 uf +40-20%; 8 v
C65	23D82397D05	4.7 uf +40-20%; 3 v
C66, 67, 71	23D82397D19	2 uf +40-20%; 8 v
C68	23D82397D17	15 uf ±20%; 20 v
C69	21C82187B16	3000; 100 v (speaker models)
C70	or21D82428B09	4700; 100 v (handset models)
C72, 73	23D82397D07	1 uf +40-20%; 15 v
C74	23D82397D16	22 uf ±20%; 15 v (speaker models)
C84	23D82397D15	10 uf ±20%; 20 v
C85L, 85M	23D82397D08	0.15 uf +40-20%; 35 v
C86	8C82317B01	0.1 uf; 100 v
	21K861426	2.2; N150
	21K861437	100; N2200

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
GR1	48C82363E03	SEMICONDUCTOR DEVICE, diode: NOTE 1
CR2	48C859464	silicon
CR4, 6, 7	48C82178A01	germanium
CR8, 9, 10	48C82363E02	germanium
L1L, 2L, 3L	24C82765D07	silicon
L1M, 1H, 2M, 2H, 3M, 3H	24C82765D06	COIL, RF: GRN-RED; does not incl 76K861425 CORE, tuning GRN-BRN; does not incl 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
L4	24C82765D05	GRN-GRA; does not incl 76K847160 CORE, tuning or 76A82686D01 SLEEVE, iron
L5M, 301M	24C82766D08	BLU-RED; does not incl 76A82686D02 CORE, tuning
L5L, 5H, 301L, 301H	24C82766D04	BLU-GRA; does not incl 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
L6	24C847920	choke; 9 uh
L9	24B82695D01	limiter; c/o; pri: term. no. 1 and 2 with no. 5 center tap; sec: term. no. 3 and 4
L10	24B82696D01	discriminator; 455 kc; incl tuning core
L12	25B82751D01	choke; 1.5 h
Q1	48R869375	TRANSISTOR: NOTE 1
Q2, 5, 301	48R869168	P-N-P; type M9375
Q3	48R869169	P-N-P; type M9168
Q4	48K869062	N-P-N; type M9169
Q6, 7, 8, 9, 10, 11	48R869057	N-P-N; type M9062 BLU
Q12, 13	48R869148	P-N-P; type M9057
Q14	48R869022	P-N-P; type M9148
Q15	48R869028	N-P-N; type M9022
Q16	48R869027	P-N-P; type M9028
R1,14,37,38,304	6K127806	N-P-N; type M9027
R2, 9, 22, 24, 26, 28, 30, 45, 47	6K127804	RESISTOR, fixed: ±10%; 1/4 w; unl stated
R3, 4, 7	6K129432	27K
R5	6K129433	4.7K
R6, 21, 23, 25, 27, 29	6K127807	820
R8, 52, 57	6K127801	5.6K
R10, 59	6K129775	33K
R11, 31	6K128685	820
R12	6K129225	5.6K
R13,32,39,44	6K128688	33K
R15, 303	6K128687	820
R16, 17, 34,69, 301, 302	6K127802	5.6K
R33, 50	6K128689	1K
R43, 60	6K128904	2.2K
R46	6K129144	18K
R49	6K127803	68K
R51	6K129233	1.5K
R53	6K129433	47
or6K127804		5.6K; handset models
R54, 55	6K127806	4.7K; speaker models
R58	6K129862	27K; speaker models
R63	6K128552	150
R64	6K129753	1.8K; 1/10 w
R70	6S185B84	100; handset models
T1L	24C82767D06	2.7K; 1/8 w
T1M, 1H	24C82767D03	TRANSFORMER: GRN-BLK; does not incl 76K861425 CORE, tuning GRN-ORG; does not incl 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
T2L	24C82767D07	GRN-VIO; does not incl 76K861425 CORE, tuning
T2M, 2H	24C82767D04	GRN-GRN; does not incl 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
T3, 5	24C82767D05	GRN-BLU; does not incl 76K847160 CORE, tuning or 76A82686D01 SLEEVE, iron


REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
T4	24C82207G01	RED-RED; does not incl 76K847160 CORE, tuning or 76A82686D01 SLEEVE, iron
T6	25B82699D01	audio input; BLU dot; c/o; pri: coil res. 1340; impd. 10K
T7	25B82893E01	sec: coil res. 348; impd. 1K audio; pri: impd. 1200; res. 125; sec: impd. 120; res. 12
Y1, 301	YM45	CRYSTAL UNIT, quartz: NOTE II
Y2	YM46	25-42 mc
		42-54 mc
		5.245 or 6.155 mc

NLN6234A Resistor Kit (Wide Channel Spacing)

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
C81, 90, 91	21K865197	CAPACITOR, fixed: 25 ±10%; 75 v; N150
C83	21K847065	500 GMV; 250 v
R35, 36	6S185B93	RESISTOR, fixed: ±10%; 1/8 w unl stated
		15K

FILTER


REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
Z1	NFN6006AS	FILTER, IF: bandpass; 20 kc
	NFN6006AW	bandpass; 40 kc
NON-REFERENCED ITEMS		
	26B82671D01	SHIELD, coil: 10 req'd
	14A82271E01	INSULATOR, coil shield; used with L1, 2, 3, 5, T1, 2



PREVIOUS REVISIONS SHOWN ON FRONT OF THIS DIAGRAM

25-54 MC "Handie-Talkie" FM Radio Carrier Squelch Schematic Diagram  
 Motorola No. 63E81017A21-AK1  
 (Sheet 1 of 2)  
 9/23/66-AP

# TRANSMITTER



TRANSMITTERS

SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF STAGES	FREQUENCY RANGE	RF POWER OUTPUT
NTB6050AA	NTB6051AA	7	1	25-30 MC	1.4 W
	NTB6052AA	9	1	30-42 MC	1.4 W
	NTB6053AA	8	1	42-54 MC	1.4 W
NTB6050AB	NTB6051AB	7	2	25-30 MC	1.4 W
	NTB6052AB	10	2	30-42 MC	1.4 W
	NTB6053AB	8	2	42-54 MC	1.4 W
NTB6060AA	NTB6061AA	7	1	25-30 MC	5 W
	NTB6062AA	9	1	30-42 MC	5 W
	NTB6063AA	8	1	42-54 MC	5 W
NTB6060AB	NTB6061AB	7	2	25-30 MC	5 W
	NTB6062AB	10	2	30-42 MC	5 W
	NTB6063AB	8	2	42-54 MC	5 W

CONTROL PANELS

MODEL NUMBER	SUFFIX	XMTR. FREQ.	RCVR. FREQ.	HANDSET	SPEAKER	MICROPHONE	RF POWER OUTPUT
NGN6023A	1	1	X				1.4 W
NGN6025A	2	1	X				1.4 W
NGN6026A	2	2	X				1.4 W
NGN6039A	1	1		X	X		1.4 W
NCN6041A	2	1		X	X		1.4 W
NCN6043A	2	2		X	X		1.4 W
NCN6044A	1	1	X	X	X		1.4 W
NCN6045A	1	1		X	X		5 W
NCN6047A	2	1		X	X		5 W
NCN6049A	2	2		X	X		5 W
NCN6052A	1	1	X	X			1.4 W
NCN6054A	2	2	X	X			1.4 W
NCN6056A	1	1	X	X			5 W
NCN6058A	2	1	X	X			5 W
NCN6060A	2	2	X	X			5 W
NCN6039B	1	1		X	X		1.4 W
NCN6043B	2	2		X	X		1.4 W
NCN6044B	1	1	X	X			1.4 W
NCN6054B	2	2	X	X			1.4 W

RECEIVERS

SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF STAGES	CHANNEL SPACING	FREQUENCY RANGE	USED WITH
NRB1120AA	NRB1121AA	12	1	40 KC	25-30 MC	SPEAKER
	NRB1122AA	15	1	40 KC	30-42 MC	SPEAKER
	NRB1123AA	15	1	40 KC	42-54 MC	SPEAKER
NRB1120AB	NRB1121AB	11	1	20 KC	25-30 MC	SPEAKER
	NRB1122AB	14	1	20 KC	30-52 MC	SPEAKER
	NRB1123AB	13	1	20 KC	42-54 MC	SPEAKER
NRB1120AC	NRB1121AC	12	2	40 KC	25-30 MC	SPEAKER
	NRB1122AC	15	2	40 KC	30-42 MC	SPEAKER
	NRB1123AC	15	2	40 KC	42-54 MC	SPEAKER
NRB1120AD	NRB1121AD	11	2	20 KC	25-30 MC	SPEAKER
	NRB1122AD	14	2	20 KC	30-42 MC	SPEAKER
	NRB1123AD	13	2	20 KC	42-54 MC	SPEAKER
NRB1150AA	NRB1151AA	8	1	40 KC	25-30 MC	HANDSET ONLY
	NRB1152AA	7	1	40 KC	30-42 MC	HANDSET ONLY
	NRB1153AA	7	1	40 KC	42-54 MC	HANDSET ONLY
NRB1150AB	NRB1151AB	7	1	20 KC	25-30 MC	HANDSET ONLY
	NRB1152AB	6	1	20 KC	30-42 MC	HANDSET ONLY
	NRB1153AB	6	1	20 KC	42-54 MC	HANDSET ONLY
NRB1150AC	NRB1151AC	8	2	40 KC	25-30 MC	HANDSET ONLY
	NRB1152AC	7	2	40 KC	30-42 MC	HANDSET ONLY
	NRB1153AC	7	2	40 KC	42-50 MC	HANDSET ONLY
NRB1150AD	NRB1151AD	7	2	20 KC	25-30 MC	HANDSET ONLY
	NRB1152AD	6	2	20 KC	30-42 MC	HANDSET ONLY
	NRB1153AD	6	2	20 KC	42-54 MC	HANDSET ONLY


POWER AMPLIFIERS

MODEL NO.	CHASSIS SUFFIX	FREQUENCY RANGE
NLB6121A	2	25-30 MC
NLB6122A	2	30-42 MC
NLB6123A	1	42-54 MC

POWER SUPPLIES

MODEL NO.	CHASSIS SUFFIX	TYPE OF BATTERIES
NPN6030B		DRY
NPN6031A		NICKEL-CADMIUM

EPD-8847-M



REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
<b>LEGEND</b>		
L = 25-30 MC		
M = 30-42 MC		
H = 42-54 MC		
<b>TRANSMITTER</b>		
NTB6051AA	NTB6061AA	
NTB6052AA	NTB6062AA	
NTB6053AA	NTB6063AA	
NTB6051AB	NTB6061AB	
NTB6052AB	NTB6062AB	
NTB6053AB	NTB6063AB	

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
C101, 141, 201	20C82399D04	CAPACITOR, fixed: uuf ±10%; 75 v; unl stated
C102, 104, 202	21K861440	470; N2200
C103, 135M, 140L, 142M, 156L, 203	21K861435	70; N150
C105L, 105H, 106M, 106H, C105M	21D82877B02	150; N1400
C107, 125H, 139M, 150	21K865922	390; 500 v
C108	21K847065	500 GMV; 250 v
C109, 110	23C82397D09	6.8 uf +40-20%; 10 v
C111	21K858108	3000 ±25%; 250 v
C113, 137	8K854329	.015 uf; 250 v
C114	23C82397D17	15 uf ±20%; 20 v
C115, 119	8C82548E03	.005 uf; 100 v
C117	23C82397D03	10 uf ±20%; 6 v
C120L, 120H, 139H, 156M, 156H	8C82548E02	.015 uf; 100 v
C120M, 132	21K861436	100; N750
C121, 128H	21K861438	220; N1400
C123L, 124L, 127L, 127M	21K861428	6; N150
C123M, 131M	21D82877B35	220; N470
C123H, 131H, 134H	21K868384	100; N150
C124M	21K864013	50; N150
C125L	21D82239E03	250 ±5%; 200 v
C126, 133, 136, 138, 149, 155M, 158	21K831126	.002 uf GMV; 300 v
C127H, 134L	21K861443	.01 uf +100-20%
C128M	21D82877B05	120; N150
C131L	21K861427	4; N150
C124H	21K864012	60; N150
	21D82877B05	150; N750

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
C134M	21K864067	80; N150
C135L	21K868384	100; N150
C135H, 159L	21K861434	40; N150
C139L, 157L, 160L	21K861432	20; N150
C138, 125M, 154M	21K861441	500; N4700
C140M, 140H, 148, 204	21D82877B19	15 ±5%; NP0
C141L	20C82399D07	var; 15-60; 200 v; N1500
C141M, 141H	20C82399D04	var; 5.5-18; 200 v; NP0
C151H	21K861430	10; N150
C154L, 154H, 155L, 155H	21C82724H01	dual sect.; each section c/o: 5500 ±100-20%
C164H	21K858108	.003 uf ±25%; 250 v
C164L, M	21C82040D12	800 uuf ±5%; 25 v
C187, 206	21D82877B11	10.5 ±5%; NP0
C188L, M	23D82397D07	1.0 uf +40-10%; 15 v
C205	21C82724H01	dual sect.; c/o: 5500 ±100-20%
C205A		5500 ±100-20%
C205B		
CR101, 102	48C82178A01	SEMICONDUCTOR DEVICE, diode: (NOTE 1)
CR103	48C82256C08	germanium
CR105	48C82392B12	zener type
		silicon
L101L, M	24C82901B04	COIL, RF: does not incl. 76K835565 CORE, tuning modulator
L101H	24C82901B05	modulator; GRN-YEL
L102	24B82194C01	1st doubler; RED
L103L, 104L	24C82904B19	quadrupler output; 2nd doubler input
L103M, 103H	24C82904B14	quadrupler output; 2nd doubler output
L104M, 104H	24C82904B15	2nd doubler input
L105L	24C82904B20	2nd doubler
L105M, 105H	24C82904B12	2nd doubler output
L106L	24B82648G01	driver input
L106M, 106H, 107M, 107H	24B82209E01	driver input; final ampl. input
L107L	24B82737E01	final ampl. input
L108L, 108M, 109L, 109M	24C82904B21	final ampl. output
L108H, 109H	24D82549D03	choke; 1 mh
L110L, 210L	24D82549D10	choke; 390 uh
L110M, 110H, 210M, 210H		
L111	25B82872B02	choke; 0.8 h
L112L	24A890687	choke; 2 uh
L112M	24A82228G01	choke; 1.2 uh
L112H	24C82000E08	choke; 0.31 uh; sleeved
L114	24D82549D09	choke; 15 uh
L115	24C83961B01	choke; 3 turns, coded BRN
L211, 212	24C82000E03	choke; 9 uh
Q101, 201	48R869010	TRANSISTOR: (NOTE 1)
Q102	48R869058	P-N-P; type M9010
Q103	48R869009	P-N-P; type M9058
Q104, 105	48R869008	P-N-P; type M9009
Q106	48R869052	P-N-P; type M9008
Q107, 108	48R869051	N-P-N; type M9051
Q110, 111	48R869038	P-N-P; type M9038
Q112	48R869079	N-P-N; type M9079
R101, 201	6K129242	RESISTOR, fixed: ±10%; 1/4 w; unl. stated
R102, 202	6R129269	56K
R103, 109	6K127803	1.8K
R104, 123L, 123M	6K127805	1.5K
R105, 126	6K127801	470
R110	6K129620	560
R111	6K129887	12K ±5%
R112	6K129668	10K ±5%
R113	6R129804	2.2K ±5%
R114	6S131594	27
R115	6S124A60	3K ±5%
R116	6K127806	27K
R117	6K129433	5.6K
R118	6K129863	390

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
R119	18B82876B04	var; 2K ±15%; 1/20 w
R120	6K128902	47K
R121	6K127804	4.7K
R122, 132L	6R127802	1K
R123H	6K129225	10K
R124, 131	6R127800	220
R125	6R127775	330
R127	6R129662	180
R133	6R131650	18
R135	6K129433	5.6K
R136	6R129231	3.3K
R137	18C82035B17	var; 10 ±20%; 1.5 w
R138L	17A82036G25	2.5 ±3%; 2 w
R138M, 138H	17A82035G26	2 ±3%; 2 w
RT102	6B859699	THERMISTOR; 75 ohms @ 25°C
Y101, 201	ABX-2	CRYSTAL UNIT, quartz; NOTE II
		xmtr. control
NON-REFERENCED ITEMS		
	26A82609E01	HEAT SINK; 3 req'd
NGN6023A	NCN6043A	NCN6052A
NGN6025A	NCN6044A	NCN6054A
NGN6026A	NCN6045A	NCN6056A
NCN6039A	NCN6047A	NCN6058A
NCN6041A	NCN6049A	NCN6060A
J801	9C82817E01	CONNECTOR, receptacle; female; coaxial; uhf type
J803	28C82846E01	male; 9 contact
K801	80C82860E01	RELAY, armature; hermetically sealed; 13.6 v d-c; 4 form "C"; coil res. 160
		LOUDSPEAKER, permanent magnet;
LS801	50D82808E01	3" square; 50 ohms impedance
R801	18C82816E02	RESISTOR, var; 10K ±10%; weatherproof
R802	6K129662	fixed; 180 ±10%; 1/4 w
R803	18C82816E01	var; 15K ±10%; weatherproof
S801	40B82851E01	SWITCH; toggle; spst; weather-resistant
S802	40C82843E01	rotary; 2 pole; 2 position; non-shorting (2-freq.)
NON-REFERENCED ITEMS		
	1V80727A11	HANDLE ASSY. incl. mic. holding clip (for models NCN6039A, NCN6041A, NCN6043A, NCN6045A, NCN6047A and NCN6049A)
	1V80729A93	HANDLE ASSY.: incl. handset holder (for models NCN6044A, NCN6052A, NCN6054A, NCN6056A, NCN6058A, NCN6060A, NCN6023A, NCN6025A and NCN6026A)
	42K861179	CLAMP, cable: 2 req'd
	42A82143C02	CLAMP, cable
	32B82855E01	GASKET, rubber; housing seal
	36B82812E03	KNOB, control; 2 req'd (vol. & sq)
	32B82804E01	KNOB, control: does not incl. 3A83174C01 SET SCREW: fluted head (F1-F2 switch)
	35B82803E01	GASKET: (speaker mtg.)
	13C82815E01	CLOTH, grille
	13C82815E04	GRILLE (1-freq. models)
	1V80749A97	GRILLE (2-freq. models)
	1V80749A98	HOUSING ASSY.: incl. handle (for NCN6039B)
	1V80749A99	HOUSING ASSY.: incl. handle (for NCN6043B)
	1V80729A94	HOUSING ASSY.: incl. handle (for NCN6044B)
	1V80731A67	HOUSING ASSY.: incl. handle (for NCN6054B)
NLN6306A Unit Component Kit		
NLN6307A Unit Component Kit		
J802	1V80715A85	CONNECTOR, receptacle; female; 4 contact; does not incl. 2A81180 NUT, knurled
R804	6R6040	RESISTOR, fixed: 680 ±10%; 1/2 w
L801 thru 804	24C82000E03	COIL, RF; choke; assembly: 9 uh
NMN6018A Microphone (plug-in; transistorized) MK501		
A501	1V80727A19	AMPLIFIER, AF; incl. C501, C502, C503, CR501, Q501, R501 and 1V80727A20 BOARD, circuit component mtg.
C501, 502, 503	21D82428B10	CAPACITOR, fixed: .0033 ±10%; 100 v
1V80731A67		SEMICONDUCTOR DEVICE, diode: NOTE I
		germanium

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
CONTROL PANEL		
NCN6039B		
NCN6043B		
NCN6044B		
NCN6054B		
J801	9C82817E01	CONNECTOR, receptacle; female; coax; uhf type
J802	1V80715A85	female; 4 cont; does not incl. 2A482070 NUT, ring; knurled
J803	28C82846E01	male; 9 cont.
K801	80C83202B01	RELAY, armature; hermetically sealed; 13.6 v d-c; 4 form "C"; coil res 160
LS801	50D83205B01	LOUDSPEAKER, permanent magnet;
		3" square; 50 ohms imp.
R801	18C82816E02	RESISTOR, var; 10K ±10%; weatherproof
R802	6K129662	fixed; 180 ±10%; 1/4 w
R803	18C82816E01	var; 5K ±10%; weatherproof
S801	40B82851E01	SWITCH; toggle; spst; weather-resistant
S802	40C82843E01	rotary; 2 pole; 2 position; non-shorting (2-freq.)
NON-REFERENCED ITEMS		
	1V80727A11	HANDLE ASSY. incl. mic. holding clip (for NCN6039B & NCN6043B)
	1V80729A93	HANDLE ASSY. incl. handset holder (for NCN6044B & NCN6054B)
	42K861179	CLAMP, cable: 2 req'd
	32B82855E01	GASKET, rubber; housing seal
	36B82812E03	KNOB, control; 2 req'd (vol. & sq)
	32B82804E01	KNOB, control: does not incl. 3A83174C01 SET SCREW: fluted head (F1-F2 switch)
	35B82803E01	GASKET: (speaker mtg.)
	13C82815E01	CLOTH, grille
	13C82815E04	GRILLE (1-freq. models)
	1V80749A97	GRILLE (2-freq. models)
	1V80749A98	HOUSING ASSY.: incl. handle (for NCN6039B)
	1V80749A99	HOUSING ASSY.: incl. handle (for NCN6043B)
	1V80729A94	HOUSING ASSY.: incl. handle (for NCN6044B)
	1V80731A67	HOUSING ASSY.: incl. handle (for NCN6054B)
NLN6306A Unit Component Kit		
NLN6307A Unit Component Kit		
J802	1V80715A85	CONNECTOR, receptacle; female; 4 contact; does not incl. 2A81180 NUT, knurled
R804	6R6040	RESISTOR, fixed: 680 ±10%; 1/2 w
L801 thru 804	24C82000E03	COIL, RF; choke; assembly: 9 uh
NMN6018A Microphone (plug-in; transistorized) MK501		
A501	1V80727A19	AMPLIFIER, AF; incl. C501, C502, C503, CR501, Q501, R501 and 1V80727A20 BOARD, circuit component mtg.
C501, 502, 503	21D82428B10	CAPACITOR, fixed: .0033 ±10%; 100 v
1V80731A67		SEMICONDUCTOR DEVICE, diode: NOTE I
		germanium

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
DP501	59C82857E01 or 59C82864E01	CARTRIDGE, microphone reluctance type
P501		CONNECTOR, plug; p/o W501
Q501	48R134621	TRANSISTOR, NOTE I P-N-P; type M4621
R501	6K127807	RESISTOR, fixed; 33K ±10%; 1/4 w
S501	40C82863E01	SWITCH; push; single pole normally open
W501	30D82565B04	CORD, microphone, incl. ref part P501 and a coiled 4 conductor; stranded cord
NON-REFERENCED ITEMS		
	15C82828E01	HOUSING, microphone: (front)
	15C82827E01	HOUSING, microphone: (rear)
	41B82856E01	SPRING, backup
	38B82833E01	BUTTON, push
	35A82853E01	DIAPHRAGM, microphone
	4C82418B22	WASHER, insulating
	75A82852E01	PAD, rubber; 1.24" dia.
	75A82192A02	PAD, rubber; 0.562" dia.
	64A82826E01	PLATE, tapped
	7B82801E01	BRACKET, hold-down
	32A8261C02	GASKET
	42B82831E01	CLAMP, cable
	1V80727A18	SPRING AND BUSHING ASSY.
	43K475873	SPACER
NLB6121A RF Amplifier (25-30 MC)		
NLB6122A RF Amplifier (30-42 MC)		
NLB6123A RF Amplifier (42-54 MC)		
C401L	21D82537B19	CAPACITOR, fixed: uuf unl. stated
C401M	21D82610C07	60 ±5%; 100 v; N150
C401H	21K410089	51; 200; N150
C402L	21K840711	27 ±10%; 500 v
C402M	21K840711	51 ±5%; 500 v
C402H	21K840365	24 ±5%; 500 v
C402H, 407H	21K859211	47 ±5%; 300 v
C403L, 403M, 406L, 406, 408	20C82109C01	var: 20-100; 350 v; N2100
C403H	20K840719	var: 8-50; 200 v
C404, 411L	21C82187B14	.001 uf ±10%; 200 v
C405, 405M	21K861435	70 ±10%; 75 v; N150
C405H	21D82610C05	57 ±5%; 200 v; N150
C407L	21K840713	120 ±5%; 500 v
C407M	21K861436	100 ±10%; 75 v; N750
C409L, 409M	21D82355B13	51 ±5%; 500 v; N1500
C409H	21D82355B14	62 ±5%; 500 v; N1500
C410L	21D82426B10	.0033 ±10%; 100 v
C410M		

REVISIONS

DIAG. ISSUE	CHASSIS AND SUFFIX NO.	REF. SYMBOL	CHANGE	LOCATION	REFER TO CIRCUIT BOARD
AN	NTB6051AC-5 NTB6052AC-8 NTB6053AC-6 NTB6061AC-5 NTB6062AC-8 NTB6063AC-6	R138L	WAS 17A82069G02 2.5; 1 W	PARTS LIST	XMTR CKT BD EPD-13429-D
		R138M, 138H	WERE 17A82069G01 2; 1 W		
AP	NTB6051AC-6 NTB6052AC-9 NTB6053AC-7 NTB6061AC-6 NTB6062AC-9 NTB6063AC-7	L111	WAS 24B82872B01	PARTS LIST	XMTRCKT BD EPD-13429-E
AR	NLB6141A-8 NLB6142A-7	C716	WAS 23D82397D16, 22 uf, 15 V	Q703 COLLECTOR	EPD-9204-K, EPD-9206-H
ARI	NRB1122AF-13 NRB1123AF-15 NRB1151AF-8 NRB1152AF-7 NRB1153AF-7 NRB1121AH-7 NRB1122AH-6 NRB1123AH-6 NTB6051AC-6 NTB6052AC-9 NTB6053AC-7 NTB6051AD-2 NTB6052AD-5 NTB6053AD-4 NTB6061AC-6 NTB6062AD-5 NTB6063AD-4 NPN6031A NLN6306A NLN6307A	C17	WAS 21D82877B17 5 uuf; N150	Q3 BASE	EPD-8838-N, EPD-13429-F, EPD-15460-A
		Q3	WAS 48R869238, TYPE M9238	1ST IF AMPL.	
		R49	WAS 6K127801, 470 OHMS	Q13 EMITTER	
		R63	WAS 6K129269, 1.8K	PARTS LIST	
		R64	WAS 6K129753 470 OHMS	PARTS LIST	
		C125M	WAS 21K847065, 500 uuf	PARTS LIST	
		C131M	ADDED 100 uuf		
		C139M	WAS C139		
		C124H	ADDED 150 uuf		
		C163, 204, 211	ADDED 15 uuf		
C601, 602	ADDED .003 uf	LOWER RIGHT OF DIAG.	NONE		
L801 THRU 804	WERE 24C847920, 9 uh		NONE		

PARTS LIST for Schematic Diagram 63E81017A22-AR1

LEGEND

L = 25-30 MC  
M = 30-42 MC  
H = 42-54 MC

NRB1121AF, NRB1151AF Receiver Circuit Board (25-30 MC) 1-Freq.  
NRB1122AF, NRB1152AF Receiver Circuit Board (30-42 MC) 1-Freq.  
NRB1123AF, NRB1153AF Receiver Circuit Board (42-54 MC) 1-Freq.  
NRB1151AH Receiver Circuit Board (25-30 MC) 2-Freq.  
NRB1152AH Receiver Circuit Board (30-42 MC) 2-Freq.  
NRB1153AH Receiver Circuit Board (42-54 MC) 2-Freq.

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
C1L, 1M, 10M C1H, 10H, 12H,	21K861433 21K861462	CAPACITOR, fixed: uuf ±10%; 75 v; unl stated 36; N150 15; N150
C2L, 2H, 32, 59 C2M, 82 C3 C4L	21D82877B02 21K868829 21C82450B27 21K861433 or 21K861434	150; N1400 220; N1400 1.5; 500 v 36; N150; handset models 40; N150; speaker models
C4M, 5M C4H, 34, 305 C5L C5H, 8M, 12M, C6, 9L, 11L	21K864013 21K861432 21K861435 21D82877B06 21C82450B30	50; N150 20; N150 70; N150 30; N150 1.8 ±5%; 500 v
C7L, 7M, 13L, 13M, 14L, 14M, 21, 27, 31, 37, 75, 77, 301, 303, 306 C7H, 13H, 14H, 43, 47, 54 C8L C8H	21K861442 21K847065 21D82877B01 21K861431	.002 uf +100-20% 500 GMV; 250 v 24; N150 12; N150
C9M, 11M, 33, 304 C9H, 11H C10L, 12L	21C82450D28 21C82450B24 21D82877B01 or 21D82877B06	1.0; 500 v 0.47; 500 v 24; N150; handset models 30; N150; speaker models
C15 C16 C17 C18, 20, 26, 28, 50 C19 C22, 23 C24, 25 C29 C30 C33, 304 C34L, 305L C35, 302 C42, 44, 46, 48, 49, 51, 56, 79, 80 C52 C53 C55 C57 C58, 62 C60 C61	21D82877B15 21K861440 21K861603 21K861444 21D82877B14 21C82450B22 21K864522 21K861429 21K865197 21C82450B28 21K861432 21K861427 21K861443 21D82239E02 23C82397D06 23C82397D16 21K864457 8C82317B03 21D82239E03 21K861441	120; N150 470; N2200 3.3 ±5%; NPO .02 uf +100-20% 91; N470 0.75; 500 v 90; N080 8; N150 25; N150 1.0; 500 v 20; N150 4; N150 .01 uf +100-20% 800 ±5%; 200 v 0.22 uf +40-20%; 35 v 22 uf ±20%; 15 v .002 uf +100-20% .03 uf; 50 v 250 ±5%; 200 v 500
C63, 78 C64 C65 C66, 67, 71 C68	23D82397D19 23D82397D05 23D82397D19 23D82397D17 21C82187B16 or 21D82428B09	2 uf +40-20%; 8 v 4.7 uf +40-20%; 3 v 2 uf +40-20%; 8 v 15 uf ±20%; 20 v 3000; 100 v (speaker models) 4700; 100 v (handset models)
C69 C70	23D82397D07 23D82397D16	1 uf +40-20%; 15 v 22 uf ±20%; 15 v (speaker models)
C72, 73 C74 C76 C83 C84 C85L, 85M	23D82397D15 23D82397D08 8C82317B06 21K861437 8C82317B01 21K861426	10 uf ±20%; 20 v 0.15 uf +40-20%; 35 v .0082 uf; 100 v 100; N2200 0.1 uf; 100 v 2.2; N150

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
CR1 CR2 CR4, 6, 7 CR8, 9, 10 CR12	48C82363E03 48C859464 48C82178A01 48C82363E02 48C82392B03	SEMICONDUCTOR DEVICE, diode; NOTE I silicon germanium germanium silicon silicon COIL, RF:
L1L, 2L, 3L	24C82765D07	GRN-RED; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-BRN; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-GRA; does not incl. 76K847160 CORE, tuning or 76A82686D01 SLEEVE, iron BLU-GRAY; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
L1M, 1H, 2M, 2H, 3M, 3H	24C82765D06	BLU-RED; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-BRN; does not incl. 76K847160 CORE, tuning or 76A82686D01 SLEEVE, iron BLU-GRAY; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
L4	24C82765D05	choke; 9 uh limiter; c/o pri: term. No. 1 and 2 with No. 5 center tap sec: term. No. 3 and 4 discriminator; 455 kc; incl. tuning core
L5L, 5H, 301L, 301H	24C82766D04	choke; 1.5 h silicon
L5M, 301M	24C82766D08	TRANSISTOR: NOTE I P-N-P; type M9375 P-N-P; type M9168 P-N-P; type M9169 N-P-N; type M9062; BLU P-N-P; type M9057
L6 L9	24C847920 24B82695D01	choke; 1.5 h silicon
L10	24B82696D01	choke; 1.5 h silicon
L12 L13	25B82751D01 48C82392B03	choke; 1.5 h silicon
Q1 Q2, 5, 301 Q3 Q4 Q6, 7, 8, 9, 10, 11 Q12, 13 Q14 Q15 Q16	48R869375 48R869168 48R869169 48K869062 48R869057 48R869148 48R869022 48R869028 48R869027	P-N-P; type M9148 N-P-N; type M9022 P-N-P; type M9028 N-P-N; type M9027
R1,14,37,38,304 R2, 9, 22, 24, 26, 28, 30, 45, 47 R3, 4, 7 R5, 65 R6, 21, 23, 25, 27, 29 R8, 52, 57 R10, 59 R11, 31 R12 R13,32,39,44 R15, 303 R16,17,34,69, 301, 302 R33, 50 R43, 60 R46 R49 R51 R53	6K127806 6K127804 6K129432 6K129433 6K127807 6K127801 6K129775 6K128685 6K129225 6K128688 6K128687 6K127802 6K128689 6K128904 6K129144 6S124A45 6K129233 6K129433 or 6K127804 6K127806 6K129862 6K128552 6K129753 6S185B84	RESISTOR, fixed: ±10%; 1/4 w; unl stated 27K 4.7K 820 5.6K 33K 470 330 22K 10K 2.7K 6.8K 1K 2.2K 18K 68K 680 ±5%; 1/4 w 47 5.6K; handset models 4.7K; speaker models 27K; speaker models 150 1.8K; 1/8 w 100; handset models 2.7K; 1/8 w TRANSFORMER, GRN-BLK; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-ORG; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-VIO; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-GRN; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
T1L	24C82767D06	GRN-BLK; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-ORG; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-VIO; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-GRN; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
T1M, 1H	24C82767D03	GRN-BLK; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-ORG; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-VIO; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-GRN; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
T2L	24C82767D07	GRN-BLK; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-ORG; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-VIO; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-GRN; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron
T2M, 2H	24C82767D04	GRN-BLK; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-ORG; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-VIO; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron GRN-GRN; does not incl. 76K861425 CORE, tuning or 76A82686D02 SLEEVE, iron

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
T3, 5	24C82767D05	GRN-BLU; does not incl. 76K847164 CORE, tuning or 76A82686D01 SLEEVE, iron RED-RED; does not incl. 76K847164 CORE, tuning or 76A82686D01 SLEEVE, iron
T4	24C82207G01	ASSY, audio input; GRN dot; c/o; pri: coil res. 1K; impd. 10K; sec: coil res. 200 impd. 1.2K
T6	1V80729A40	audio: pri: impd. 1200; res. 125; sec: impd. 120; res. 12
T7	25B82893E01	CRYSTAL UNIT, quartz; NOTE II 25-42 mc 42-54 mc 5, 245 or 6.155 mc
Y1	YM45 or YM46	
Y2	YN	

FILTER

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
Z1	NFN6006AS	FILTER, IF; bandpass
NON-REFERENCED ITEMS		
	26B82671D01 14A82271E01	SHIELD, coil: 10 req'd INSULATOR, coil shield: used with L1, 2, 3, 5, T1, 2

NLB6141A "Private-Line" Squelch Deck (25-42 MC)  
NLB6142A "Private-Line" Squelch Deck (42-54 MC)

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
C701 C702 C702A C702B	23D82397D20 21C82724H01	CAPACITOR, fixed: uf; ±10%; unl stated 0.12 ±20%; 35 v; non-polarized dual sect.; c/o: .0055 +100-20%; 75 v .0055 +100-20%; 75 v
C704 C705	23D82397D13 23D82397D10	.022; 6 v .056; 35 v
C707, 719 C709 C710 C711, 713, 724 C712, 714, 716 C715, 717 C721 C718, C720 C722,723,729,730 C726 C727 C728	23D82397D14 23D82397D05 21K847065 23D82397D07 23D82397D23 23D82397D09 23D82397D16 23D82397D28 23D82397D25 21K861442 21K858108 21K831126 21K861441	.082; 20 v 4.7 +40-20%; 3 v 500 uuf GMV; 250 v 1 +40-20%; 15 v 6.8 ±20%; 20 v 6.8 +40-20%; 10 v 22 ±20%; 15 v 3.3 ±20%; 20 v 0.27; 20 v .002 +100-20%; 75 v .003 ±25%; 250 v .002 GMV; 300 v 500 uuf; 75 v; N4700 SEMICONDUCTOR DEVICE, diode; NOTE I silicon germanium COIL, RF: choke; 7 h
CR701 CR702 L702	48C82392B03 48C82187A01 25C82750D02	TRANSISTOR: NOTE I P-N-P; type M9033 RESISTOR, fixed: ±10%; 1/8 w; unl stated 15K 6.8K; 1/4 w 8.2K 56K
Q701, 702, 703, 704	48R869033	TRANSISTOR: NOTE I P-N-P; type M9033 RESISTOR, fixed: ±10%; 1/8 w; unl stated 15K 6.8K; 1/4 w 8.2K 56K
R701, 708 R702 R703 R704, 705, 714, 716, 726 R706 R709 R710,711,712 R713 R715,717,723 R718 R719 R720 R721 R722 R724 R725	6S185B93 6K128687 6S185B90 6S185C01 6S185B70 6S185C05 6S185B87 6S185B88 6S185B83 6S129752 6K129225 6S129269 6S185B76 6K129229 6K129231 6K129432	470; (NLB6141A) 470; 1/4 w (NLB6142A)

CONTROL PANELS

MODEL NO.	CHASSIS SUFFIX	XMTR. FREQ.	RCVR. FREQ.	HANDSET	SPEAKER	MICROPHONE	RF POWER OUTPUT
NGN6024A	1	1	1	X			1.4 W
NCN6040A	1	1	1		X	X	1.4 W
NCN6042A	1	2	1		X	X	1.4 W
NCN6046A	1	1	1		X	X	5 W
NCN6048A	1	2	1		X	X	5 W
NCN6050A	1	2	2		X	X	1.4 W
NCN6051A	1	2	2		X	X	5 W
NCN6053A	1	2	1	X	X		1.4 W
NCN6055A	1	2	2	X	X		1.4 W
NCN6057A	1	1	1	X	X		5 W
NCN6059A	1	2	1	X	X		5 W
NCN6061A	1	2	2	X	X		5 W
NCN6065A	1	2	2	X	X		1.4 W
NCN6040B		1	1		X	X	1.4 W
NCN6050B		2	2		X	X	1.4 W
NCN6055B		2	2	X	X		1.4 W
NCN6065B		2	2	X	X		1.4 W

TRANSMITTERS

SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF FREQ.	FREQUENCY RANGE	RF POWER OUTPUT
NTB6050AC	NTB6051AC	6	1	25-30 MC	1.4 W
	NTB6052AC	9	1	30-42 MC	1.4 W
	NTB6053AC	7	1	42-54 MC	1.4 W
NTB6050AD	NTB6051AD	2	2	25-30 MC	1.4 W
	NTB6052AD	4	2	30-42 MC	1.4 W
	NTB6053AD	4	2	42-54 MC	1.4 W
NTB6060AC	NTB6061AC	6	1	25-30 MC	5 W
	NTB6062AC	9	1	30-42 MC	5 W
	NTB6063AC	7	1	42-54 MC	5 W
NTB6060AD	NTB6061AD	2	2	25-30 MC	5 W
	NTB6062AD	4	2	30-42 MC	5 W
	NTB6063AD	4	2	42-54 MC	5 W

RECEIVERS

SERIES	MODEL NO.	CHASSIS SUFFIX	NO. OF FREQ.	CHANNEL SPACING	FREQUENCY RANGE	USED WITH
NRB1120AF	NRB1121AF	13	1	20 KC	25-30 MC	HANDSET ONLY
	NRB1122AF	16	1	20 KC	30-42 MC	HANDSET ONLY
	NRB1123AF	15	1	20 KC	42-54 MC	HANDSET ONLY
NRB1150AF	NRB1151AF	8	1	20 KC	25-30 MC	SPEAKER
	NRB1152AF	7	1	20 KC	30-42 MC	SPEAKER
	NRB1153AF	7	1	20 KC	42-54 MC	SPEAKER
NRB1120AH	NRB1121AH	7	2	20 KC	25-30 MC	SPEAKER
	NRB1122AH	6	2	20 KC	30-42 MC	SPEAKER
	NRB1123AH	6	2	20 KC	42-54 MC	SPEAKER

POWER SUPPLIES

MODEL NO.	CHASSIS SUFFIX	TYPE OF BATTERIES
NPN6030B		DRY
NPN6031A		NICKEL-CADMIUM

"PRIVATE-LINE" DECK

MODEL	CHASSIS SUFFIX
NLB6141A	7
NLB6142A	6

POWER AMPLIFIERS

MODEL NO.	CHASSIS SUFFIX	FREQUENCY RANGE
NLB6121A	2	25-30 MC
NLB6122A	2	30-42 MC
NLB6123A	1	42-54 MC

EPD-9020-P


PREVIOUS REVISIONS SHOWN ON FRONT OF THIS DIAGRAM

25-54 MC "Handie-Talkie" FM Radio  
Dual Squelch "Private-Line"  
Schematic Diagram  
Motorola No. 63E81017A22-AR1  
(Sheet 1 of 2)  
9/23/66-AP




NOTES:

- UNLESS OTHERWISE STATED: RESISTOR VALUES ARE IN OHMS, ±10%; 1/4 WATT, K=1000. ALL CAPACITOR VALUES ARE IN MICROMICROFARADS.
- REFER TO PARTS LIST FOR COMPONENT VALUE.
- USED IN SINGLE FREQUENCY MODELS ONLY.
- PART OF HOUSING.
- REFER TO RECEIVER PRINTED CIRCUIT BOARD AND WIRING DIAGRAM FOR PROPER TAP.
- ALL VOLTAGE READINGS REFERENCED TO CHASSIS GROUND. DC READINGS TAKEN WITH A MOTOROLA DC MULTIMETER.
- FREQUENCY CALCULATIONS:  
TRANSMITTER:  $f_0 = \frac{f_c}{16}$   
RECEIVER:  $f_c =$  CARRIER FREQUENCY (25-54 MC)  
 $f_{01} =$  1ST OSCILLATOR CRYSTAL FREQUENCY (30.7-48.3 MC)  
 $f_{02} =$  2ND OSCILLATOR CRYSTAL FREQUENCY (REFER TO CHART ON BLOCK DIAGRAM)  
 $f_1 =$  1ST INTERMEDIATE FREQUENCY (5.7 MC)  
 $f_2 =$  2ND INTERMEDIATE FREQUENCY (455 KC)  
 $f_{01} = f_c + f_1$  (25-42 MC)  
 $f_{02} = f_c - f_1$  (42-54 MC)
- HANDSET MODELS ONLY.
- JU103 MAY OR MAY NOT EXIST DEPENDING UPON OPERATING FREQUENCY.
- REFER TO BATTERY REPLACEMENT AND CHARGING SECTION OF THE INSTRUCTION MANUAL FOR LOCATION OF FUSE.
- NOT USED IN 42-54 MC RANGE.
- PART OF UNIT COMPONENT KIT.

EPD-8874-D



# TRANSMITTER



REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
NON-REFERENCED ITEM		
	1V80724A84	PRINTED CIRCUIT BD. ASS'Y.

NTB6051AC, NTB6061AC Transmitter (25-30 MC) 1-Freq.  
 NTB6052AC, NTB6062AC Transmitter (30-42 MC) 1-Freq.  
 NTB6053AC, NTB6063AC Transmitter (42-54 MC) 1-Freq.  
 NTB6051AD, NTB6061AD Transmitter (25-30 MC) 2-Freq.  
 NTB6052AD, NTB6062AD Transmitter (30-42 MC) 2-Freq.  
 NTB6053AD, NTB6063AD Transmitter (42-54 MC) 2-Freq.

C101L, 141M, 141H, 201L	20C82399D04	CAPACITOR, fixed: uuf ±10%; 75 v; unl stated var; 5.5-18; 200 v; NP0
C101M	20C82399D05	var; 9-35; 200 v; N650
C101H, 201M, 201H	20C82399D06	var; 3-15; 200 v; N650
C102L, 102M, 120L, 202L, 202M	21K868829	220; N1400
C102H, 104H	21K861440	470; N2200
C103, 140L, 142M, 156L, 203	21K861435	70; N150
C105H, 106M, 106H	21D82877B02	150; N1400
C105M	21K865922	390; 500 v
C107, 125H, 139M, 150	21K847065	500 GMV; 25 v
C108	23C82397D09	6.8 uf ±40-20%; 10 v
C109, 110	21K858108	3000 ±25%; 250 v
C111	8K854329	.015 uf; 250 v
C113, 137	23C82397D17	15 uf ±20%; 20 v
C114	8C82548E03	.005 uf; 100 v
C115, 119	23C82397D03	10 uf ±20%; 6 v
C117	8C82548E02	0.15 uf; 100 v
C120H, 139H, 156M, 156H	21K861436	100; N750
C120M, 132, 106L	21K861438	220; N1400
C121, 128H	21K861428	6; N150
C123L, 124L, 127L, 127M	21D82877B35	220; N470
C123M, 131M	21K868384	100; N150
C123H, 131H, 134H	21K864013	50; N150
C124M	21D82239E03	250 ±5%; 200 v
C125L	21K831126	.002 uf GMV; 300 v
C126, 133, 136, 149, 155M, 158	21K861443	.01 uf ±100-20%
C127H, 134L	21D82877B15	120; N150
C128M	21K861427	4; N150
C131L	21K864012	60; N150
C134M, 135M	21K864067	80; N150
C135L	21K868384	100; N150
C135H, 159L	21K861434	40; N150
C139L, 157L, 160L	21K861432	20; N150
C125M, 138, 154M	21K861441	500; N4700
C140M, 140H, C141L	21D82877B19	15 ±5%; NP0
C142H	20C82399D07	var; 15-60; 200 v; N1500
C146, 206	21D82877B18	30 ±5%; NP0
C147, 207, 124H	21K861442	.002 uf ±100-20%
C151H	21D82877B05	150; N750
C153H, 163, 208H, 204, 211	21K861430	10; N150
C154L, 154H, 155L, 155H, 205A, 205B	21K861462	15; N150
C164H	21C82724H01	dual sect.; c/o: each sect: 5500 ±100-20%
C164L, 164M	21K858108	.003 uf ±25%; 250 v
C170, 172M	21C82040D12	800 uuf ±5%; 25 v
C171L	21D82877B34	150; NP0
C171M	21D82239E03	250; N150
C172L	21K861436	100; N750
C188L, 188M	21K861435	70
	23D82397D07	1.0 uf ±40-10%; 15 v
CR101, 102	48C82178A01	SEMICONDUCTOR DEVICE, diode; NOTE I germanium
CR103	48C82256C08	zener type
CR104, 201	48C863140	silicon
CR105	48C82392B12	silicon
		COIL, RF; does not incl. 76K835565 CORE, tuning modulator
L101L, 101M	24C82901B04	modulator; GRN-YEL
L101H	24C82901B05	

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
L102	24B82194C01	1st doubler; RED
L103, 104L	24C82904B19	quadrupler output; 2nd doubler input
L103M, 103H	24C82904B14	quadrupler output; 2nd doubler output
L104M, 104H	24C82904B15	2nd doubler input
L105	24C82904B20	2nd doubler
L105M, 105H	24C82904B12	2nd doubler output
L106L	24B82648G01	driver input; final ampl. input
L106M, 106H, 107M, 107H	24B82209E01	driver input; final ampl. input
L107L	24B82737E01	final ampl. input
L108L, 108M, 109L, 109M	24C82904B21	final ampl. output
L108, 109H	24C82904B01	final ampl. output
L110L, 201L	24D82549D08	choke; 6.8 uh
L110M, 201M	24D82549D10	choke; 1 mh
L110H, 210H	24D82549D03	choke; 390 uh
L111	25B82872B02	choke; 0.8 h
L112L	24A890687	choke; 2 uh
L112M	24A82228G01	choke; 1.2 uh
L112H	24C82000E08	choke; 0.31 uh; sleeved
L114	24D82549D09	choke; 15 uh
L115	24C83961B01	choke; 3 turns; coded BRN
L211, 212	24C82000E03	choke; 9 uh
		TRANSISTOR; NOTE I
Q101, 201	48R869189	P-N-P; type M9189
Q102	48R869058	P-N-P; type M9058
Q103	48R869009	P-N-P; type M9009
Q104, 105	48R869008	P-N-P; type M9008
Q106	48R869052	N-P-N; type M9052
Q107, 108	48R869051	P-N-P; type M9051
Q110, 111	48R869038	P-N-P; type M9038
Q112	48R869079	P-N-P; type M9079
		RESISTOR, fixed ±10%; 1/4 w; unl. stated
R101, 201	6K127806	27K
R102, 141M, 202, 207M	6R129269	1.8K
R103	6K127803	1.5K
R104, 123L, 123M, 134, 203	6K127805	15K
R105, 126	6R127801	470
R106, 123H	6K129225	10K
R108	6R129753	100
R109	6K128903	39K
R110, 206L, 207L	6K128689	2.2K
R111	6K129887	12K ±5%
R112	6K129668	10K ±5%
R113	6R129804	2.2K ±5%
R114	6S131594	27
R115	6S124A60	3K ±5%
R116, 139M	6K127806	27K
R117, 135	6K129433	5.6K
R118	6K129863	390
R119	18B82876B04	var; 2K ±15%; 1/20 w
R120	6K128902	47K
R121	6K127804	4.7K
R122, 132L	6R127802	1K
R124, 131	6R127800	220
R125	6R127775	330
R127	6R129662	180
R132M, 132H	6R129620	560
R133	6R131650	18
R136	6R129231	3.3K
R137	18D82035B17	var; 10
R138L	17A82035G25	2.5 ±3%; 2 w
R138M, 138H	17A82035A26	2 ±3%; 2 w
R139L, 205L	6K129242	56K
R140M, 145L, 204L, 206M	6K128687	6.8K
R142L, 142M, 208L, 208M	6K129233	47
		THERMISTOR; 75 ohms @ 25°C
RT102	6B859699	CRYSTAL UNIT, quartz; NOTE II
Y101, 201	ABS-2	xmtr. control
NON-REFERENCED ITEM		
	26A82609E01	HEAT SINK; 3 req'd

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
NLB6121A RF Amplifier (25-30 MC)		
NLB6122A RF Amplifier (30-42 MC)		
NLB6123A RF Amplifier (42-54 MC)		
C401L	21D82537B19	CAPACITOR, fixed: uuf; unl. stated
C401M	21D82610C07	60 ±5%; 100 v; N150
C401H	21K410089	51; 200 v; N150
C402L	21K840711	27 ±10%; 500 v
C402M	21K840365	51 ±5%; 500 v
C402H, 407H	21K859211	24 ±5%; 500 v
C403L, 403M, 406L, 406, 408	20C82109C01	47 ±5%; 300 v var; 20-100; 350 v; N2100
C403H	20K840719	var; 8-50; 200 v
C404, 411L	21C82187B14	.001 uf ±10%; 200 v
C405, 405M	21K861435	70 ±10%; 75 v; N150
C405H	21D82610C05	57 ±5%; 200 v; N150
C407L	21K840713	120 ±5%; 500 v
C407M	21K861436	100 ±10%; 75 v; N750
C409L, 409M	21D82355B13	51 ±5%; 500 v; N1500
C409H	21D82355B14	62 ±5%; 500 v; N1500
C410L	21D82426B10	.0033 ±10%; 100 v
C410M	21K858108	3000 ±25%; 250 v
C410H	21K858107	1500 ±25%; 250 v
C412L	21D82355B09	33 uf ±5%; 500 v; NP0
C413L	21C82372C03	0.1 uf ±80-20%; 25 v
		COIL, RF; input coil assembly
L401L	24B83349D01	input coil assembly
L401M	24V82643G01	input coil assembly
L401H	24B82640G01	input coil assembly
L402L, 402M, 402H	24V80900A86	choke; 1.02 uh
L403L, 403M	24A82813E01	coil, output
L403H	24A82818G01	coil, output
L404	24A82819G01	coil, output
L405L, 405M	24C82000E15	choke; tapped output
L405H	24C82000E14	choke; output
L406L	24B82122D04	choke; filter; 3 turns
L406H	24B82122D07	2 turns
		TRANSISTOR; NOTE I
Q401L, 401M	48R869101	P-N-P; type M9101
Q401H	48R869102	P-N-P; type M9102
		RESISTOR, fixed: ±10%; 1 w
R401L, M	6R6330	150
CONTROL PANEL		
NGN6024A	NCN6048A	NCN6055A
NCN6040A	NCN6050A	NCN6057A
NCN6042A	NCN6051A	NCN6059A
NCN6046A	NCN6053A	NCN6061A
J801	9C82817E01	CONNECTOR, receptacle; female; coaxial; uhf type
J803	28C82846E01	male; 9 contact
		RELAY, armature; hermetically sealed; 13.6 v d-c; 4 form "C"; coil res 160
K801	80C83202B01	RELAY, armature 2 form "C"; coil res 160 ohms; 13.6 v
		SPEAKER, dynamic; coil imped. 50 ohms; 3" dia. weatherproof
LS801	50D83205B01	RESISTOR, fixed: ±10%; 1/4 w; unl. stated
R801	18C82816E02	var; 10K; 0.12 w @ 55°C
R802	6S129662	180 ±10%
R803	18C82816E01	var; 5K; 0.12 w @ 55°C
R805	6S129144	68K
S801	40C82843E01	SWITCH; rotary; dp 2p (Models NCN6040B & NCN6065B)
	or 40C82891E01	rotary; 3p 4p (Models NCN6050B & NCN6055B)
S802	40B82851B01	toggle; 1 form "A"
NON-REFERENCED ITEMS		
	38B82807E01	BUTTON
	36B82628H14	KNOB, control (used on S801)
	36B82628H13	KNOB, control (used on R801 and R803)
NPN6031A Power Supply (less battery) Nickel-Cadmium		
C601, 602	21C82187B16	CAPACITOR, fixed: 3000 -10%; 100 v
	or 21K850446	3000 ±25%; 250 v
		SEMICONDUCTOR DEVICE, diode; NOTE I silicon
CR601	48C82095C01	diode; NOTE I silicon
F601	65A82496G01	FUSE, cartridge; 3 amp; 32 v; 1/4" x 5/8"
J601	9C82847E01	CONNECTOR, receptacle; female; 9 cont.
P601	28A82488G01	CONNECTOR, plug; male; 2 cont.
P602	28A16313	male; 3 cont.
XF601	1V80731A03	FUSEHOLDER ASSY; single fuse Mtg.

REFERENCE SYMBOL	MOTOROLA PART NO.	DESCRIPTION
	1V80729A93	HANDLE ASSY.; incl. handset holder (for models NCN6053A, NCN6055A, NCN6057A, NCN6059A, NCN6061A, NCN6064A)
	42K861179	CLAMP, cable; 2 req'd
	42A82143C02	CLAMP, cable
	32B82855E01	GASKET, rubber; housing seal
	36B82812E03	KNOB, control; 2 req'd (vol. & sq.)
	36B82812E01	KNOB, control; ("PL" ON-OFF)
	36B82804E01	GASKET; (speaker mtg.)
	35B82803E01	CLOTH, grille
	13C82815E03	GRILLE (1-freq. models)
	13C82815E02	GRILLE (2-freq. models)
	1V80731A68	HOUSING ASSY.; incl. handle (for models NCN6040A, NCN6042A, NCN6048A, NCN6050A and NCN6051A)
	1V80731A67	HOUSING ASSY.; incl. handle (for models NCN6051A, NCN6053A, NCN6055A, NCN6057A, NCN6059A, NCN6061A and NGN6024A)
NCN6040B Control Panel		
NCN6050B Control Panel		
NCN6055B Control Panel		
NCN6065B Control Panel		
J801	9C82817E01	CONNECTOR, receptacle; female; single cont.
J802	9B82413B01	female; 4 cont.
J803	28C82846E01	male; 9 cont.
K801	80C83202B01	RELAY, armature 2 form "C"; coil res 160 ohms; 13.6 v
LS801	50D83205B01	SPEAKER, dynamic; coil imped. 50 ohms; 3" dia. weatherproof
R801	18C82816E02	var; 10K; 0.12 w @ 55°C
R802	6S129662	180 ±10%
R803	18C82816E01	var; 5K; 0.12 w @ 55°C
R805	6S129144	68K
S801	40C82843E01	SWITCH; rotary; dp 2p (Models NCN6040B & NCN6065B)
	or 40C82891E01	rotary; 3p 4p (Models NCN6050B & NCN6055B)
S802	40B82851B01	toggle; 1 form "A"
NON-REFERENCED ITEMS		
	38B82807E01	BUTTON
	36B82628H14	KNOB, control (used on S801)
	36B82628H13	KNOB, control (used on R801 and R803)
NPN6031A Power Supply (less battery) Nickel-Cadmium		
C601, 602	21C82187B16	CAPACITOR, fixed: 3000 -10%; 100 v
	or 21K850446	3000 ±25%; 250 v
		SEMICONDUCTOR DEVICE, diode; NOTE I silicon
CR601	48C82095C01	diode; NOTE I silicon
F601	65A82496G01	FUSE, cartridge; 3 amp; 32 v; 1/4" x 5/8"
J601	9C82847E01	CONNECTOR, receptacle; female; 9 cont.
P601	28A82488G01	CONNECTOR, plug; male; 2 cont.
P602	28A16313	male; 3 cont.
XF601	1V8073	