SPECIFICATIONS

VHF	IC-F70DT/DS, IC-F70T/S	IC-F3161DT/DS,T/S IC-F3163T/S	IC-F50V	IC-F50	IC-F33GT/GS	IC-F3021T/S IC-F3023T/S	IC-F14/S
UHF	IC-F80DT/DS, IC-F80T/S	IC-F4161DT/DS,T/S IC-F4163T/S	IC-F60V	IC-F60	IC-F43GT/GS	IC-F4021T/S IC-F4023T/S	IC-F24/S
Frequency range (VHF)	136-174MHz	136-174MHz	136-174MHz	136-174MHz	136-174MHz	136-174MHz	136-174MHz
(UHF)	380–450MHz 400–470MHz 450–520MHz	400–470MHz 450–512MHz 450–520MHz	400–470MHz 450–512MHz 450–520MHz	400–470MHz 450–512MHz 450–520MHz	400–470MHz 450–512MHz 450–520MHz	400–470MHz 450–512MHz 450–520MHz	400–470MHz 450–512MHz 450–520MHz
Number of channels	256ch/32 zones	512ch/128 zones	128ch/8 zones	128ch/8 zones	256ch/16 zones	128ch/8 zones	16 (Rotary type) 4 (Max.; simple type)
Dimensions (projections are not included; WxHxD)	58.6×152×38mm 2 ⁵ / ₁₆ ×5 ³¹ / ₃₂ ×1 ¹ / ₂ in	53×136×38.9mm 2 ³ / ₃₂ ×5 ¹¹ / ₃₂ ×1 ¹⁷ / ₃₂ in	56×97×36.4mm 2 ⁷ / ₃₂ ×3 ¹³ / ₁₆ ×1 ⁷ / ₁₆ in	56×97×36.4mm 2 ⁷ / ₃₂ ×3 ¹³ / ₁₆ ×1 ⁷ / ₁₆ in	53×120×36.9mm 2 ³ / ₃₂ ×4 ²³ / ₃₂ ×1 ⁷ / ₁₆ in	53×120×36.9mm 2 ³ / ₃₂ ×4 ²³ / ₃₂ ×1 ⁷ / ₁₆ in	53×120×42.4mm 2 ³ / ₃₂ ×4 ²³ / ₃₂ ×1 ²¹ / ₃₂ in
Weight (approx.)	400g; 14.1oz (with BP-253)	340g; 12.0oz (with BP-232U)	280g/284g; 9.9/10.0oz (with BP-227, V/U)	280g; 9.9oz (with BP-227)	340g; 12.0oz (with BP-232N)	300g; 10.6oz (with BP-232N)	300g; 10.6oz (with BP-232N)
RF output power (VHF/UHF)	5W/4W	5W/5W	5W/4W	5W/4W	5W/4W	5W/4W	5W/4W
LCD display	12 character × 2 line	12 character × 2 line	8 character	8 character	8 character	8 character	LED
PTT ID	✓	V	V	✓	✓	V	Tx only
Alias Table	500	500	500	500	500	5	-
Selcall	V	V	V	✓	✓	-	-
Call Alert	✓	✓	V	V	✓	-	-
Status Message	✓	✓	Tx only	Tx only	Tx only	-	-
Status Request	✓	V	Rx only	Rx only	Rx only	-	-
Message	V	V	Tx only	Tx only	Tx only	-	-
Emergency	V	V	V	✓	V	V	Tx only
Man down function	UT-124	UT-124R	-	-	UT-124	UT-124R	UT-124
Lone Worker function	-	V	V	-	-	V	-
Radio Check	✓	V	V	V	V	Rx only	-
Radio Stun/Revive	V	V	Rx only	Rx only	Rx only	Rx only	-
Call log	✓	V	-	-	-	-	-
No. of MDC profiles	5	5	5	5	5	1	1

VHF	IC-F1821/D	IC-F1721/D	IC-F5061/D, IC-F5063	IC-F121S IC-F111S
UHF	IC-F2821/D	IC-F2721/D	IC-F6061/D, IC-F6063	IC-F221S IC-F211S
Frequency range (VHF)	136-174MHz	136-174MHz	136-174MHz	136-174MHz
(UHF)	400–470MHz 450–512MHz	400–470MHz 450–512MHz	400–470MHz 450–512MHz 450–520MHz	400–430MHz 440–490MHz
Number of channels	256ch/32 zones	256ch/32 zones	512ch/128 zones	8ch/2 zones
Dimensions (projections are not included; WxHxD)	175×45×170 mm 67/8×125/32×611/16 in	175×45×170 mm 67/8×125/32×611/16 in	160×45×150 mm 65/16×125/32×529/32 in	150×40×167.5 mm 5 ²⁹ / ₃₂ ×1 ⁹ / ₁₆ ×6 ¹ / ₃₂ in
Weight (approx.)	1.5kg; 3.3lb	1.5kg; 3.3lb	1.3kg; 2.9lb	1.1kg; 2.4lb
RF output power (VHF/UHF)	50W/45W	50W/45W	50W/45W 25W/25W (F5063/F6063)	50W/45W
LCD display	12 character × 2 line	12 character × 2 line	12 character × 2 line	LED
PTT ID	V	V	V	Tx only
Alias Table	500	500	500	_
Selcall	V	V	V	-
Call Alert	V	✓	V	-
Status Message	V	~	V	-
Status Request	V	~	~	_
Message	V	✓	V	-
Emergency	V	✓	V	Tx only
Man down function	-	-	-	-
Lone Worker function	_	_	~	_
Radio Check	V	V	V	-
Radio Stun/Revive	V	~	~	_
Call log	V	~	V	-
External out	V	~	~	-
No. of MDC profiles	5	5	5	1

-	: Not available
JT-124	
equires	internal unit

Count on us!

: Available

(Eg. UT-124)

Icom, Icom Inc. and the Icom Iogo are registered trademarks of Icom Incorporated (Japan) in the United States, the United Kingdom, Germany, France, Spain, Russia and/or other countries. All other trademarks are the properties of their respective holders.

ICOM Inc. 1-1-32, Kami-minami, Hirano-ku, Osaka 547-0003, Japan Phone: +81 (06) 6793 5302 Fax: +81 (06) 6793 0013 URL: http://www.icom.co.jp/world/index.html

Icom America Inc.

E-mail: sales@icomamerica.com
URL: http://www.icomamerica.com

2380 116th Avenue NE, Bellevue, WA 98004, U.S.A. Phone: +1 (425) 454-8155 Fax: +1 (425) 454-1509

Icom Canada

Icom (UK) Ltd. Icom New Zealand

E-mail:info@icomuk.co.uk
URL:http://www.icomuk.co.uk

Icom (Europe) GmbH

Glenwood Centre #150-6165 Highway 17, Communication Equipment Himmelgeister Str. 100, D-40225 Düsseldorf, Germany Phone: +49 (0211) 346047
Fax: +49 (0211) 33639
E-mail: info@icomeurope.com
URL: http://www.icomeurope.com

URL : http://www.icom.co.nz

Icom (Australia) Pty. Ltd. Icom Spain S.L.

Unit 1 / 103 Garden Road, Clayton, VIC 3168 Australia Phone: +61 (03) 9549 7500 Fax: +61 (03) 9549 7505

Delta, B.C., V4K 5B8, Canada Phone: +1 (604) 952-4266 Fax: +1 (604) 952-0090 E-mail: info@icomcanada.com

URL: http://www.icomcanada.com

Ctra. Rubi, No. 88 "Edificio Can Castanyer" 08190, Sant Cugat del Valles, Barcelona, Spain Phone : +34 (93) 590 26 70 Fax : +34 (93) 589 04 46

146A Harris Road, East Tamaki, Auckland, New Zealand Phone: +64 (09) 274 4062 Unit 9, Sea St., Herne Bay, Kent, CT6 8LD, U.K. Phone: +44 (01227) 741741 Fax: +44 (01227) 741742 Fax : +64 (09) 274 4708 E-mail : inquiries@icom.co.nz

Icom France s.a.s. Zac de la Plaine, 1 Rue Brindejonc des Moulinais, BP 45804, 31505 Toulouse Cedex 5, France Phone : +33 (5) 61 36 03 03 Fax : +33 (5) 61 36 03 00 E-mail : icom@icom-france.com URL : http://www.icom-france.com

Icom Polska

Fax : +48 (58) 551 0484
E-mail : icompolska@icompolska.com.pl
URL : http://www.icompolska.com.pl


Asia Icom Inc.

F No. 68, Sec. 1 Cheng-Teh Road, Taipei, Taiwan, R.O.C. Phone: +886 (02) 2559 1899 Fax: +886 (02) 2559 1874 E-mail: sales@asia-icom.com URL: http://www.asia-icom.com

Beijing Icom Ltd.

10:007, Long Siliver Mansion, No.88, Yong Ding Road, Haidian District, Beijing, 100039, China Phone : +86 (010) 5889 5391/5392/5393 Fax : +86 (010) 5889 5391 E-mail : bjicom@bjicom.com URL : http://www.bjicom.com

Your local distributor/dealer:



MDC 1200 signaling features

Compatible with other MDC 1200 systems, take advantage of Icom quality

FEATURE	FUNCTION	BENEFIT
PTT ID*	The radio sends own ID informing everyone on the system when the PTT button is pushed/released.	Allows the dispatch and other units to know who is calling. Easily identifies callers in noisy environments as the radio notifies that user who transmitted. Use with the alias table to assign text names for easy identification.
Alias Table*	Use this feature for both transmit and receive. On transmit the user can scroll through up to 500 aliases*1 on the display. Once the user selects the name the user can then call that unit. On receive if a unit ID corresponds with an alias, then that alias is shown on the display.	Allows users to quickly identify transmissions. You don't need to cross reference names to a table or memorize a bunch of numbers. Get your message through to the correct person easily. Easily identify other users by name as they communicate.
Call Alert*	In an open channel environment it allows users to sound an alert at user's radio when they're not hearing another person's call.	Useful in noisy environments where you may not hear normal calls or when the user is away from their radio.
SelCall*	Call individual users on a channel for private communications.	Enhances channel efficiency by allowing users to call a selected radio out in the field without disturb ing other users.
Emergency Call*	The emergency call function allows you to send an emergency signal to the dispatch, as well as to other units. After the dispatch acknowledges the emergency signal, the radio automatically ceases sending out the signal, clearing the channel for normal traffic.	Allows users to quickly identify who transmitted an emergency signal. The PTT ID of the unit that transmitted the emergency call is displayed on screen. Essential for public safety and plant security as well as in any hazardous, high-risk areas. The silent mode allows the user to call for help without alerting the people around them.
Emergency Man Down*	Allows the radio to automatically initiate any of the emergency features, when a "man down" condition exists (UT-124/R man down unit is required).	If someone is in trouble, the radio will automatically activate the emergency function.
Lone Worker Function*	When the radio is not operated for a preset period, the radio sounds a beep and requires you to push any button. If a button is not pushed, the radio automatically transmits an emergency signal.	If someone is in trouble, the radio will automatically activate the emergency function. This function is similar to the man down function, but does not require the man down unit.
Emergency "Hot Mic" Monitoring*	After the dispatch acknowledges an emergency message, the radio can transmit anything the microphone hears for a preprogrammed time period.	The dispatcher can listen into the environment where the emergency is taking place to help identify if an emergency exists, or what is occurring near the user.
Auto Emergency Retransmit*	If an initial emergency attempt(s) is unsuccessful due to the radio channel traffic, the radio will automatically send multiple emergency signals until it gets through. The number of retry attempts required to activate this function is programmable.	Maximizes the chance that an emergency call can be heard in a high-traffic environment.

*Depending on the model, some MDC functions are not available. Please see the back page	age for details.
---	------------------

^{*1:5} aliases only for IC-F3021 series. *2:16 status and 16 messages per a MDC system profile, 5 MDC profiles available.



IC-F1821/D









1200 functionality and operations.













IC-F1721/D

IC-F5061/D

FEATURE FUNCTION BENEFIT Call Log^{*} Displays the received call history of the SelCall. Call Log information includes the type of call, who placed alert and Emergency call. the call, and when the call was placed Status* Allows a user to set up to 16*2 conditions such as "on Immediately informs the dispatch of your current duty", "at lunch", or "in route". After a unit sends its status and allows the dispatcher/controller to obtain status to the dispatch/controller, its status will be the status at any time. maintained in memory until changed. Also program radios to poll other units for their current status. Improves channel efficiency allowing the user to Message* Send and receive up to 16*2 programmable messages to the dispatch. send commonly used messages using MDC instead of voice. Enables privacy by sending messages in digital format rather than voice and only the dispatcher can receive the messages. Send and receive stun commands. This feature will Program the radio to either disable other units or be Stun* place a subscriber unit in a stunned state where no remotely disabled itself in the event of an unauthorfunctionality is available until a revive command is ized use or a theft. Excellent for maintaining commureceived. nication integrity with minimal disruption. Revive* Send and receive revive commands. This feature In the event that a radio was stunned, the dispatch will revive a subscriber unit that previously received can remotely revive the radio. a stun command. Until a stunned unit receives this command, all functions will be locked out. Allows the dispatch to verify if a radio is powered on Check to see if a remote radio in the field is on, with-Radio Check* and within the communications range. out disturbing or notifying the user. Also check for a missing radio before initiating stun. Available on mobile units. Program this output to Allows the user to customize their mobile systems **External** become active when it receives an emergency, select for special modifications when radio receives a Output* or call alert call. Connect this output to an external select call, call alert or emergency call. device such as a siren or alarm strobe light. **Multiple** Configure up to 5 different system combinations of Allows different MDC ID numbers to be used in the

MDC System Profiles*

Compatible with

Other MDC 1200

System

all MDC functions. Store specific profiles such as PTT ID, emergency, status, etc, for the applications need on each channel.

same radio, depending upon channel selected. Perfect for integrating one radio into multiple agency communications systems or multiple locations.

Behaviorally compatible with other brand's MDC

Easily integrate Icom radios into your existing fleet using MDC 1200.